



Stem For Two Handle Kitchen, Lavatory and Tub/Shower Faucets. Shut Off Water Supply.

1. Remove handle. 2. Unscrew bonnet and pull out stem unit. 3. Replace in reverse order, making sure bonnet is wrenched tight. Important! For knob handle faucets, both stops must point toward spout for clockwise closing. For lever handle faucets, both stops point toward the right.

Tige Pour Robinets de Deux Poignées Pour L'cuisine, Lavabo et Bain-Douche. Interrrompez L'Alimentation en Eau. 1. Retirez la poignée. 2. Dévissez le capuchon et retirez l'unité de tige. 3. Remontez le robinet en suivant l'ordre inverse, en veillant que le capuchon est arraché fortement. Important ! Pour des robinets de poignée sphérique, les deux butées doivent soyez dirigé vers le bec pour la fermeture dans le sens des aiguilles d'une montre. Pour des robinets de poignée de levier, les deux butées sont dirigés vers la droite.

Eje Con cañón Para llaves de Dos Perillas para Cocina, Lavamanos, Tinas y Duchas. Cierre el Suministro de Agua. 1. Retire el mando. 2. Desatornille el bonete y hale el cañón de la unidad. 3. Reemplácelo en el orden contrario, asegurando de apretarlo bien con una llave. ¡Importante! Para llaves de perilla, ambos obstrutores deben apuntar hacia el rociador para que cierren siguiendo a las manecillas del reloj. Para llaves con manija de leva, ambos obstrutores deben apuntar hacia la derecha.

Bonnet/Capuchon/
Bonete



Made in/Fabrique a/Hecho en: USA

1.800.345.3358 deltafaucet.com