

**Fluidmaster.****INSTALL WITH CONFIDENCE****523A-009****1****TURN OFF WATER** and
REMOVE your old flapper
(SEE VIDEO)**2**

Measure old flapper with Easy Sizing Guide (see inside).

SCAN FOR
DETAILED
VIDEO:**2"****MEASURE OLD FLAPPER****3"****3a**Stretch to
remove **BLUE Seal**.**3b**Remove **BLUE Bulb**.**3c**Remove **BLUE Arms** by
pushing up on tabs.**3d**Install.
Clip **RED Arms**.***CONTINUE TO STEP 4*****OR****3a**Stretch to
remove **RED Seal**.**3b**Install using
BLUE Arms.**4****FINISH:** Connect
chain to lever leaving
1/2" slack. (**J-Shape**)**5****TURN ON WATER**
and **DISCARD**
remaining parts.**Fluidmaster.**30800 Rancho Viejo Rd.,
San Juan Capistrano, CA 92675
www.fluidmaster.com
800.631.2011
M-F 5:30 am - 5:00 pm (PST) **WARNING:** Cancer and Reproductive
Harm - www.P65Warnings.ca.gov.U.S. and other Patents Pending.
Red/Green color arrangement
is a registered trademark of
Fluidmaster Inc. ©
2024 Fluidmaster Inc. ©
Registered trademark of
Fluidmaster Inc.

P/N 5-4130, GRv. 2, 07/24

Made in Mexico.



0 39961 03544 8