



LED Wall Control



Wall Control

Models: FV-SCVE2

Compatible with:

BalancedHome® Elite & Elite Plus+:
FV-16VEC1T, FV-16VEC1S, FV-13VEC1T,
FV-13VEC1S, FV-15VE1T, FV-15VE1S,
FV-12VE1T, FV-12VE1S

Intelli-Balance® Elite & Elite Plus+:
FV-15ESC1, FV-12ESC1, FV-14ES1,
FV-11ES1

LED Wall Control

The new touchscreen LED wall control (sold separately) provides complete command over the Intelli-Balance® Elite / Elite Plus+, and the BalancedHome® Elite / Elite Plus+ ERV units. It provides users access to multiple ventilation settings while delivering real-time updates on air flow and temperature for smarter, more efficient home ventilation management.

KEY FEATURES

- Real-time display shows airflow, temperature, CFM settings, and power usage
- One-touch control activates multiple ventilation modes, including standby and boost
- Adjustable intermittent runtime per hour from 10–60 minutes
- Frost prevention mode with selectable recirculation or exhaust options for Elite Plus+ models
- Five duct configuration options for flexible installation
- Auto-balance mode activation for optimized airflow
- Selectable low/high constant run settings
- Filter status and replacement reminders
- CEC-compliant Fault Indicator Display (FID) for quick diagnostics

DISPLAY AT A GLANCE

- Ventilation Mode
- CFM Supply & Exhaust
- Power Usage
- Operation Status

Model No	FV-SCVE2
Voltage	DC12V
Power Consumption (W)	1.8
Net Weight lb. (kg)	0.26 (0.119)

The Boost Timer function allows you to turn the feature on or off and set a custom operating time.

Each time you tap, the mode changes. Display the operation status. Press to see QR information and the filter reset button.

