



Ref	Part Description	075-ASVF	100-ASVF
SOLENOID			
1	Solenoid Handle	170228	170228
2	Solenoid Repair Kit	B60599	B60599
3	Solenoid O-Ring	209502	209502
4	Solenoid Filter	(170368)	(170368)
BONNET REPAIR KIT			
5	BONNET REPAIR KIT	209398	209398
6	Flow Control Handle	208393	208393
7	Bonnet	(210334)	(210334)
8	External Bleed Screw	(234999)	(234999)
9	Stem	(207922)	(207922)
10	Stem O-Ring	(208487)	(208487)
11	Piston	(207925)	(207925)
12	Piston O-Ring	(208654)	(208654)
DIAPHRAGM REPAIR KIT			
13	DIAPHRAGM REPAIR KIT	B60486	B60486
14	Bonnet screws (6)	210295	210295
15	Diaphragm Spring	(206944)	(206944)
16	Diaphragm Assembly w/Filter	(170817)	(170817)
PLUNGER/CAP & COVER ASSEMBLY			
17	PLUNGER/CAP & COVER ASSEMBLY	151932	151933
18	Cap & Cover	(140260)	(140253)
19	Plunger	(231917)	(231917)
20	Plunger Gasket	(231916)	(231916)
21	Cap Seal	(115629)	(115629)
22	BODY NPT	(140258)	(140121)

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.