

Ignitors

Goodman
Air Conditioning & Heating




Fig.	Order #	Mfg. #	Description
A	L38-275	B1401011S	Pilot Burner
A	L39-280	B1401012	Burner Ignitor
B	L38-044	B1370724	Ignition Module
C	L38-045	B1401003S	Pilot Assembly
D	L40-068	0230K00001	Ignitor Assembly
D	L40-530	20165703S	Ignitor
E	L42-315	0130F00008S	Ignitor

Fig.	Order #	Mfg. #	Description
F	L38-046	B1401018S	Furnace Ignitor Assembly
G	L42-317	10735003A	Ignitor
H	L42-319	20261709S	Ignitor
I	L42-321	D9918202A	Ignitor Assembly
J	L42-323	11111701S	SiNi Ignitor
K	L42-326	C6411103	Module Ignition

Sensors

Goodman
Air Conditioning & Heating




Fig.	Order #	Mfg. #	Description
A	L39-282	B1172605	Flame Sensor
B	L38-034	B1172601	Spark Ignition Sensor

Fig.	Order #	Mfg. #	Description
C	L38-035	0130F00010	Flame Sensor
D	L42-334	10735201	Flame Sensor

Fig.	Order #	Mfg. #	Description
E	L42-335	C6437502	Flame Sensor

Ignition Control Modules

• For use with Goodman & Amana equipment

Goodman
Air Conditioning & Heating



Fig.	Order #	Mfg. #	Description
A	L42-311	RF000011	Ignition Control Module
B	L42-312	RF000129	Ignition Control Kit (PCBBF117) (WR #50A55-288-05)

SMARTER EVERY MINUTE

Your source for HVAC training. Gain the knowledge and skills to succeed with JohnstoneUniversity.com.

Hundreds of **FREE** product courses. Learn more and sign up today at: JohnstoneUniversity.com.

Making it Easier to Do Business



© 2019-2020 Johnstone Supply