




INSTALLATION STEPS



1. Using a bit whose diameter equals the anchor diameter, drill hole to any depth exceeding the minimum embedment. Clean hole.



2. Assemble anchor with nut and washer so that the top of the nut is flush with the top of the anchor. Drive anchor through material to be fastened so that nut and washer are flush with surface of material.



3. Expand anchor by tightening nut 3 to 5 turns, or to the specific torque requirement (see selection chart).