


Multi-Set II Anchor




To set anchor flush with surface:

1. Drill hole the same diameter as outside diameter of anchor being used to any depth exceeding minimum embedment. Clean hole.



2. Drive anchor flush with surface of concrete.



3. Expand anchor with setting tool provided. Anchor is properly expanded when shoulder of setting tool is flush with top of anchor.

To set anchor below surface:

Drill hole deeper than anchor length. Thread bolt into anchor. Hammer anchor into hole until bolt head is at desired depth. Remove bolt and set anchor with setting tool.