SCRIBE LINE 55000158 WALL CLIP FIGURE I

INSTRUCTIONS

- 1) To determine the location of the wall clip level top of backsplash against the wall.
- 2) Scribe line at top of backsplash.
- 3) Locate wall clip 3-7/16" down from scribe line (see Figure 1).
- 4) Screw wall clip to wall (screws by others).
- 5) Lift sink over wall clip (see figure 11).

NOTE: Wall clip is used to hold drainboard to wall.

