


SERVICE PARTS

RMPE



## SERVICE PARTS

**MODEL RMPE** - Parts for stainless steel models shown. For service parts for black, white, polished brass, or brushed copper models, call Broan Customer Service.

| KEY NO. | PART NO.   | DESCRIPTION                                                                  |
|---------|------------|------------------------------------------------------------------------------|
| 4       | B03295083  | GRILL STOP                                                                   |
| 5       | B003183627 | GRILL                                                                        |
| 6       | B02011013  | SPRING                                                                       |
| 9       | B08087153  | GREASE FILTER                                                                |
| 19      | B03295005  | TRANSFORMER PROTECTION                                                       |
| 26      | B02300722  | HALOGEN LAMP BULB                                                            |
| 39      | B03294033  | WIRING BOX COVER                                                             |
| 56      | B03292465  | DISCHARGE COLLAR                                                             |
| 57      | B02011004  | DAMPER FLAP                                                                  |
| 62      | BE3402860  | BLOWER CASING                                                                |
| 114     | B03290499  | WIRE CLAMP                                                                   |
| 115     | BE3334250  | CONNECTION BOX                                                               |
| 116     | BE3334252  | CONNECTION BOX COVER                                                         |
| 134     | B03295084  | STOP                                                                         |
| 144     | B03292287  | WIRE CLAMP                                                                   |
| 152     | B03292200  | WIRE CLAMP                                                                   |
| 165     | B03294781  | WIRING BOX                                                                   |
| 165     | B03294780  | CONTROLS BOX                                                                 |
| 166     | B08086141  | WIRING BOARD                                                                 |
| 195     | BE3344844  | LAMP SUPPORT                                                                 |
| 202     | B03294779  | WIRE CLAMP                                                                   |
| 202     | B03292063  | WIRE CLAMP                                                                   |
| 208     | B02300783  | TRANSFORMER                                                                  |
| 222     | B03295080  | CONTROL COVER                                                                |
| 223     | B03295082  | MOTOR BOTTON                                                                 |
| 228     | B08086262  | CONTROLS BOARD                                                               |
| 229     | B03201014  | WARNING LAMP                                                                 |
| 241     | B03295081  | LIGHT BOTTON                                                                 |
| 274     | B03295035  | FUSE BOX                                                                     |
| 415     | B03292169  | WIRE CLAMP                                                                   |
| 472     | BE3344843  | CONTROL BRACKET                                                              |
| 474     | B02300741  | HALOGEN LAMP                                                                 |
| 477     | B03294776  | TRANSFORMER PROTECTION COVER                                                 |
| *       | B06107409  | CONTROLS ASSEMBLY (INCLUDES NO. 165, 222, 228, 152, 241, 223, 229, 202, 472) |
| -       | B02300782  | FUSE                                                                         |
| -       | B02300674  | FUSE HOLDER                                                                  |
| 998     | B080810168 | HARDWARE PACKAGE                                                             |

\* Not shown assembled.