




ROMAC  
INDUSTRIES,  
INC.

# INSTALLATION INSTRUCTIONS

Read installation instructions first before installing. Check LCT Gasket to ensure that no damage has occurred during transit and that you have the right size gasket for your pipe.

## LCT Manhole Adapter Gasket



**Step 1** • Check the area where gasket will seat on the pipe to make sure there are no dents, projections, gouges, etc that will interfere with the gasket seal. Welds must be ground flush.

**Step 2** • Clean pipe, lubricate gasket and pipe surface with a suitable gasket lubricant

**Step 3** • A hole at least two inches greater than the pipe OD needs to be cut into the wall.

**Step 4** • The pipe should be centered in the hole and supported.

**Step 5** • Slide the LTC Gasket onto the pipe with the curved fins on the back side of the gasket facing the soil.

**Step 6** • Center the LCT Gasket in the wall and grout completely around the gasket filling all voids.