



PACKAGE CONTENTS 2.



Unpack your fan and check the contents. You should have the following items:

1. Fan Blades(3)
2. Hanger Bracket
3. Canopy
4. Coupling Cover
5. Fan Motor/Housing ass'y
6. Glass Shade
7. Metal Light Cover (for optional use)
8. Standard downrod ass'y
9. Minimum-length downrod (for close to the ceiling installation only)
10. Receiver (includes 6 Wire Nuts)
11. Hand Held Remote with 2 Screws
12. Balancing Kit
13. Blade Removal Kit



A. Mounting Hardware:

- Machine Screws (2)
- Flat Washers (2)
- Wood Screws (2)
- Lock Washers (2)
- Wire Nuts (3)
- Washers (2)