

Kitchen Faucets

If there is a leak from the base of the spout, kit GP30420 may need to be replaced along with the valve.



If there is dripping from the spout, replace the faucet valve.

Faucet Types



Pages 36-38

Pullout

Single-handle faucet with sprayhead that pulls out towards you.



Pages 36-38

Pull-Down

Faucet with sprayhead that pulls down towards the sink.



Pages 34-36

Single-Handle

The handle may be located on the top or side of the faucet. Faucet may have a sidespray next to the faucet. Faucets with a sidespray always have an internal diverter. If the sidespray is not working, it is most likely the diverter malfunctioning.



Page 35, 38

Remote Valve

Faucet that has the handle located to the side of the spout. Faucets may have a pull-down sprayhead or sidespray.



Pages 38-39

Wall-Mount

Faucet that is mounted to the wall. Most have two handles.



Page 33

Bridge

Two-handle faucet which is raised off the deck. These faucets may have a sidespray. If the sidespray is not working, it is most likely the diverter inside the faucet that is malfunctioning.



Pages 31-34

Two-Handle

Two-handle faucets come with or without an escutcheon. These faucets may have a sidespray. If the sidespray is not working, it is most likely the diverter inside the faucet that is malfunctioning.



Page 33, 37

Single-Hole, Two-Handle

These faucets may have a sidespray. If the sidespray is not working, it is most likely the diverter inside the faucet that is malfunctioning.

Common Valves



GP77548



GP1016515



GP1017426




1170273
(Antique only –
See page 31)



GP1093674



1090948



GP30420 O-Ring Kit
(See pages 34-35 to see if
this is required.)

Suggest replacing with
valve, if applicable.



Full Turn
GP30002 (H)
GP30004 (C)



1/4 Turn
GP77005-RP (H)
GP77006-RP (C)



UltraGlide 1/4 Turn
GP1092204 (H)
GP1092203 (C)



GP76672 (H)
GP76671 (C)

Common Sidesprays



1011130*
(Includes hose
and holder)



1021724*
(Sprayhead with Hose)
1021728* (Holder)



1148477* (Sprayhead)
1141915 (Hose)
1132472* (Holder)



1088395* (Sprayhead)
1088396 (Hose)
1087232 (Holder)

Common Miscellaneous Kitchen Parts



1023391* (Stopper)
1023393* (Flange)



41398* (Strainer)



87404 (1.5 gpm Filter)
87406 (0.6 gpm Filter)

For individual kitchen faucet details, see pages 31-39.