


## Mounting Adaptor (#12904)

This adaptor will fit an InSinkErator sink opening of: 6-5/8" I.D. and 7-1/8" O.D.



### Installation Instructions

1. Place the split ring (2) around the sink bowl connection neck (located just above the sink bowl connection lip).
2. Insert ten screws (1) through the split ring (2), flat gasket (3), and mounting flange (4) tapering downward. With screws protruding through the mounting flange (4), attach ten lock washers (5) and ten nuts (6). Tighten all screws evenly.

**NOTE:** This adaptor is used to reduce the InSinkErator #6, #7, or sink bowl openings (12, 15, or 18) to a 3-1/2" diameter, accommodating a standard sink flange.