

# Grip Tip™

## Test Plug & Test Cap

Patent #6,769,291



Available in both Test Cap and Test Plug

### Test Cap


OVER PIPE



Glue over pipe O.D. • Cut off with saw

### Test Plug

INSIDE PIPE



Glue into pipe I.D. • Knock out in one piece

- Double tip acts as a handle while applying glue and can be snipped to allow filling and bleeding with water or air for testing
- Deeper glue surface ensures a good seal especially on unevenly cut pipe
- Durable, virgin ABS may be glued to pipe with PVC, ABS, or all-purpose cement
- High visibility models make installed plugs and caps easy to see for ensured removal



Hangers & Brackets   Preformed Copper   Arresters & Trap Primers   Drainage Products   Plumbing Specialties



# Air and Water Testing

FOR BOTH STYLES



### Remove Test Tip

Grip and twist off the small tip before doing an air or water test on the DWV system. This creates a 1/4" hole for filling and draining the system.



### Air Test

Attach the compression end of valve (881-02A) to the large 5/8" O.D. tip. Attach air hose to valve and test as usual. Safely holds up to 15 psi.



### Water Test

Attach compression end of valve (881-02H) to the large 5/8" O.D. tip. Attach garden hose to female swivel end and test as usual. Safely holds over 3 floors.



### Ground-Rough Head Tests

Screw a #8 washer-head screw (591-08) into the center of the small tip. Loosen the screw to bleed the air out and retighten to test.

## Test Plug

INSIDE PIPE



### Apply Cement

Apply cement around the outside of the plug. The large tip and the deep glue surface make application easier.



### Use in Sioux Chief Drains

The Grip Tip can be installed in Sioux Chief Smart drains. Look for this icon in our catalog.



### Knock Out

After testing and draining the system, hit the raised rim in one spot until the edge fractures. The knockout will never shatter.



### Remove Knockout

Grasp the large tip and peel back to remove the loose knockout. The knockout always comes out in one piece.

## Test Cap

OVER PIPE



### Apply Cement

Apply cement around the inside of the cap. The large tip and the deep glue surface make application easier.



### Saw Off Cap

After testing and draining the system, saw the cap off and proceed with installation.

## Air & Water Test Valves

The 5/8" poly ferrule (supplied) is reusable. Always use a poly ferrule when attaching to the Grip Tip.



Item No.	Description	Min. Qty.	Case Qty.	List Price
<b>TEST CAP - INDIVIDUALLY BAR CODED IN CUT CASE</b>				
880-81PK	1 1/2" Grip Tip test cap - natural	50	50	.68 EA
880-82PK	2" Grip Tip test cap - natural	50	50	.70 EA
880-83PK	3" Grip Tip test cap - natural	25	25	.86 EA
880-84PK	4" Grip Tip test cap - natural	25	25	.90 EA
<b>TEST CAP - BULK</b>				
880-81	1 1/2" Grip Tip test cap - natural	25	200	.29 EA
880-82	2" Grip Tip test cap - natural	25	200	.34 EA
880-83	3" Grip Tip test cap - natural	10	50	.46 EA
880-84	4" Grip Tip test cap - natural	10	50	.60 EA
880-81C	1 1/2" Grip Tip test cap - high-visibility	25	200	.31 EA
880-82C	2" Grip Tip test cap - high-visibility	25	200	.36 EA
880-83C	3" Grip Tip test cap - high-visibility	10	50	.48 EA
880-84C	4" Grip Tip test cap - high-visibility	10	50	.62 EA
<b>TEST PLUG - BULK</b>				
881-10	1 1/2" Grip Tip test plug - natural	25	200	.29 EA
881-12	2" Grip Tip test plug - natural	25	200	.34 EA
881-13	3" Grip Tip test plug - natural	10	50	.46 EA
881-14	4" Grip Tip test plug - natural	10	50	.60 EA
881-10C	1 1/2" Grip Tip test plug - high-visibility *	25	200	.31 EA
881-12C	2" Grip Tip test plug - high-visibility *	25	200	.36 EA
881-13C	3" Grip Tip test plug - high-visibility *	10	50	.48 EA
881-14C	4" Grip Tip test plug - high-visibility *	10	50	.62 EA
<b>TESTING ACCESSORIES - BULK</b>				
881-02A	Air test valve for Grip Tip 5/8" O.D. comp x Schrader valve with gauge	1	10	23.88 EA
881-02H	Water test valve for Grip Tip 5/8" O.D. comp x female swivel hose thread	1	10	13.77 EA
881-02FP	Replacement 5/8" poly ferrule	100	1000	.24 EA

\*The pink rim of the Grip Tip Test Plug may be visible after installation. Use discretion when installing in any location where a visible rim would be undesirable.

### DISTRIBUTED BY

tel: 1-800-821-3944  
 fax: 1-800-758-5950  
 www.siouxchief.com  
 P.O. Box 397  
 24110 South Peculiar Drive  
 Peculiar, Missouri 64078 U.S.A.

