

Capacity: 1/8", through 2 1/2"



NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.

Ref. No.	Catalog No.	Description
1	40895	Base
2	40915	Legs & Tray Assembly
3	41240	Tool Tray
4	40900	Yoke & Hook Assembly
5	40920	Yoke Assembly
6	41235	Tray Support with Screw
7	40380	Hook Assembly
8	46675	Leg Bolt
9	44225	Nut (3)
10	40930	Lock Washer (3)
11	41265	Tray Pin & Washer (3)
12	41270	"X" Washer (3)
13	41245	Set Screw
14	41255	Front Leg Assembly (2)
15	41250	Rear Leg Assembly
16	40945	Leg Chain
17	40905	Hinge Bolt, Nut & Washer
18	40910	Lower Jaw Screw (2)
19	40385	Jaw Clamp Screw with Washer (2)
20	40390	Feed Screw
21	72102	Jack Screw Assembly
22	40395	Jaw Clamp Set
23	40940	Grommet (3)
24	40400	Upper Jaw
25	40405	Lower Jaw (1 Set)
26	40415	Hinge Pin

Capacity: 1/8", through 2 1/2"




NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.

Ref. No.	Catalog No.	Description
—	16703	425 TRISTAND®
1	19063	Hex Bolt, 3/8" - 16 x 3 1/2"
2	59970	Flat Washer, 3/8"
3	19118	Latch
4	19113	Torsion Spring
5	19108	Latch Bushing
6	19103	Adjuster Shoe Assembly
7	83545	Jam Nut, 3/8" - 16"
8	41005	Chain Assembly
9	41040	Chain Screw Pin
10	41065	Chain Screw
11	41020	Jaw
	41280	Jaw for Plastic Pipe
	40222	Jaw for Coated Pipe
12	41025	Friction Ring
13	41060	Swivel Nut w/Friction Ring
14	41015	Handle
15	41050	Handle Assembly
16	79985	Lock Nut, 3/8" - 16 (4)

Ref. No.	Catalog No.	Description
17	58052	Hex Bolt, 3/8" - 16 x 2 1/2" (3)
18	19053	Base
19	40990	Roll
20	41035	Roll Pin
21	40770	Lock Washer, 3/8" (2)
22	76735	Spring Pin
23	32457	Screw w/Washer (2)
24	89720	Pivot Pin (6)
25	19088	Link (6)
26	41270	X-Washer (6)
27	18228	Hand Grip
28	19093	Center Ring w/Handle
29	19098	Center Tube
30	19533	RIDGID Label
31	40940	Grommet (3)
32	19068	Rear Leg Assembly
33	19078	Right Leg Assembly
34	19073	Left leg Assembly
35	68625	Link


Capacity: 1/8", through 5"



NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.


Ref. No.	Catalog No.	Description
1	72097	Base with Wear Plate and Screws
2	40915	Leg & Tray Assembly
3	41240	Tool Tray
4	41235	Tray Support with Screw
5	40960	Screw with Washer (2)
6	46675	Leg Bolt (3)
7	44225	Nut (3)
8	40930	Lock Washer (3)
9	41020	Jaw
	41280	Jaw for Plastic Pipe
	40222	Jaw for Coated Pipe
10	40955	Wear Plate
11	89720	Tray Pin with "X" Washer (3)
12	41270	"X" Washer (3)
13	41245	Set Screw
14	41255	Front Leg Assembly (2)
15	41250	Rear Leg Assembly
16	40945	Leg Chain
17	41090	Jaw Screw with Washer (2)
18	68625	Link
19	41015	Handle
20	41060	Swivel Nut with Friction Ring
21	41025	Friction Ring
22	41065	Chain Screw
23	41035	Roll Pin
24	40990	Roll
25	72092	Chain Assembly
26	41040	Chain Screw Pin
27	41050	Handle Assembly
28	72102	Jack Screw Assembly
29	31650	Nut Locking Pin
30	40940	Grommet (3)

Capacity: 1/8", through 6"




NOTE: Order parts by Catalog Number only.
DO NOT order by Reference Number.

Ref. No.	Catalog No.	Description
—	72037	460 TRISTAND®
—	72042	460E TRISTAND® Export
1	40915	Leg & Tray Assembly
2	41250	Rear Leg Assembly
3	40940	Grommet (3)
4	40945	Leg Chain
5	41265	Tray Pin with "X" Washer (3)
6	41270	"X" Washer (3)
7	41235	Tray Support with Screw
8	41245	Set Screw
9	46675	Hex Bolt 3/8" - 16 x 2 3/4" (3)
10	40930	Lock Washer 3/8" (3)
11	44225	Nut 3/8" - 16 (3)
12	72102	Jack Screw Assembly
13	41020	Jaw
	41280	Jaw for Plastic Pipe
	40222	Jaw for Plastic Coated Pipe
14	72092	Chain Assembly
15	41065	Chain Screw
16	41015	Handle
17	41025	Friction Ring
18	41060	Swivel Nut w/Friction Ring
19	41050	Handle Assembly
20	41040	Chain Screw Pin
21	31650	Nut Locking Pin
22	40990	Roll
23	41035	Roll Pin
24	60080	Washer, 5/16"
25	95397	Screw, 5/16" - 18 x 2"
26	93537	Wear Plate
27	72097	Base with Wear Plate and Screws
28	41240	Tool Tray
29	41255	Front Leg Assembly (2)
30	68625	Chain Extension Link



NOTE: Order parts by Catalog Number only. DO NOT order by Reference Number.

Ref. No.	Catalog No.	Description
1	40915	Leg & Tray Assembly
2	44225	Nut 3/8" - 16 (3)
3	46675	Hex Bolt 3/8" -16 x 2 3/4" (3)
4	40940	Grommet (3)
5	39743	Leg Chain Assembly
6	39733	Rear Leg Assembly
7	41255	Front Leg Assembly (2)
8	41235	Tray Support with Screw
9	41245	Set Screw
10	41265	Tray Pin with "X" Washer (3)
11	41270	"X" Washer (3)
12	41240	Tool Tray
13	39728	Base with Wear Plate and Screws
14	39748	Wear Plate
15	95397	Screw, 5/16" -18 x 2"
16	60080	Washer, 5/16"
17	41035	Roll Pin
18	31650	Nut Locking Pin
19	40990	Roll
20	72102	Jack Screw Assembly
21	41020	Jaw
	41280	Jaw f/Plastic Pipe
	40222	Jaw f/Plastic Coated Pipe
22	72092	Chain Assembly
23	41065	Chain Screw
24	41015	Handle
25	41050	Handle Assembly
26	41060	Swivel Nut w/Friction Ring
27	41025	Friction Ring
28	41040	Chain Screw Pin
29	68625	Chain Extension Link



NOTE: Order parts by Catalog Number only. DO NOT order by Reference Number.

Ref. No.	Catalog No.	Description
1	44225	Nut 3/8" - 16 (3)
2	46675	Hex Bolt 3/8" -16 x 2 3/4" (3)
3	40940	Grommet (3)
4	39743	Leg Chain Assembly
5	39778	Rear Leg Assembly
6	41255	Front Leg Assembly (2)
7	41235	Tray Support with Screw
8	41245	Set Screw
9	41265	Tray Pin with "X" Washer (3)
10	41270	"X" Washer (3)
11	41240	Tool Tray
12	39773	Base with Wear Plate and Screws
13	39748	Wear Plate 460-12
14	95397	Screw, 5/16" -18 x 2"
15	60080	Washer, 5/16"

Ref. No.	Catalog No.	Description
16	39788	Bolt
17	39783	Conversion Arm
18	72102	Jack Screw Assembly
19	39768	Jaw
20	40990	Roll
21	31650	Nut Locking Pin
22	41035	Roll Pin
23	39763	460-12 Chain Assembly
24	41065	Chain Screw
25	41015	Handle
26	41050	Handle Assembly
27	41060	Swivel Nut w/ Friction Ring
28	41025	Friction Ring
39	41040	Chain Screw Pin
30	32555	Chain Ring