


INNER HOUSING END SEALS

Model 2200 and 2250 seal is 20.56" long x 6.88" wide.

Model 2400 and 5000 seal is 16.12" long x 6.88" wide.

INSTALLATION:

1. Remove old seal and scrape smooth.
2. Apply 3M spray adhesive or any household adhesive generously to seal installation area.
3. For white polyester seal, apply with the scrim (thin polyester sheet) facing up.




FOAM OUTER HOUSING SEAL

Model 2200 seal is 21.20" long x .75" wide.

Model 2400 and 5000 seal is 17.00" long x .75" wide.

INSTALLATION:

1. Remove old pink seal and scrape smooth.
2. Wipe seal installation area clean.
3. Remove paper backing from new foam seal and apply to the inside of the Outer Housing on inlet side of rail as shown.



DOOR SEALS

Model 2200 seal is 22.38" long x 8.63" wide.

Model 2400 seal is 17.13" long x 8.63" wide.

INSTALLATION:

1. Remove old pink seal and scrape smooth.
2. Apply 3M spray adhesive or any household adhesive generously to seal installation area.
3. Apply new polyester seal with scrim (thin polyester sheet) facing up.



Older Models



Current Model

Remove
Foam Seal
and Replace