Mounting Plate Instructions

Model MPW101

Installer

To assure you install this model easily and correctly, PLEASE READ THESE SIMPLE INSTRUCTIONS BEFORE STARTING THE INSTALLATION. CHECK YOUR INSTALLATION FOR COMPLIANCE WITH PLUMBING, ELECTRICAL AND OTHER APPLICABLE CODES. After installation, keep these instructions for future reference.


IMPORTANT


ALL SERVICE TO BE PERFORMED BY AN AUTHORIZED SERVICE PERSON

Parts List


Refer to the illustration to make sure you receive all mounting plate parts. If any parts are missing, please call our Customer Care at 1.800.476.4106.

ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	1	28792C	Mounting Plate
2	16	70020C	Hex Nut 5/16-18
3	16	75541C	Flat Washer .339/.359ID
4	4	75708C	Threaded Rod 5/16-18 x 6 ln.






This Mounting Plate System is designed for use with the following models: Single HDFF Series, Single HRF Series, Single Soft Sides®, Single SwirlFlo®




HDFF Series, HRF Series, SoftSides® Series Fig. 1



SwirlFlo® Series Fig. 2


HDFF Series/HRF Series/SoftSides®

When mounting plate directly to wall studs please refer to the diagrams shown below. For electrical, waste, and water supply locations please refer to the Installation/Owners manual.




HDFF Series/HRF Series/SoftSides®

When using mounting plate with ML100 (Support Columns) please refer to the diagrams shown below. For electrical, waste, and water supply locations please refer to the Installation/Owners Manual for the specific unit.




Swirlflo® Series

When mounting plate directly to wall studs please refer to the diagrams shown below. For electrical, waste, and water supply locations, please refer to the Installation/Owners Manual for the specific unit.



SwirFlo® Series

When using mounting plate with ML100 (Support Columns) please refer to the diagrams shown below. For electrical, waste, and water supply locations please refer to the Installation/Owners Manual for the specific unit.



** WITH STANDARD STUD LENGTH OF 6 INCHES.
NOTE - AFTER INSTALLATION, U-BOLTS AND THREADED RODS MAY NEED TO BE TRIMMED.

For Technical Service, please contact us at 1.800.476.4106