

**Stop the flow of water without
shutting down the system.
A must for every Fire Department
or building owner.**

ARGCO
1-877-982-7426



SPRINKLER STOP™

Easily fits into
fireman's coat
pocket or in spare
sprinkler head box.

Only 6-3/4" long
and weighs 10 ounces.

Universal sprinkler stopper designed to fit into recessed sprinkler heads but can be set to stop the flow of water from most sprinkler heads.

When one or two sprinkler heads control or extinguish a small fire, the sprinkler stop valve allows fire crews to stop water damage from occurring without shutting the sprinkler system down while they attend to other tasks such as evacuation of the building, ventilation, checking for extension of fire, and starting salvage and overhaul operations.



Simply push rubber stop into opening of sprinkler head and turn handle until water flow stops.

1-877-982-7426



fax: 303-484-1046