


Washbasin -
Three-hole basin mixer with pop-up waste
Article number: 20 710 882-33 0010





Washbasin -
Three-hole basin mixer with pop-up waste
Article number: 20 710 882-33 0010

Spare parts list

Position	Quantity used	Item Number	Spare part	Delivery time
1	1	90 28 22 217 02-33	spout	-
2	1	90 23 01 028 04-33	aerator	30
3	1	09 30 30 057 90	screw	2
4	1	09 11 10 087 10-33	connection	30
5	1	04 20 89 030 80-33	pull-rod	30
6	1	09 28 10 133-33	ring	30
7	1	90 17 11 040 51 90	side panel	2
8	2	04 30 04 019 00 90	hose	2
9	1	09 14 05 047 90	seal	2
10	1	04 30 11 038 00 90	fixing set	2
11	1	09 31 11 011 90	pin	2
12	2	04 20 88 052 00-33	handle	30
13	2	04 18 20 022 00-33	angle	60
14	2	09 20 88 052-33	handle	30
15	2	90 12 12 007 00-33	base	30
16	2	09 30 11 029 90	disc	2
17	2	09 30 30 075 90	screw	2
18	2	09 21 02 140-33	sleeve	30
19	2	09 27 89 105-33	rosette	30
20	2	09 14 10 043 90	seal	2
21	1	90 17 11 040 50 90	side panel	2
22	2	04 23 30 040 00-33	threaded connector	10
23	1	04 11 01 023 00-33	Basin Waste US 1 1/4"	30