

# MODEL 460XL and 460

## Spill Resistant Pressure Vacuum Breaker – 3/8" to 1"



Repair Kit Components		3/8" and 1/2"		3/4" and 1"	
Item #	Item Description	RK12-460	RK12-460R	RK1-460	RK1-460R
1	Screw, Canopy	●		●	
2	Canopy	●		●	
3	Bonnet	●		●	
4	O-Ring, Bonnet	●	●	●	●
5	Spring, Vent	●		●	
6	Vent Cage	●		●	
7	O-Ring, Vent Poppet	●		●	
8	Poppet, Vent	●	●	●	●
9	Thrust Washer	●		●	
10	Diaphragm	●	●	●	●
11	Check Cage	●		●	
12	Spring, Check	●		●	
13	Poppet, Check	●		●	
14	Seal Ring	●	●	●	●
15	O-Ring, Seat	●	●	●	●
16	Seat	●		●	
17	O-Ring, Check Cage	●	●	●	●
18	Screw, Bleed	●		●	

Whole Goods (Available for individual sale)					
Item #	Item Description	3/8"	1/2"	3/4"	1"
19	Ball Valve, Outlet	38-850XL	12-850XL	34-850XL	1-850XL
20	Ball Valve, Inlet	38-850TXL	12-850TXL	34-850TXL	1-850TXL
21	Test Cock	18-860XL			

Item No.	Repair Kit Description
<b>3/8" and 1/2"</b>	
RK12-460	Complete Repair Kit, 3/8" and 1/2" 460XL
RK12-460R	Rubber Repair Kit, 3/8" and 1/2" 460XL
<b>3/4" and 1"</b>	
RK1-460	Complete Repair Kit, 3/4" and 1" 460XL
RK1-460R	Rubber Repair Kit, 3/4" and 1" 460XL

