As Easy to Install as It Is to Use!

The innovative SinkTop Switch" is an ideal solution for builders or remodelers looking for that touch of elegance that makes a new kitchen shine. And best of all, the UL:approved SinkTop Switch installs quickly and easily.

Here's How the SinkTop Switch Works:

The remote push button uses air pressure to activate the power module, located under the sink. When pressed, the SinkTop Switch sends a pulse of air down the air tube, triggers the remote switch and activates the disposer.



SinkTop Switch™ Kit Includes:

- · Power module with cord
- · 6-foot-long air tube
- Complete step-by-step installation instructions



Matte Black*

SinkTop Switch™ Push Buttons

Dual-outlet includes chrome and white
Single-outlet includes satin nickel,

· Other finishes available by special order

chrome and white

Typical Installation



1.800.558.5700 www.insinkerator.com

in sink erator



Food waste disposers provide an environmentally responsible alternative to transporting food waste to landfills. And they can help reduce greenhouse gas emissions. At capable wastewater treatment plants, food waste can be converted to biosolids and used as fertilizer. Capable plants can also capture methane gas and recycle it as an energy source. (Check the plant in your area.)

www.insinkerator.com/green



Oil-Rubbed Bronze*

* Special Order Finish



The Emerson logo is a trademark and

inSineStator may make improvements anglor changes in the specifications at any time, in its sale discretion, without notice or obligation and further research the notice to represent the models.