



# RHBL

Parts List  
03-October-2017



*This parts list is current as of the above revision date.  
See <http://www.rheempartslists.net/92-42800-RHBL.pdf> for the current revision.*

**Air Handlers**

No.	Notes	MODEL CABINET CAPACITY METERING VOLTAGE	RHBL- FR 24 T J	RHBL- FR 36 T J
<b>COIL GROUP</b>				
19		Coil	RCKL-T24A	RCKL-T36A
		Header - Coil	82-103227-07	82-103227-06
		Coil Seal	68-103682-01	68-103682-02
16		Coil Bracket - Left	AE-103106-01	AE-103106-05
17		Coil Bracket - Right	AE-103106-02	AE-103106-06
18	Stk	Drain Pan	68-103104-01	68-103104-02
18a		Drain Shield	AE-104877-01	AE-104877-01
31	Stk	TXV - Expansion Valve	61-103652-07	61-103652-01
		Bulb Strap Kit - TXV	64-101357-01	64-101357-01

No.	Notes	MODEL CABINET CAPACITY VOLTAGE	RHBL- FR 24 J	RHBL- FR 36 J
<b>HEATER KITS</b>				
		Heater Kit - 3kW/208-230/1	RXHJ-21B03J	RXHJ-24B03J
		Heater Kit - 5kW/208-230/1	RXHJ-21B05J	RXHJ-24B05J
		Heater Kit - 8kW/208-230/1	RXHJ-21B08J	RXHJ-24B08J
		Heater Kit - 10kW/208-230/1	RXHJ-21B10J	RXHJ-24B10J