

ROOT 66 PARTS LIST

ITEM NO.	CATALOG NO.	DESCRIPTION	ITEM NO.	CATALOG NO.	DESCRIPTION
178275	66-100	Frame & Clutch Housing Assembly	178615	66-330	Coil Spring
178280	66-101	Clutch Housing	178660	66-403	Ball Bearing
178285	66-101-A	Grease Fittings (2)	178670	66-404	Mounted Collar w/Knob
178310	66-101-B	Bronze Bushing	178680	66-404-A	Knob
178315	66-102	Rear Casting	178690	66-404-B	Set Screws (3)
178320	66-102-A	Grease Fitting (1)	178695	66-404-C	Grease Fitting
178325	66-102-B	Socket Head Cap Screws (4)	178710	66-405	Flange Bearing Set (2)
178350	66-110	Drip Guard	178730	66-407	Fiber Washers (3)
178360	66-150	Leg Assembly	178740	66-408	Brake Disc
178365	66-150-A/B	Left & Right Leg Assembly	178750	66-409	Spacer
178390	66-150-C	Rubber Pads, Screws, Nuts & Washers (4)	178760	66-410	Slotted Tube
178370	66-150-D	Front Leg Spacer	178770	66-411	Snap Ring
178375	66-150-E	Rear Leg Spacer	178230	66-35-0	Container (for 3/8" & 5/16" Cables)
178380	66-150-F	Bolts (4)	178805	66-451	Container Shell
178385	66-160-1	Cutter Bag	178810	66-451-A	Container Front
178430	66-200	Clutch Assembly	178820	66-451-B	Container Back
178440	66-210	Ball Thrust Bearing	178825	66-451-C	Screws & Clips (3)
178450	66-215	Shaft w/Key	178840	66-452	Spindle for Large Drum
178460	66-220	Large Bevel Gear w/Set Screw	178850	66-456	Washer (2)
178470	66-225	Front Cone w/Pins	178855	66-457	Thrust Bearing Race
178410	66-225-A	Guide Pins (3)	178860	66-465	Nut
178480	66-225-B	Set Screw	178900	66-600	1/3 hp Motor w/Reverse Switch & GFCI
178500	66-234	Clutch Jaws, Pins & Springs (3)	168880	66-600-1	1/2 hp Motor w/Reverse Switch & GFCI
178510	66-234-B	Springs Only (3)	178910	66-601	Small Bevel Gear w/Set Screws
178415	66-234-C	Spring Pins Only (3)	178920	66-602	Mounting Bolts (2)
178520	66-235	Rear Cone w/Shaft	136010	GFI-10	GFCI w/10' Power Cord
178530	66-240	Ball Thrust Bearing	178940	66-605	Reverse Switch Assembly
178540	66-300	Rack & Pinion Assembly	178950	66-605-A	Switch Box Only w/Cover & Screws
178550	66-301	Pinion Gear	178960	66-605-G	Reverse Switch
178560	66-305	Clutch Handle	178965	66-605-H	Rubber Switch Boot
178570	66-307	Retaining Knob	178973	66-605-K	Switch Guard
178580	66-310	Drive Collar (Rack)	178970	66-610	Motor Drip Shield
178590	66-315	Hair Pin Spring	178250	66-RGH	Rear Guide Hose
178600	66-320	Retaining Washer	178240	66-W	Dolly for Root 66
178610	66-325	Snap Ring	132210	66-DECALS	Set of Safety Decals
			140840	BNDT	Band-It Splashguard

ROOT 66 SCHEMATIC DIAGRAM

