



ROHL DECORATIVE LUXURY AIR ACTIVATED SWITCH BUTTON ONLY FOR WASTE DISPOSAL

ROHL Kitchen Accessories

AS525

FEATURES

- Traditional styling
- Remote on/off air switch button for activating continuous feed waste disposals
- Transmitter button with escutcheon, base and fastening nut included
- 1 1/4" cutout, 1 3/4" max. installation depth on deck or wall
- Escutcheon and button made of brass
- Does not come with control box, button only
- Includes ROHL branding on top of button
- Button and escutcheon adhered to base

COLORS/FINISHES

- Polished Chrome
- Polished Nickel
- Satin Nickel
- Tuscan Brass
- Inca Brass
- English Bronze
- Stainless Steel

WARRANTY

- 2-year Limited Warranty*
- *No Warranty on Tuscan Brass Finish (TCB)

