



MINI-ROOTER XP PARTS LIST

Note: Parts shown indented beneath another part are included with the item they are listed under.

ITEM NO.	DESCRIPTION	ITEM NO.	DESCRIPTION
169005	Complete Frame Assembly (Includes XP-304, XP-305, and AFH)	169340	Motor Support w/Nuts, Bolts & Washers
169007	Complete Frame Assembly (Orange) (Includes XP-304, XP-305, and AFH)	169345	Nuts, Bolts & Washers (4)
169008	Complete Frame Assembly (Blue) (Includes XP-304, XP-305, and AFH)	169350	Guide Screws (2)
169017	Frame Only	169355	Motor Support Spring
169018	Frame Only (Orange)	136200	V-Belt (45")
169019	Frame Only (Blue)	169400	Belt Guard
169020	Rubber Leg Tip (2)	169405	Air Switch & Motor Switch (Yellow) Assembly
169022	Rubber Foot, Washer & Nut (2)	169403	Air Switch & Motor Switch (Yellow) Assembly for Motor # S48AC63A40P
169025	Drum Shaft Retaining Pin	169407	Air Switch & Motor Switch (Red) Assembly
169030	Retaining Pin Spring	169408	Air Switch & Motor Switch (Red) Assembly for Motor # S48AC62A40P
169035	Retaining Pin Collar w/Set Screw	169410	Box Only w/Cover & Screws
169037	Shaft Spacer w/Set Screw	136170	Foot Pedal & Hose
169040	Handle Knobs w/Washers (2)	169420	Cable Tie
169045	Folding Handle	136060	Foot Pedal Only
169046	Folding Handle (Orange)	136080	Power Switch Diaphragm
169044	Folding Handle (Blue)	136050	Air Hose Only
169047	Rubber Tip (2)	136130	Motor Switch (Yellow)
169050	8" Wheel w/ Retaining Cap	168400	Motor Switch (Yellow) for Motor # S48AC63A40P
169055	Wheel Retaining Cap	136210	Motor Switch (Red)
169060	Wheel Spacer (4)	168403	Motor Switch (Red) for Motor # S48AC62A40P
169065	Post Locking Knob	169450	Switch Guard
169085	Bolt w/ Lock Washer	156395	Strain Relief Nut
136230	Tool Holder w/ Screws and Washers	164550	Motor Guard w/Nylon Strip
169023	Front Post	164555	Nylon Strip
169024	Front Post (Orange)	136010	Ground Fault Circuit Interrupter w/10' Cord
169070	Post Support Bracket	169465	Complete XP Power Cable Feed
169120	Complete Drum Assembly w/Inner Cage (Closed)	169466	Complete XP Power Cable Feed for Rental
169125	Complete Drum Assembly w/Inner Cage (Open)	168904	Power Feed Body
169130	Drum Shell	168905	Spout
169135	Edging	168906	Lifting Spring
169133	Open Drum Shell	168909	Feed Roller Assembly
169143	Drum Shaft	168910	Feed Roller Assembly for Rental
169145	Front Shaft Retaining Ring	168912	Carrier Only
169150	Flat Washer	68913	Carrier Only for Rental
169155	Felt Washer	168915	Swing Pin
169160	Rear Shaft Retaining Ring	168916	Swing Pin for Rental
169165	Rear Hub Assembly w/Bushing	168918	Feed Roller Shaft
169175	Screws & Flanged Locknuts (5)	136150	Set of Feed Rollers (3) Note: ONLY 1 pc comes w/ PO-MR-200 & PO-MR-200-R
169180	Distributor Tube and Inner Drum Assembly	168924	Feed Pressure Knob Assembly
168997	Flexitube Distributor Tube Assembly	168929	Outer Pressure Spring
169250	Fiber Washer (3)	168936	Washer
169260	Front Hub w/Bushing (Orange)	168938	Bottom Roller Assembly Retaining Snap Ring
169263	Front Hub w/Bushing (Silver)	168941	Thrust Washer
169270	Round Head Cap Screws (4)	168944	Feed Control Disc
169280	Distributor Tube Front Collar w/Set Screw	168945	Lever & Knob (For 3 Piece Feed Control Disc)
169240	Inner Drum Cage	168949	Control Disc Retaining Snap Ring
169290	Drum Connecting Cable w/ Screws & Lock Nut	169470	Guide Tube
169300	Connecting Cable Screws & Lock Nut	169080	Guide Tube Holder (Only included with PO-XP-R)
169360	Inner Drum Retaining Bolt	131340	Cutter Bag
169365	Drum Retaining Washer	132355	Instructional DVD
169370	Felt Washer	132210	Set of Safety Decals
169380	High Collar Lock Washer	170990	Condensed Operating Instructions (Instructions w/Chain & Fittings, Connector, & Screw)
169305	Motor 1/3 hp w/GFCI, Air Foot Switch, & Motor Switch	169480	Complete Operating Instructions
169307	Motor 1/3 hp w/GFCI, Air Foot Switch, & Motor Switch	130050	Mini-Rooter Cutter Set
169310	Belt Guard Retaining Knob	121040	(75EM2) Flexicore Cable, 3/8" x 75 ft. w/ Female Conn.
167060	Washer	121070	(50EM3) Flexicore Cable, 1/2" x 50 ft. w/ Female Conn.
169330	V-Belt Pulley		
136180	Safety Slip Clutch		

* "-R" Indicates for rental machine only

MINI-ROOTER XP SCHEMATIC DIAGRAM



IMPORTANT: When ordering, give Serial Number of Machine.