

Ref#	Part #	Description
1	101145	Mounting Bracket, Die Cast, Keyslot Attach
2	132523	Canopy, 130mm, WH, 2 tier, Outdoor, 1
3	127206	Downrod, WH, 4" x 1/2", Die Cast Ball
4	140119	Yoke Cover, WH, Outdoor
5	109097	Blade Bracket, WH, U-Shape,
6	102223	Hardware Pack, Stainless, 5WF52,MC Fob
7	131080	Blade, White ABS,
8	108738	Switch Cap, 100mm, WH,
9	133209	Socket Assembly, WH, 2x13w CFL
10	G973	Glass/Matte Opal
11	160016	Fluorescent, 13w, Edison, Opal, CFL




remote No

Search

General

Print



Note: Not all numbers shown on the graphic are listed.
Parts listed are loose parts included with the fan and switches with the exception of bulbs.

Glass Broken? Missing Parts? Need Help?
Verre brisé? Pièces manquantes? Besoin d'aide?

Call our customer service center, open Monday - Friday from 8:00 a.m. until 5:00 p.m. CST at 1-800-519-4092
Appeler notre centre de service au consommateur, ouvert de lundi
- vendredi de 8:00 a.m. jusqu'à 5:00 p.m. HCN (Heure centrale normale) à 1-800-519-4092



