


FAUCET CONNECTOR

CONECTOR PARA GRIFO

EASY TO INSTALL / FÁCIL DE INSTALAR

No cutting, flaring or bending required.
No requiere cortar, ensanchar o doblar.



INSTALLATION INSTRUCTIONS

1. Turn off water supply at shutoff valve.
2. Remove old supply connector and clean all connector threads.
3. Prior to threading the 3/8" Click Seal nut to shutoff valve, turn nut counter-clockwise until threads align. Turn Click Seal nut clockwise and **HAND-TIGHTEN** until nut clicks. "The click lets you know it's sealed."™
4. Prior to threading the 1/2" black Click Seal nut to the faucet, turn nut counter-clockwise until threads align. Turn Click Seal nut clockwise and **HAND-TIGHTEN** until nut clicks. "The click lets you know it's sealed."™ (continued)

CLICK SEAL®

FAUCET CONNECTOR

CONECTOR
PARA GRIFO

Also available in
12", 16" & 30" lengths

Disponibles también
en largos de
12", 16" y 30"



5 YEAR WARRANTY
5 AÑOS DE GARANTÍA

WARRANTY: This Fluidmaster® product has a limited warranty for a period of 5 years. For complete warranty details, please visit our website at www.fluidmaster.com.

GARANTÍA: Este producto Fluidmaster® tiene garantía limitada por un período de 5 años. Para consultar los detalles completos de la garantía, por favor visite nuestro sitio web www.fluidmaster.com.

(Installation Instructions continued)

5. Slowly turn on water at the shutoff valve.
6. Carefully check for leaks at shutoff valve.

INSTRUCCIONES DE INSTALACIÓN

1. Corte el suministro de agua con la llave de paso.
2. Quite el conector de suministro viejo y limpie todas las rosas de conexión.
3. Antes de enroscar la tuerca de encaje para sellar de 3/8" en la válvula de cierre, gire la tuerca en dirección contraria a las manecillas del reloj hasta que las rosas se alineen. Gire la tuerca de encaje para sellar en dirección de las manecillas del reloj y **APIETE A MANO** hasta que la tuerca haga clic. "The click lets you know it's sealed."™
4. Antes de enroscar la tuerca de encaje para sellar negra de 1/2" en el grifo, gire la tuerca en dirección contraria a las manecillas del reloj hasta que las rosas se alineen. Gire la tuerca de encaje para sellar en dirección de las manecillas del reloj y **APIETE A MANO** hasta que la tuerca haga clic. "The click lets you know it's sealed."™
5. Abra lentamente el suministro de agua con la llave de paso.
6. Revise con cuidado que no haya filtraciones en la válvula de cierre.