

MODEL 375XL and 375

Reduced Pressure Principle – Backflow Preventers 1/2" to 1"

Item	Description	1/2"	3/4"	1"
1	WEDGE SCREW	372-11B	372-11B	373-11B
2	WEDGE	372-23	372-23	373-23
3	O-RING, SLEEVE	118N	118N	216N
4	SLEEVE	372-2	372-2	373-2
5	O-RING, #1 CHECK SEAT	124N	124N	225N
6	#1 CHECK SEAT	372-18A	372-18A	373-18A
7	POPPET SCREW	30-11	30-11	952-11
8	CHECK SEAL RETAINER	372-14A	372-14A	373-14A
9	CHECK SEAL RING	372-12A	372-12A	373-12A
10	POPPET	372-30	372-30	373-30
11	#1 CHECK SPRING	372-33A	372-33A	373-33A
12	#1CHECK SPRING RETAINER	372A-80A	372A-80A	373A-80A
13	O-RING, #2 CHECK SEAT	124N	124N	223N
14	#2 CHECK SEAT	372-18B	372-18B	373-18B
15	#2 CHECK SPRING	372-33B	372-33B	373-33B
16	#2 CHECK SPRING RETAINER	372A-80B	372A-80B	373A-80B
17	O-RING, HOUSING INLET	130N	130N	227N
18	TEST COCK	18-860XL	18-860XL	18-860XL
19	CHECK HOUSING	372-1	372-1	373-1
20	O-RING, HOUSING OUTLET	119N	119N	218N
21	O-RING, RV COVER	010N	010N	010N
22	O-RING, RV SEAT	WK-018N	WK-018N	WK-018N
23	RELIEF VALVE SEAT	372-18	372-18	372-18
24	RELIEF VALVE SPRING	372-33CU	372-33CU	372-33CU
25	RV SEAL RETAINING SCREW	372-11C	372-11C	372-11C
26	RV SEAL RING	372-12	372-12	372-12
27	RV LOWER PLUNGER	372-34A	372-34A	372-34A
28	DIAPHRAGM	372-43	372-43	372-43
29	RV UPPER PLUNGER	372-34	372-34	372-34
30	O-RING, RV STEM	015N	015N	015N
31	RELIEF VALVE COVER	372-3	372-3	373-3
32	RV COVER SCREW, SHORT	372-11B	372-11B	372-11B
	RV COVER SCREW, LONG	372-11	372-11	N/A
33	INLET BALL VALVE, 375XL	RK12-375XLBV1	RK34-375XLBV1	RK1-375XLBV1
33	INLET BALL VALVE, 375	RK12-375BV1	RK34-375BV1	RK1-375BV1
34	OUTLET BALL VALVE, 375XL	371-48BXL	372-48BXL	373-48BXL
34	OUTLET BALL VALVE, 375	371-48B	372-48B	373-48B
35	#1 CHECK ASSEMBLY	372-300A	372-300A	373-300A
36	#2 CHECK ASSEMBLY	372-300B	372-300B	373-300B
37	RELIEF VALVE STEM ASSY	372-50	372-50	372-50
38	COMPLETE VESSEL ASSY	RK34-375V	RK34-375V	RK1-375V
39	HOUSING, BLOW OUT/FLUSH	372-1BOF	372-1BOF	373-1BOF
40	GREEN BALL VALVE HANDLE and NUT	372-6XL	372-6XL	373-6XL
40	BLUE BALL VALVE HANDLE and NUT	372-6	372-6	373-6

Repair Kit

REPAIR KIT, COMPLETE		RK34-375 1/2"-3/4"		RK1-375 1"	
Description	Part Number	Qty.	Part Number	Qty.	
#1 CHECK ASSEMBLY	372-300A	1	373-300A	1	
#2 CHECK ASSEMBLY	372-300B	1	373-300B	1	
RELIEF VALVE STEM ASSY	372-50	1	372-50	1	
O-RING, SLEEVE	118N	1	216N	1	
O-RING, HOUSING INLET	130N	1	227N	1	
O-RING, HOUSING OUTLET	119N	1	218N	1	
O-RING, RV COVER	010N	1	010N	1	
O-RING, RV SEAT	WK-018N	1	WK-018N	1	
RELIEF VALVE SEAT	372-18	1	372-18	1	
RELIEF VALVE SPRING	372-33CU	1	372-33CU	1	
REPAIR KIT, RUBBER ONLY		RK34-375R 1/2"-3/4"		RK1-375R 1"	
Description	Part Number	Qty.	Part Number	Qty.	
O-RING, #1 CHECK SEAT	124N	1	225N	1	
O-RING, #2 CHECK SEAT	124N	1	223N	1	
CHECK SEAL RING	372-12A	2	373-12A	2	
O-RING, SLEEVE	118N	1	216N	1	
O-RING, HOUSING INLET	130N	1	227N	1	
O-RING, HOUSING OUTLET	119N	1	218N	1	
O-RING, RV COVER	010N	1	010N	1	
O-RING, RV SEAT	WK-018N	1	WK-018N	1	
RELIEF VALVE SEAL RING	372-12	1	372-12	1	
DIAPHRAGM	372-43	1	372-43	1	
O-RING, RV STEM	015N	1	015N	1	
REPAIR KIT, VESSEL ASSY		RK34-375V 1/2"-3/4"		RK1-375V 1"	
Description	Part Number	Qty.	Part Number	Qty.	
VESSEL W/CHECKS AND RV	ITEM 38	1	ITEM 38	1	
REPAIR KIT, WEDGE ASSY		RK34-375W 1/2"-3/4"		RK1-375W 1"	
Description	Part Number	Qty.	Part Number	Qty.	
O-RING, SLEEVE	118N	1	216N	1	
SLEEVE	372-2	1	373-2	1	
WEDGE	372-23	1	373-23	1	
WEDGE SCREW	372-11B	2	373-11B	2	
REPAIR KIT, BLOW OUT/FLUSH FITTING		RK34-375BOF 1/2"-3/4"		RK1-375BOF 1"	
Description	Part Number	Qty.	Part Number	Qty.	
HOUSING, BLOW OUT/FLUSH	372-1BOF	1	373-1BOF	1	
O-RING, HOUSING INLET	130N	1	227N	1	
O-RING, HOUSING OUTLET	119N	1	218N	1	
REPAIR KIT, BALL VALVE HANDLES		RK34-375XLBVHD 1/2"-3/4"		RK1-375XLBVHD 1"	
Description	Part Number	Qty.	Part Number	Qty.	
GREEN BALL VL.V. HANDLE & NUT	372-6XL	2	373-6XL	2	
REPAIR KIT, BALL VALVE HANDLES		RK34-375BVHD 1/2"-3/4"		RK1-375BVHD 1"	
Description	Part Number	Qty.	Part Number	Qty.	
BLUE BALL VL.V. HANDLE & NUT	372-6	2	373-6	2	

MODEL 375XL and 375 – 1/2" to 1"

Parts Drawing

