


Installation Instructions


Two Piece Toilet




TOOLS NEEDED



1. Install bolts.




2. Attach wax ring.




3. Place bowl in position.




4. Install washers & nuts.
DO NOT OVERTIGHTEN!




5. Install seal, if not already installed.




6. Align seals, place tank on bowl & install washers and nuts.
DO NOT OVERTIGHTEN!



7. Attach supply line. HAND TIGHTEN ONLY.



8. For maximum volume efficiency, adjust water level using adjustment rod. Attach cable to flush lever arm.



Installation Instructions

Two Piece Toilet



Step 9.

Flapper is secured by a rubber band. Cut it off to release flapper before flushing toilet.

Step 10.

Adjusting the Water Level (Very Important)
For proper flushing of the bowl, the water must fill to the waterline mark indicated on the inside surface of the tank. The float rod and float ball controls the water level. If the water level is below the water line mark, turn the float rod adjusting screw counter-clockwise, if the water is above the waterline mark, turn the screw clockwise. At least 20 psi water pressure is necessary for the proper functioning. If it is less than 20 psi, the water may not be able to fill up to the waterline mark. However, the water pressure should not be more than 80 psi.

Caution

We do not recommend the use of chemical commercial tank/bowl cleaners that are placed in the tank and remain for extended periods of time. These products may damage ballcock and flapper valves and shorten the operating life of these parts. The flapper valve and ballcock valve can be retightened if the water is leaking.

Problem Solving

Problem	Reason	Solution
Fill valve can't fill	1. Fill switch is closed.	1. Turn on fill switch.
	2. Drain guard gets stuck.	2. Clean drain guard (Drawing 3-1).
	3. Float cup is crushed by tank wall.	3. Adjust direction of fill valve.
Leakage	1. Fit incorrectly.	1. Fit again according to the correct installation procedure.
	2. Flush valve seat does not fit flush valve body.	2. Fit again.
	3. Flush valve body gets stuck.	3. Unpick and wash flush valve body.
	4. Incorrect operation.	4. Refill tube should be higher than water level.
Can't flush or flush little	Steel wire is twisted or pulled too much.	Adjust flush valve body.
Half flush water level is too high or too low	Adjust water level incorrectly.	Adjust water level.

Warranty

WHAT IS COVERED?

Ferguson Enterprises, Inc. "Ferguson" or the "Company" warrants its products to be free from defects in material and workmanship under normal use and service FOR A PERIOD OF ONE (1) YEAR FROM THE DATE OF INSTALLATION.

WHAT IS NOT COVERED?

The warranty set forth in paragraph 1 does not cover installation or any other labor charges and does not apply to products which have been damaged as a result of any accident, abuse, improper installation or maintenance, or modification of original plumbing product. The warranty of such products is limited to the warranty extended to Ferguson by the product manufacturer. Finally, FERGUSON SHALL NOT BE RESPONSIBLE OR LIABLE FOR ANY FAILURE OR DAMAGE TO THIS PRODUCT OR ANY COMPONENT THEREOF CAUSED BY THE USE OF ABRASIVE CLEANERS.

HOW TO OBTAIN WARRANTY SERVICE

US Customers:

The purchaser should contact their local Ferguson location, installing contractor or builder from whom the product was purchased. To find you nearest Ferguson location please visit www.ferguson.com and enter in your address into the

Find a Location field.

Canadian Customers:

The purchaser should contact their local Wolseley Canada location, installing contractor or builder from whom the product was purchased. To find you nearest Wolseley Canada location please visit www.wolseleyinc.ca, then click on Find a Location and enter in your address into the location field. PROFLO is a registered trademark of Ferguson Enterprises, Inc.

LIMITATIONS OF IMPLIED WARRANTY AND DISCLAIMER OF CONSEQUENTIAL OR INCIDENTAL DAMAGES FERGUSON DISCLAIMS ANY LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES AND DISCLAIMS ALL EXPRESS OR IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AS SET FORTH ABOVE. IMPLIED WARRANTIES OF THE PRODUCTS AND PRODUCT COMPONENTS SET FORTH IN PARAGRAPH 1 ABOVE ARE LIMITED TO THE DURATIONS OF THE RESPECTIVE WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Parts Breakdown


1.6gpf Closet Tank

PF1400T Low Consumption Series



PF5112WHM

Shown with PF1401TWH elongated bowl



Warranty and Codes

This product comes complete with installation, operating, care and maintenance instructions. All PROFLO fixtures carry a 1- year limited warranty. This product meets ANSI: A112.18.1M.

Distributed Exclusively by Ferguson and Wolsley Canada