
# <u>Instructions for Models</u>:

# CPT-8400-P



#### Need Help?

For additional assistance or service call:

**SPEAKMAN** Company 400 Anchor Mill Road New Castle, DE 19720

PHONE: 800-537-2107

EMAIL: customerservice@speakmancompany.com WEB: www.speakmancompany.com

92-3271-R3

# What You Need To Know:

#### Tools:

#### Required:

\*Phillips Screwdriver



#### Helpful:

\* Tape Measure



### Important Notes:

Be sure to read instructions thoroughly before beginning installation. Do not overtighten any connections or damage may occur.


Be sure to have properly adjusted the Temperature Liminting Stop (TLS) as per the Valve Installation Instructions before installing Valve Trim.


# Safety Tips:


Cover your drain to prevent loss of parts.


#### Maintenance:


Your new valve trim is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with a soft cloth. Avoid abrasive cleaners, steel wool, and harsh chemicals as these will dull the finish and void your warranty.

















RPG05-0874 2 3 4 RPG10-0103 5

RPG04-0392 6

