



INSTALLATION INSTRUCTIONS:

- 1. Be sure wax ring is at least 70°F in temperature to insure proper flow of wax.**
- 2. Place bolts in floor flange, secure with retainer washer.**
- 3. Press wax ring with flange on bowl outlet, extend flange away from the bowl.**
- 4. Set bowl in place and use body weight to compress wax. Twist bowl slightly to spread wax.**
- 5. Place washers and nuts on bolt. Tighten bolts carefully to prevent breaking bowl.**