



## INSTALLATION INSTRUCTIONS:

1. Be sure wax ring is at least 70°F in temperature to insure proper flow of wax.
2. Place bolts in floor flange, place stainless steel washer onto bolts, secure with stainless steel nut.
3. Press wax ring with flange on bowl outlet, extend flange away from the bowl.
4. Set bowl in place and use body weight to compress wax. Twist bowl slightly to spread wax.
5. Place washer and nut on bolt. Tighten bolts carefully to prevent breaking bowl.