## **Installation/Instruction Manual for Architects & Engineers**

## Service

For servicing of the unit it is imperative that 30" of clearance be available in front of the unit access panel. All electrical components are inside an easy access control box to aid in checking the contactor and capacitor electrical connections. The condenser fan motor is easily accessible for inspection of the bearings.

To clean the condenser coil it is recommended to use high pressure nitrogen from the interior with a non-rinse, non-acidic coil cleaner. Keep building exterior material in consideration when choosing cleaning products. If the coil is accessible from the outside, the coil can be brushed clean with care to not damage the aluminum fins.