


KitchenAid®

36" GAS COOKTOP

MODELS:

KCGS356ESS00 (Stainless)


COOKTOP, BURNER AND GRATE PARTS



COOKTOP, BURNER AND GRATE PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	7	W10597166	Holder, Orifice (9.1K)	11	W10652710	Orifice (9.1K)
	W10597144	Installation Instructions			(Left Front & Left Rear)			(Left Front & Left Rear)
	W10672375	Undercounter Install Instructions		W10594405	Holder, Orifice (12K)		W10409144	Orifice (12K)
	W10597142	Use & Care Guide			(Right Front)			(Right Front)
	9762761	Tips, Safe Cooking (English)		W10594399	Holder, Orifice (5K)		W10652711	Orifice (5K)
	W10065852	Tips, Safe Cooking (French)			(Right Rear)			(Right Rear)
2	W10597068	Cooktop		W10639869	Holder, Orifice (19K)		W10409146	Orifice (19K)
3		Kit, Burner Cap			(Center)			(Center, Main)
	W10597132	Black	8	8286814	Head, Burner		W10652706	Orifice (19K)
		Kit, Grate			(Left Front & Left Rear)	12	W10541842	Wiring, Electrode
	W10594450	Black		8286815	Head, Burner			(Left Front & Right Front)
5	8286863	Spring, Electrode			(Right Front)		W10541843	Wiring, Electrode
		Knobs, Cooktop		8286813	Head, Burner			(Left Rear & Right Rear)
6		Knobs, Cooktop			(Right Rear)			
	W10545849	Stainless	9	W10625915	Grommet	13	W10611434	Spreader, Flame
			10	8287059	Screw	14	W10611438	Electrode (Stack)
								(Center)

BURNER BOX, GAS VALVES AND SWITCH PARTS



BURNER BOX, GAS VALVES AND SWITCH PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8287057	Screw, Valve Bracket	7	W10132345	Regulator, Pressure	16	W10566296	Tubing, Gas Burner
2	W10594397	Assembly, Pipe Manifold	8	W10594429	Bracket, Orifice Holder			(Center, Main)
3	W10594392	Valve, Single (Left Front)	9	W10475149	Module, Spark (2+0 Filtered)	17	W10566297	Tubing, Gas Burner
	W10594391	Valve, Single (Left Rear)	10	W10494787	Box, Burner			(Center, Simmer)
	W10594393	Valve, Single (Right Front)	11	W10140571	Seal, Switch Shaft	18	W10594430	Bracket, Orifice Holder
	W10597156	Valve, Single (Right Rear)	12	W10566305	Tubing, Gas Burner (Left Front)			FOLLOWING PARTS NOT ILLUSTRATED
	W10594389	Valve, Dual (Center)	13	W10566306	Tubing, Gas Burner (Left Rear)		W10539913	Harness, Main
4	8287055	Bracket, Single Valve	14	W10566308	Tubing, Gas Burner (Right Front)		W10392003	Cord, Power
5	8287056	Bracket, Dual Valve	15	W10566307	Tubing, Gas Burner (Right Rear)		W10132200	Relief, Strain
6	W10614951	Panel, Front					9760279	Seal, Foam
							313438	Clip, Harness
							W10676661	Kit, LP Conversion
								ACCESSORIES
							W10685483	Griddle