


KitchenAid®

30" GAS FREESTANDING SELF CLEAN CONVECT RANGE

MODELS:

KFGG500EWH0 (White)
KFGG500EBL0 (Black)
KFGG500ESS0 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10694025	Installation Instructions
	W10694017	Use and Care Guide
	W10694023	Tech Sheet
	9762761	Tips, Safe Cooking (English)
	W10065852	Tips, Safe Cooking (French)
	W10400066	Guide, Quick Start (English)
2		Set, Burner Cap
	W10183374	Black
3	W10067840	Screw
4	W10515455	Burner Head, Ultra Rapid (15K) (Left Front & Right Front)
	W10515454	Burner Head, Semi (9.5K) (Left Rear and Center)
	W10515453	Burner Head, Auxi (5K) (Right Rear)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
5		Cooktop
	W10366729	White
	W10366730	Black
	W10294800	Stainless
6		Panel, Manifold
	W10724448	White
	W10724449	Black
	W10729891	Stainless
7		Knob
	W10643306	Stainless
8		Grate, Set
	W10676612	Black
9	3400701	Screw
10	W10530070	Bracket, Rear Gas Cooktop
11	W10432544	Griddle
12	W10306542	Bracket, Anti-Tip
13	7101P485-60	Screw, Anti-Tip Kit
14	W10515459	Electrode
15	8273062	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16		Bezel
	W10437082	Stainless
		FOLLOWING PARTS NOT ILLUSTRATED
	W10580269	Harness, Main
	W10696251	Harness, Bake/Broil
	W10519920	Harness, DSI Ground
	W10519934	Harness, DSI 200C
	3196696	Clip, Harness
	W10334923	Clip, Wire
	313438	Clip, Harness
	3196896	Clip, Wire
	3196520	Clip, Wire

CONTROL PANEL PARTS




CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap
	W10184433	White (Left Hand)
	W10184434	White (Right Hand)
	W10184437	Black (Left Hand)
	W10184438	Black (Right Hand)
2	W10516123	Bracket, Console Mounting

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Console, Panel
	W10645847	White
	W10645846	Black
	W10645848	Stainless
4	W10511278	Module, Spark DSI
5	W10198745	Cover, Upper
6	W10192841	Shield, Heat
7	W10643264	Control, Maxwell

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10762981	Bracket, Mounting
9	W10184251	Cover, Back
10	3196178	Screw
11		Active Overlay Assembly
	W10645815	White
	W10692150	Black
12	W10475149	Module, Spark (5+0)


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314347	Assembly, Flue	16	W10311326	Assembly, Flue (Upper)	32	W10158780	Cover, Fan
2	9758701	Spacer, Door	17	3196560	Screw	33	W10531060	Rack, Oven
3	W10273002	Bracket, Oven Support	18	W10323077	Diffuser, Flame	34	W10289145	Rack, Oven (Gull-Wing)
4		Panel, Side	19	3196178	Screw	35	W10501599	Clip, Front Frame Cover
	W10575396	White	20	W10273005	Back, Main	36	W10137382	Clip, Panel
	W10162245	Black	21	W10162385	Gasket, Door			INSULATION
5	W10346153	Baffle, Full Convection	22	W10031780	Screw		W10526208	Insulation, Wrap Gas
6	W10627802	Switch, Door	23	W10273195	Shield, Heat		W10526209	Insulation, Main Back
7	8273036	Box, Burner	24	W10273192	Rod, Door Switch		4820F015-59	Insulation, Strap
8	W10341186	Assembly, Front Foot	25	W10624590	Cord, Power			
9	W10289077	Receiver, Hinge	26	W10035900	Support, Oven Bottom			
10	W10058460	Foot, Leveling	27	W10273204	Pan, Bake			
11	W10211368	Bottom, Oven	28	W10454648	Assembly, Light			
12	W10586204	Sensor	29	311255	Bulb, Oven Light			
13	3601P356-45	Baffle, Bake Burner	30	W10390007	Assembly, Base Rail (Right)			
14	W10362924	Screw		W10390008	Assembly, Base Rail (Left)			
15	W10435470	Brace, Main Back	31	W10389553	Motor, Fan (Convection)			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	7	W10677605	Mainifold Assembly	17	W10178934	Orifice (12K) (Right Front)
2	W10732137	Assembly, Orifice holder (15K) (Right Front)	8	W10566062	Valve, Gas (Left Front & Right Front)		W10732136	Orifice (5K) (Right Rear)
	W10732139	Assembly, Orifice Holder (5K) (Right Rear)		W10566057	Valve, Gas (Left Rear and Center)		W10170507	Orifice (8K) (Left Rear)
	W10732140	Assembly, Orifice Holder (9.5K) (Left Rear)		W10566055	Valve, Gas (Right Rear)		W10170510	Orifice (15.5 K) (Left Front)
	W10473934	Assembly, Orifice Holder (15.5 K) (Left Front)	9	W10224921	Bracket, Aegis		W10251991	Orifice (7K) (Center)
	W10732141	Assembly, Orifice Holder (8K) (Center)	10	W10439242	Burner, Broiler	18	W10362924	Screw
3	W10295996	Bracket, Saddle Valve	11	W10680035	Burner, Bake	19	3196385	Screw
4	W10510125	Tubing, Main Supply	12	W10720102	Valve, Gas	20	3400016	Screw
5	W10755370	Harness, Switch Spark	13	W10324262	Igniter, Bake			Following Parts Not Illustrated
6	3601P336-45	Baffle, Broil Burner	14	W10306050	Tubing (Broiler Fitting To Valve)		W10170516	LP Conversion Kit
			15	W10732135	Fitting, Broil		W10400497	Orifice, LP Broil
			16	W10333842	Electrode, Broil		W10400494	Orifice, LP Bake

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door Skin
	W10692526	Stainless
2	W10317886	Screw
3		Handle, Door
	W10551000	Stainless
4	W10297318	Liner, Door
5	W10300487	Glass, Inner
6	W10333990	Bracket, Full
7	3196165	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8		Badge
	W10518672	Grey
9	W10294853	Bracket, Glass Liner
10	W10440013	Hinge, Door (Active)
11		Trim, Door
	W10334003	White
	W10334004	Black
12	W10294851	Rail, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Glass, Outer Door
	W10495962	White
	W10665481	Black

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Panel, Drawer Front
	W10330041	White
	W10330042	Black
	W10330044	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	3400882	Screw
3	W10688022	Drawer, Storage

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10441804	Slide, Drawer (Left)
	W10441805	Slide, Drawer (Right)
5	W10318026	Bracket, Mounting

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	4392901	Biscuit/Bisque
	285006	Black
	350956	Almond
	350938	Gray Primer
	206922	Primer (White)

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	241430	Aluminum Foil
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	W10355051	Cleaner, Cooktop
	W10423113RP	Kit, Oven Cleaning
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	W10432019	Alt Cleaning Kit
	W10205524	Split Oven Rack
	W10289145	Rack, Oven (Gull-Wing)
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting