SPECIFICATIONS

| | HR06MN | HR10MN | HR10TN |
|---------------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|
| Btu(available) | 6,000 | 5,500/10,000 | 10,000 |
| Gas Type | Natural Only | Natural Only | Natural Only |
| Ignition | Piezo | Piezo | Piezo |
| Pressure Regulator setting | 6" W.C. | 6" W.C. | 6" W.C. |
| Inlet Gas Pressure* (inches of water) | | | |
| Maximum | 10.5" | 10.5" | 10.5" |
| Minimum | 7" | 7" | 7" |
| Dimensions, Inches (HxWxD) | | · | · |
| Heater | 19 × 14-1/4 × 7 | 19 × 14-1/4 × 7 | 19 × 14-1/4 × 7 |
| Carton | 22 x 16-3/4 x 8-1/8 | 22 x 16-3/4 x 8-1/8 | 22 × 16-3/4 × 8-1/8 |
| Weight (pounds) | | | *** |
| Heater | 12 | 13 | 13 |
| Shipping | 15 | 16 | 16 |

Note: Dimensions listed are outer most points on the heater (includes control knobs and grill). * For purposes of input adjustment.

REPLACEMENT PARTS

Note: Use only original replacement parts. This will protect your warranty coverage for parts replaced under warranty.

PARTS UNDER WARRANTY

Contact authorized dealer from whom you purchased this product. If they are unable to supply original replacement part(s), call the number on the front of this manual. When contacting your dealer or HearthRite, have ready:

- your name
- your address
- model and serial numbers of your heater
- how heater was malfunctioning
- type of gas used (propane/LP or natural gas)
- purchase date
- warranty card

Usually, we will ask you to return the defective part to the factory.

PARTS NOT UNDER WARRANTY


Contact authorized dealers of this product. If they can't supply original replacement part(s), contact HearthRite at (800)851-3153.

TECHNICAL SERVICE

You may have further questions about installation, operation, or troubleshooting. If so, contact HearthRite at (800)851-3153.

ACCESSORIES

Purchase these heater accessories from your local dealer. If they can not supply these accessories, contact HearthRite for information. You can also write to the address listed on the front of this manual.



FLOOR MOUNTING STAND

For locating heater on the floor away from a wall. Complete installation instructions provided with floor mounting stand.

HearthRite

A Division of Empire Comfort Systems, Inc. 918 Freeburg Avenue Belleville, IL 62220

Phone: 618-233-7420 or 1-800-851-3153 Fax: 618-233-7097 or 1-800-443-8648 www.hearthrite.com