




## **27" BUILT-IN ELECTRIC DOUBLE OVEN WITH CONVECTION**

### **MODELS:**

KODE507EBL02 (Black)  
KODE507EWH02 (White)  
KODE507ESS02 (Stainless)  
KODE507EBS02 (Black Stainless)

# CONTROL PANEL PARTS




# CONTROL PANEL PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>                         |
|-----------------------------|-----------------|--------------------------------------------|
| 1                           |                 | Literature Parts                           |
|                             | W10643471       | Guide, Use & Care                          |
|                             | W10725670       | Instructions, Installation                 |
|                             | W10888961       | Instructions, Installation                 |
|                             |                 | (Black Stainless Models Only)              |
|                             | W10861943       | Sheet, Tech                                |
| 2                           |                 | Assembly, Control Panel (Includes Overlay) |
|                             | W10890579       | Black                                      |
|                             | W10890573       | White                                      |
|                             | W10890575       | Stainless                                  |
|                             | W10890561       | Black Stainless                            |
| 3                           | W10777215       | Control (With Power Supply)                |
|                             | W10777216       | Control (Without Power Supply)             |
| 4                           | W10618105       | Spacer, Lateral                            |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
| 5                           | W10669823       | Blower                  |
| 6                           | W10671226       | Gasket, Rubber          |
| 7                           | W10436435       | Fuse, Thermal           |
| 8                           | 7101P426-60     | Screw                   |
| 9                           | 7101P434-60     | Screw                   |
| 10                          | W10655463       | Bracket, Blower (Left)  |
|                             | W10655462       | Bracket, Blower (Right) |
| 11                          | 4451758         | Block, Foam             |
| 12                          |                 | Skin, Control Panel     |
|                             | W10588745       | Black                   |
|                             | W10588747       | White                   |
|                             | W10588741       | Stainless               |
|                             | W10861075       | Black Stainless         |
| 13                          | W10694467       | Tray, Electronic        |
| 14                          | W10655465       | Chassis, Back Divider   |
| 15                          | W10351295       | Bumper                  |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------------|
| 16                          | W10318193       | Chassis, Cover Top Front 27"    |
| 17                          | W10694466       | Chassis, Cover Top Back 27"     |
| 18                          | W10728475       | Gasket, Rubber                  |
|                             |                 | FOLLOWING PARTS NOT ILLUSTRATED |
|                             | W10836625       | Harness, Main                   |
|                             | W10603944       | Harness, Signal                 |
|                             | W10775068       | Harness, Door Latch             |
|                             | W10562910       | Harness, EOL                    |
|                             | W10766377       | Harness, TOD Jumper             |
|                             | 4450800         | Screw, Grounding                |
|                             | 313438          | Clip, Harness                   |
|                             | 4452400         | Strap, Lead Ground              |
|                             | 4448664         | Clamp, Conduit                  |
|                             | W10655464       | Bracket, Harness                |

# OVEN PARTS




# OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            |
|-----------------------------|-----------------|-------------------------------|
| 1                           | W10318196       | Duct, Chassis Back<br>(Upper) |
| 2                           | W10282946       | Tube, Vent                    |
| 3                           | W10616802       | Receiver, Hinge               |
| 4                           | W10618102       | Spacer, Base                  |
| 5                           | W10618131       | Latch, Motorized              |
| 6                           | W10764078       | Element, Broil                |
| 7                           | W10519866       | Assembly, Oven Light          |
| 8                           | W10618101       | Foot, Base                    |
| 9                           | W10641572       | Deflector, Blower             |
| 10                          | W10254050       | Screw                         |
| 11                          | W10282961       | Gasket                        |
| 12                          | W10616810       | Cover, Vent Exhaust           |
| 13                          | W10318190       | Side, Chassis                 |
| 14                          | W10813734       | Back, Chassis                 |
| 15                          |                 | Liner, Oven (Not Serviceable) |
| 16                          | W10622170       | Probe, Sensor                 |
| 17                          | W10351278       | Bumper & Screw                |
| 18                          | 4449751         | Thermostat (TOD)              |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>          |
|-----------------------------|-----------------|-----------------------------|
| 19                          | W10282901       | Base, Chassis               |
| 20                          |                 | Assembly, Bottom Vent       |
|                             | W10327375       | Black                       |
|                             | W10506349       | White                       |
|                             | W10351280       | Stainless                   |
|                             | W10869573       | Black Stainless             |
| 21                          | W10283008       | Chassis, Bottom Duct        |
| 22                          |                 | Trim, Bottom Vent           |
|                             | W10351237       | Black                       |
|                             | W10504025       | White                       |
|                             | W10327378       | Stainless                   |
| 23                          | W10213759       | Support, Air Channel        |
| 24                          | W10351308       | Spacer, Chassis Bottom Duct |
| 25                          | W10618103       | Foot, Front (Left)          |
|                             | W10618104       | Foot, Front (Right)         |
| 26                          | 8285593         | Cover, Connector            |
| 27                          | 7101P426-60     | Screw                       |
| 28                          | W10472386       | Lens, Light                 |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------------|
| 29                          | W10327369       | Cover, Side Trim (Left)         |
|                             | W10327368       | Cover, Side Trim (Right)        |
| 30                          | W10347649       | Spacers, Front                  |
| 31                          | W10472384       | Bulb, Light                     |
| 32                          | W10542857       | Duct, Chassis Back<br>(Lower)   |
| 33                          | W10616809       | Base, Vent Exhaust              |
| 34                          | W10588736       | Bracket, U-Shape                |
| 35                          | W10283041       | Vent, Center 27"                |
| 36                          | W10283037       | Vent, Top 27"                   |
| 37                          | W10607120       | Screw                           |
| 38                          | W10863234       | Bracket, Side Cover (Left)      |
|                             | W10863233       | Bracket, Side Cover (Right)     |
|                             |                 | Following Parts Not Illustrated |
|                             | W10520716       | Insulation, Wrap                |
|                             | W10282945       | Insulation, Back                |


# UPPER OVEN DOOR PARTS



# UPPER OVEN DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>    | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>           |
|-----------------------------|-----------------|-----------------------|-----------------------------|-----------------|--------------------|-----------------------------|-----------------|------------------------------|
| 1                           | W10347597       | Assembly, Window Pack | 7                           |                 | Assembly, Door     | 10                          | W10284297       | Bracket, Glass               |
| 2                           | W10284285       | Spring, Door Glass    |                             | W10615246       | Black              | 11                          | W10480830       | Screw                        |
| 3                           | 3196183         | Screw                 |                             | W10615247       | White              | 12                          | 7101P426-60     | Screw                        |
| 4                           | W10653954       | Clip, Spring Metal    |                             | W10615245       | Stainless          | 13                          | 7101P635-60     | Screw (Black)                |
| 5                           | W10320793       | Assembly, Liner       | 8                           | W10878437       | Black Stainless    | 14                          | W10687815       | Extension, Side Rail (Left)  |
| 6                           | W10639067       | Hinge, Door           |                             |                 | Assembly, Handle   |                             | W10687814       | Extension, Side Rail (Right) |
|                             |                 |                       | 9                           | W10640874       | Stainless          | 15                          | W10669415       | Shield, Door Liner           |
|                             |                 |                       |                             | W10678525       | Glass, Inner       |                             |                 |                              |

# LOWER OVEN DOOR PARTS






# LOWER OVEN DOOR PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>             |
|-----------------------------|-----------------|--------------------------------|
| 1                           | W10347597       | Assembly, Window Pack          |
| 2                           | W10284285       | Spring, Door Glass<br>Fixation |
| 3                           | 3196183         | Screw                          |
| 4                           |                 | Badge                          |
|                             | W10518672       | Grey                           |
| 5                           | W10320793       | Assembly, Liner                |
| 6                           | W10639067       | Hinge, Door                    |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
| 7                           |                 | Assembly, Door     |
|                             | W10615246       | Black              |
|                             | W10615247       | White              |
|                             | W10615245       | Stainless          |
|                             | W10878437       | Black Stainless    |
| 8                           |                 | Assembly, Handle   |
|                             | W10640874       | Stainless          |
| 9                           | W10678525       | Glass, Inner       |
| 10                          | W10284297       | Bracket, Glass     |

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------------|
| 11                          | W10480830       | Screw                           |
| 12                          | 7101P426-60     | Screw                           |
| 13                          | 7101P635-60     | Screw (Black)                   |
| 14                          | W10653954       | Clip, Spring Metal              |
| 15                          | W10687815       | Extension, Side Rail<br>(Left)  |
|                             | W10687814       | Extension, Side Rail<br>(Right) |
| 16                          | W10669415       | Shield, Door Liner              |

# INTERNAL OVEN PARTS



# INTERNAL OVEN PARTS

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>            | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>               | <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|-------------------------------|-----------------------------|-----------------|----------------------------------|-----------------------------|-----------------|--------------------|
| 1                           | W10764078       | Element, Broil                | 9                           | W10631504       | Nut, Acorn                       | 15                          | W10696226       | Jack, Meat Probe   |
| 2                           | W10554529       | Rack, Oven                    | 10                          | W10631503       | Blade, Fan                       | 16                          | 9755547         | Washer, Lock       |
| 3                           | W10318198       | Tray, Hidden Bake             | 11                          | W10546519       | Element, Convection              | 17                          | 9755546         | Nut, Hidden        |
| 4                           | 7101P434-60     | Screw                         | 12                          | W10359277       | Baffle, Bow Tie                  | 18                          | W10554532       | Rack, Sliding      |
| 5                           | 7101P426-60     | Screw                         |                             | W10725944       | Baffle, Bow Tie                  | 19                          | 9755542         | Probe, Temperature |
| 6                           | W10282957       | Crossbar, Hidden Bake<br>Tray |                             |                 | (Black Stainless Models<br>Only) | 20                          | 7101P500-60     | Screw              |
| 7                           | W10546517       | Element, Bake                 | 13                          | W10318164       | Shield, Broil Element            |                             |                 |                    |
| 8                           | W10722667       | Fan, Convection               | 14                          | W10588738       | Shield, Broil Front              |                             |                 |                    |

# OPTIONAL PARTS

## PAINT, TOUCH-UP (1/2OZ.)

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>      |
|-----------------------------|-----------------|-------------------------|
|                             | 72017           | White                   |
|                             | 72032           | Black                   |
|                             | 4392899         | Biscuit/Bisque          |
|                             | 511873          | White Porcelain (2 oz.) |

## PAINT, SPRAY

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 350930          | White              |
|                             | 285006          | Black              |
|                             | 4392901         | Biscuit/Bisque     |
|                             | 350956          | Almond             |
|                             | 350942          | White Primer       |
|                             | 350938          | Gray Primer        |

## ADHESIVE

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u> |
|-----------------------------|-----------------|--------------------|
|                             | 482338          | Sealer, Silastic   |

## ACCESSORIES

| <u>Illus.</u><br><u>No.</u> | <u>Part No.</u> | <u>Description</u>              |
|-----------------------------|-----------------|---------------------------------|
|                             | 4396923         | Broiler Pan and Grid            |
|                             | W10123240       | Rack, Broiler Pan & Roasting    |
|                             | W10355016       | Cleaner, Stainless Steel        |
|                             | W10355010       | Cleaner, Kitchen & Appliance    |
|                             | W10355049       | Wipes, Stainless Steel Cleaning |
|                             | W10275756       | Cleaner, Granite                |