


**KitchenAid®**

**30" BUILT-IN MICROWAVE**




**MODELS:**

KMBP100ESS01 (Stainless)

# OVEN PARTS



Literature Parts




# OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10725730	Instructions, Installation
	W10643473	Guide, Use & Care (Microwave Oven)
	W10756613	Sheet, Tech
2	W10239155	Box, Conduit
3	W10420960	Support, Microwave Module
4	W10416256	Rail, Side (Left)
	W10416255	Rail, Side (Right)
5	W10420958	Stainless

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10239156	Bracket, Lower (Left)
	W10239157	Bracket, Lower (Right)
7	3400832	Screw (Black)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	7101P653-60	Screw
		FOLLOWING PARTS NOT ILLUSTRATED
	W10371813	Harness, Convection
	W10389372	Harness, Fan & Turntable
	W10406103	Harness, Inverter
	W10524303	Harness, Communication
	4450800	Screw, Grounding
	W10392129	Strap, Ground
	W10209041	Conduit


# CONTROL PANEL PARTS



# CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Control Panel	2	W10610028	Interface, User	4		Skin, Control Panel
	W10588761	Stainless	3	3400832	Screw (Black)		W10588740	Stainless


# MICROWAVE DOOR PARTS



# MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8304588BL	Cap, Screw	6		Assembly, Outer Door	7		Assembly, Door Handle
2	7101P338-60	Screw		W10615372	Stainless		W10541913	Stainless
3	W10687342	Assembly, Inner Door						
4		Badge						
	W10518672	Grey						
5	W10359769	Foam, Handle						

# CABINET AND STIRRER PARTS






# CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10577815	Manager, Appliance	13	4375231	Block, Fuse	28	461968979601	Hinge, Door
2	423107845441	Sensor, Convection	14	461967846741	Thermostat, Magnetron	29	461969000371	Motor, Convection Fan
3	461967848711	Heater, Convection Element	15	461967847321	Magnetron	30	461968969271	Assembly, Cooling Fan
4	461967001792	Fan, Convection	16	W10465869	Spring, Lamp	31	W10468206	Inverter
5	W10120233	Nut, Speed	17	W10490593	Holder, Lamp	32	W10130890	Screw
6	W10692851	Filter, Noise	18	241954900069	Lamp, Halogen	33	W10120235	Rod, Release
7	W10358241	Assembly, Interlock Switch	19	461968973241	Vent, Top Microwave	34	241960100002	Sensor, Temperature
8	461967017491	Trim, Side (Left)	20	W10330566	Switch	35	W10128850	Assembly, Sliding Arm
	W10367739	Trim, Side (Right)	21	8205683	Holder, Switch	36	8205704	Spring, Torsion
9	461967825321	Screw	22	423107022541	Reflector	37	461967750494	Support
10	461967848621	Transformer, Light (20V)	23	423107720491	Lens, Lamp	38	461967750483	Arm, Sliding
11	461967842541	Thermoactuator	24	461967010591	Clip, Spring	39	W10460457	Sensor, Humidity
12	241908600053	Fuse	25	W10260060	Board, Power Supply	40	461967754821	Duct, Magnetron
			26	W10283016	Grommet, Front Frame	41	423107570871	Spring, Release Rod
			27	461967008461	Support, Bottom			

# INTERNAL MICROWAVE PARTS



# INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461968977491	Plate, Crisp
2	461965699731	Steamer
3	W10748279	Rack, Convection
4	W10608467	Plate, Baking
5	461967848971	Motor, Turntable

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	461967721091	Turntable
7	W10367316	Ring, Turntable
8	W10545578	Drive, Turntable
9	461968929542	Handle, Pan
10	W10387651	Element, Grill

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	461967451001	Plate, Cover
12	461967753871	Support, Element
13	461967753742	Adapter, Turntable Motor

# OPTIONAL PARTS

## PAIN, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	261869	Cord Brown
	72032	Black

## PAIN, SPRAY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	261900	Citrine White
	830864	Black

## FOLLOWING PARTS NOT ILLUSTRATED

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic