




UNDERCOUNTER DISHWASHER

MODELS:

KDTE204EPA0 (Panel Ready)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	3	W10321448	Barrier, Vapor	11		Fastener
	W10741197	Installation Instructions	4	W10518815	Insulation, Four Layer		W10503548	Black
	W10746816	Energy Guide	5		Access Panel	12	304392	Screw
	W10751710	Use & Care Guide		W10526114	Black	13	W10641745	Bracket, Control
	W10750905	Tech Sheet, English	6		Panel Front			
	W10750906	Tech Sheet, French		W10292632	Panel Ready			
	W10195005	Template, 6" Custom Panel	7	W10234565	Insulation, Front Panel			
2		Arm, Hinge	8	3400071	Screw			
	8534854	Left Hand	9	W10195008	Hardware, Custom Panel			
	8534853	Right Hand	10	W10366978	Seal, Panel Ready			

CONTROL PANEL AND LATCH PARTS




CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)
	W10742455	Panel Ready
2	W10195237	Clip, Control
3	W10756253	Box, Connector

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10348409	Screw
5	W10653840	Latch Assembly (Includes Switch)
6	W10790702	Control, Electronic
7	W10194937	Brace, Connector

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10355484	Shield, Control
9	W10528492	Jumper, 4 Wire

INNER DOOR PARTS




INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	8281217	Screw
3	W10480715	Inner Door
4	W10497235	Seal, Door Bottom

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10748115	Wiring Harness
6	W10524919	Knob, Rinse Aid
7	W10177098	Screw
8	W10409521	Dispenser Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	W10767097	Bracket, Dispenser
10	W10195007	Seal, Console/Door


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	8	3390631	Screw	14	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
2	8531412	Hose	9	W10195039	Switch, Overfill Control	15	370445	Clamp, Hose
3	W10195536	Inlet, Water (Also Order Item 4)	10	W10647205	Housing, Overfill (Also Order Item 11)	16	W10545278	Drain Loop with Check Valve Assembly
4	8531323	Gasket	11	8531743	Gasket, Flat			
5	W10213825	Nut, Water Inlet (Also Order Item 4)	12	W10195038	Nut, Standpipe			
6	371505	Clamp, Hose	13	W10195036	Float & Retainer Assembly			
7	W10327250	Fill Valve Assembly						


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681491	Tub Assembly (Also Includes Heater Assembly)	11	8269145	Bracket, Undercounter	21	W10158291	Cable, Door
2	W10713315	Assembly, Terminal Box	12	3400074	Screw	22	W10292870	Shield, Thermostat
3	W10300924	Gasket, Tub	13	W10681564	Support Assembly, Rear	23		Spacer, Tub/Brace
4	W10082838	Plug, Tub	14	W10348411	Screw		W10195630	Left Hand
5	W10544004	Strike, Latch	15	W10190778	Wheel Leg		W10195631	Right Hand
6	304392	Screw	16	W10619352	Leveler, Leg	24	8573240	Shield, Tub Sound
7	W10179427	Seal, Cabinet	17	3378128	Washer, Pronged Cup	25	W10300703	Bracket, Thermostat
8	W10337661	Strain Relief	18	8270182	Spring, Door Balance	26	W10195091	Thermostat
9	W10084086	Door Balance Assembly	19	3400014	Screw, Grounding			
10	3367670	Screw	20	W10653292	Cover, Terminal Box			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10529163	Motor (Also Order Items 9 & 11)	9	W10789434	Clamp, Hose	20	W10169167	Clamp, Hose
2	W10195086	Motor, Isolator	10	W10605058	Sump & Motor Assembly	21	W10300776	Damper, Sump Assembly
3	W10455272	Cover, Outlet	11	W10538166	Grommet			
4	W10455268	Sump With Seal (Also Order Items 9 & 11)	12	W10348407	Screw			
5	9741232	Screw	13	W10372113	Tab, Sump			
6	W10463906	Screen	14	W10348269	Pump, Drain			
7	W10406822	Wash Arm Assembly	15	8269144	Hose, Drain			
8	W10693534	Filter Cup Assembly	16	W10476221	Disc, Diverter			
			17	W10476222	Motor, Diverter			
			18	8269146	Clamp, Hose			
			19	W10705575	Indicator, Optical Wash			

UPPER WASH AND RINSE PARTS




UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Items 2 & 3)
2	W10327455	Sprayarm, Third Level

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	3400918	Retainer
4	W10340542	Manifold
5	W10448645	Sprayarm

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10195690	Bracket, Feed Tube
7	W10769518	Manifold, Turbo Zone

HEATER PARTS




HEATER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10696509	Heater Element Assembly (Includes Heater Washer & Nut)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10446558	Washer, Heater

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10687139	Nut, Heater Element
NOTE: If heater element is removed, it must be replaced.		


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10312792	Dishrack, Upper	6	W10195840	Positioner, Adjuster	11	W10473794	Handle, Dishrack Front
2		Housing, Adjuster (Includes Spring and Lever)	7	W10082649	Cupshelf Assembly	12	W10473792	Handle, Dishrack Rear
	W10588164	Left Hand	8	W10267076	Clip, Dispenser Guard	13	8539101	Clip, No Flip
	W10588165	Right Hand	9	W10250162	Cover, Adjuster	14	W10309090	Screw
3	W10250160	Clip, Adjuster	10		Track, Assembly	15	9741232	Screw
4	W10546503	Adjuster Assembly		W10752595	Left Hand	16	W10082848	Clip, Cupshelf
5	W10195839	Strap, Tether Adjuster		W10752596	Right Hand			



LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10525646	Dishrack, Lower	3	W10473836	Basket Assembly, Silverware	5	W10078215	Retainer, Tine Row Combo
2	W10195417	Wheel & Transport Assembly	4	W10056272	Tine Row, Fold Down	6	W10473835	Lid, Silverware Basket

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Track Assembly
	W10653357	Left Hand
	W10653356	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10309090	Screw
3	W10653326	Rack Assembly (Third Level)

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES			PAINT, TOUCH-UP (1/2OZ.)			POWER CORD KIT		
<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TOWEL BAR HANDLE		72017	White		4317824	Power Cord Kit
W10701399	Stainless			72032	Black			(Included Cord & Misc. Hardware)
		DISHRACK ACCESSORIES		4392899	Biscuit/Bisque			
W10712311	Anti-Tarnish Silverware			4396603	Meteorite			
		Basket	PAINT, PRESSURIZED SPRAY (12 OZ.)			ANTI-TIP KIT		
W10712312	Cutlery Dishwasher					<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
W10712313	Basket							
		Bottle/Vase Holder					8171477	Floor Mount Kit
		DRAIN HOSE	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>		8212560	Side Mount Kit
W10712310	12 Ft.							
		VINYL TOUCH-UP (4oz)		350930	White			
676453	White			285006	Black			
676455	Grey			4392901	Biscuit/Bisque			
4396853	Silver Atlantis		PAINT, BULK (1 QT.)			DISHRACK REPAIR		
		MOISTURE BARRIER KIT				<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4396277	Barrier Kit						4396838	White
							4396840	Grey
							4396854	Silver Atlantis
				799344	White			
				4392900	Biscuit/Bisque			