

KitchenAid®

FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:


KRFC302EWH00 (White)

KRFC302EBL00 (Black)

KRFC302ESS00 (Stainless Steel)

KRFC302EBS00 (Black Stainless)

CABINET PARTS




CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10543539	Tech Sheet
	W10742059	Owners Manual
	W10739667	Energy Guide
2	12820505	Insulation
3	W10120087	Block, Pivot
4	B5759655	Gasket
5	W10141622	Brake, Roller
6		Cabinet (Not a Servicable Part)
7		Plug, Button
	A3076901	Black
8	12990504	Screw
9	12992603	Screw
10		Hinge, Top
	W10210891	Right Hand
11	W10339086	Screw
12		Cover, Right Hinge
	W10163247	White
	W10153131	Black
	W10120103	Grey

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13		Cover, Left Hinge
	W10163248	White
	W10153130	Black
	W10120102	Grey
14	12992403	Screw
15		Hinge, Center
		Right Hand
	W10162695	White
	W10210883	Black
	W10135097	Grey
16	W10658542	Block, Fill Tube
17		Cover, Corner
	12587703W	White
	12587703B	Black
	12587703AP	Grey
18		Hinge, Top
	W10210890	Left Hand
19		Roller Assembly (Front)
	W10515763	Left Hand
	W10515762	Right Hand
20	12991302	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
21		Shim, Hinge
	12999501	Left Hand
	12999502	Right Hand
22		Grille, Toe
	W10534154	White
	W10534153	Black
	W10534155	Grey
23	M0104106	Clip, Cord
24		Hinge, Center
		Left Hand
	W10162694	White
	W10210882	Black
	W10135096	Grey
25	12990511	Screw
26	12726003	Cover, Water Line
27	W10208593	Guard, Dual Water Valve
28	12990302	Screw
29	W10528513	Sweep, Dual Tube
30	W10211855	Cover, Unit
31	M0108107	Clamp, Tube


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	12	12990604	Screw	23	W10204292	Facade, Dispenser
2	W10464766	Module, Light	13	12806701	Cover, Damper	24	W10204289	Switch, Plunger
3	W10742010	Overlay	14	13012402	Insulation, Damper	25	12575502	Switch, Limit
4	W10464767	Module, Control	15	W10594329	Control, Damper	26	W10117324	Waterline, Dispenser
5	W10631452	Board, Control	16	W10116529	Cover, Waterline	27	12706109	Tank, Water
6	12466104	Switch, Rocker	17	61006182	Union, Water			Following Parts Not Illustrated
7	12806501	Cover, Light	18	W10609243	Head, Water Filter	W10391289		Harness, Control (Refrigerator)
8	W10443023	Housing, Light	19	W10735404	Filter, Water			
9	W10745744	Lamp, LED	20	12960301N	Cover, Filter			
10	12570701V	Socket, Light	21	12990504	Screw			
11	12806801	Insert, Damper Cover	22	12664501SP	Cartridge, Bypass			


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10157765	Diverter, Air	26	W10128551	Motor, Evaporator
2	A3189392	Gasket, Foam	15	13058002	Clip, Evaporator Motor	27	W10662407	Assembly, Drain Funnel
3	12002497	Gear	16	12466105	Switch, Light	28	M0500703	Seal
4	12476401V	Housing, Freezer Light	17	12990504	Screw	29	B8381501	Gasket, Drain
5	12812903WD	Shaft, Rack	18		Cradle, Basket	30	12815301	Cover, Thermistor
6	12570701V	Socket, Light		W10119848	Left Hand	31	12990501	Screw
7	W10201550	Guide, Fill Tube		W10119849	Right Hand	32	12791419SP	Thermistor
8	12990521	Screw	19	13055901N	Slide, Drawer			Following Parts Not Illustrated
9	W10745744	Lamp, LED	20	A3189396	Gasket	W10196195		Harness, Lights (Freezer)
10	W10119832	Module, Freezer Light	21		Adapter, Slide			
11	W10308420	Cover, Evaporator		W10544403	Left Hand			
12	12990511	Screw		W10544404	Right Hand			
13		Bracket, Door	22	13024803	Grille, Freezer Air			
	W10330994	Left Hand	23	13057901	Shroud, Evaporator Fan			
	W10330995	Right Hand	24	2169142	Blade, Fan			
			25	W10121318	Grommet			

REFRIGERATOR DOOR PARTS




REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	13094744W	White
	13094744B	Black
	13094747S	Stainless
	13094754BLS...	Black Stainless
2	W10460893	Screw
3		Stop, Door
	W10163249	White
	W10153126	Black
	W10120097	Grey
4	12990204	Screw
5	W10119841	Bucket, Medium
6	W10450018	Gripper, Medium
	W10450019	Gripper, Gallon

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10119846	Bucket, Gallon
8		Gasket, Door
	W10443243	White
	W10435971	Black
	W10443241	Grey
9		Handle, Door
	W10775000	Stainless
10		Mullion, Door
	W10163292	White
	W10153146	Black
	W10153704	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11		Closure, Door
	12028505W	White
	12028505B	Black
	12028505AP	Grey
12	12990504	Screw
13		Door, Right
	13094738W	White
	13094738B	Black
	13094739S	Stainless
	13094753BLS...	Black Stainless

FREEZER DOOR PARTS




FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	13094918W	White
	13094918B	Black
	13094918S	Stainless
	13094918BS	Black Stainless
2		Handle, Door
	W10774995	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Gasket, Door
	W10443319	White
	W10436252	Black
	W10443320	Grey
4	W10460893	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Badge
	W10518672	Grey

UNIT PARTS




UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw
2	12825803	Blade, Fan
3	W10480111	Basepan
4	12990511	Screw
5	W10350564	Capacitor
6	W10233569	Tube, Discharge
7	W10292241	Harness, Evaporator Heater
8	W10655368	Pan, Drain
9	W10622701	Screw
10	12729123	Heater, Defrost
11	W10216075	Strap, Bale
12	W10330834	Device, Start
13	W10137529	Grommet, Condenser
14	12961602	Cover, Control Box
15	12477102	Roller
16	12992101	Screw
17	10835903	Grommet
18	W10346415	Condenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10281329	Clip, Drier
20	W10292803	Tray, Drip
21	12990701	Screw
22	W10317014	Evaporator
23		Dam
	12225602	Left Hand
	12225702	Right Hand
24	W10609117	Motor, Condenser Fan
25	10428101	Clip, Heater
26	W10679221	Harness, Wire
27	W10177049	Drier
28	W10445422	Compressor
29	10623002	Clip, Evaporator
30	12477202	Axle, Roller
31	W10189184	Shroud, Condenser Fan
32	W10622099	Extension, Drain Tube
33	W10296541	Lid, HV Control Box
34	12957801	Gasket, Control Box

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
35	W10120827	Control, Electronic
36	W10236396	Strap, Compressor
37	W10120821	Control, Power Supply Electronic Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE 5.00 oz. (R-134A)

SHELF PARTS




SHELF PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12204815	Glass, Pantry
2	12655204	Knob, Temperature Control
3	12656822	Lid, Pantry Drawer
4	W10119222	Knob, Humidity Control
5	12227305WH	Brace, Pantry
6	2204542	Roller, Basket
7	W10119854	Basket, Middle
8	W10144706	Assembly, Bin
9	12656901	Gasket, Pantry
10	12656202	Housing, Control
11	W10739613	Assembly, Shelf
12	12655402	Slide, Temperature Control
13	2207415	Nut, Hex
14		Glide, Drawer
	W10132653	Left Hand
	W10132652	Right Hand
15	12990504	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16		Endcap, Pantry
	W10122078	Left Hand
	W10121977	Right Hand
17	W10119219	Pan, Crisper
18	W10490807	Brace, Crisper Frame
19	W10170836	Glide, Upper Basket
20	W10119215	Frame, Crisper
21	12204827	Glass, Crisper Cover
22	W10273463	Ladder, Center
23	W10569182	Ladder, Side
24	12990513	Screw
25	12990515	Screw
26	W10120003	Basket, Upper Freezer
27	W10119217	Slide, Humidity Control
28	12655303	Bar, Temperature Control
29	12655703	Drawer, Pantry
30	W10182881	Scoop, Ice Pan
31	W10120005	Pan, Ice

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
32	W10120008	Carrier, Ice Pan
33	W10184030	Lever, Ice Pan
34	W10131252	Magnet, Latch
35	W10174720	Front, Ice Pan
36	W10170835	Glide, Ice Pan
37	W10120014	Support, Freezer Door
38	W10451455	Mat, Upper Basket
39	W10119220	Front, Crisper
40		Adapter, Basket
	W10163084	Left Hand
	W10163087	Right Hand
41	W10121002	Latch, Coupler
42	W10121004	Housing, Coupler
43	W10739612	Assembly, Shelf
44		Slide, Crisper
	2302952	Left Hand
	2302953	Right Hand
45	W10528935	Trim, Pantry Glass
46	W10742811	Rack, Wine

ICEMAKER PARTS



ICEMAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10420084	Bracket, Icemaker Mounting
2	B5705333	Tubing, Plastic
3	10526702	Clamp, Wire
4	W10120005	Pan, Ice
5	W10420083	Valve, Water Inlet
6	W10512602	Arm, Shut Off
7	W10377174	Cover, Front
8	A3223101	Insert, Tube
9	W10300025	Assembly, Mold and Heater

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10410073	Cup, Water Fill
11	W10318914	Ejector
12	W10699925	Stripper, Ice
13	628379	Clip, Thermal Fuse
14	10463203	Elbow, Fill Tube
15	627985	Thermostat
16	8533917	Screw
17	489464	Screw
18	W10458985	Harness, Ice Maker

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	M0114003	Clip, Speed
20	W10281342	Assembly, Module And Motor
21		Motor (Not Available, Order #20)
22	W10001240	Screw
100	W10683115	Assembly, Icemaker (Complete)

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key