


KitchenAid®

20 CUBIC FOOT FRENCH DOOR BOTTOM MOUNT REFRIGERATOR

MODELS:

KRFC300EWH01 (White)
KRFC300EBL01 (Black)

CABINET PARTS




CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10635370	Use and Care Guide
	W10739663	Energy Guide
		Tech Sheet
	W10787424	English
	W10787423	French
2	M0114003	Clip, Speed
3	12698403	Plate, Pivot
4	B5759655	Gasket
5		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
6	W10528513	Sweep, Dual Tube
7		Plug, Button
	A3076901	Black
8	W10257665	Box, HV Control
9	12992602	Screw
10		Cover, Hinge
		Right Hand
	12962302W	White
	12962302B	Black
11	W10339086	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
12		Hinge, Top
	12963205EDN.	Right Hand
13		Cover, Hinge
		Left Hand
	W10337634	White
	W10337647	Black
14	12992403	Screw
15		Hinge, Center
		Right Hand
	13000002WD	White
	13000008ED	Black
16	W10658542	Block, Fill Tube
17		Cover, Corner
	12587703W	White
	12587703B	Black
18		Hinge, Top
	12963204EDN.	Left Hand
19		Cabinet (Not A Serviceable Part)
20	12991302	Screw
21		Shim, Hinge
	12999501	Left Hand
	12999502	Right Hand

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
22		Assembly, Grille (Includes Clips)
	W10534154	White
	W10534153	Black
23	W10317076	Board, HV Control
24		Hinge, Center
		Left Hand
	13000001WD	White
	13000007ED	Black
25	12990511	Screw
26	12726003	Cover, Water Line
27	W10208593	Guard, Dual Water Valve
28	12990302	Screw
29	12957801	Gasket, Control Box
30	W10211855	Cover, Unit
31	10463203	Elbow, Fill Tube
32	12820505	Insulation
33	W10141622	Brake, Roller
34	12957702SP	Lid, HV Box


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	13012402	Insulation, Damper	26	12664501SP	Cartridge, Bypass
2	W10464764	Module, Light	15	W10594329	Control, Damper	27	B8390302	Clip, Facade
3	W10746278	Overlay	16	12707005	Facade, Dispenser (Top)	28	12990513	Screw
4	W10464767	Module, Control	17	61006182	Union, Water	29	W10163893	Insulation, Tank
5	W10746274	Board, Control	18	12707206	Guide, Waterline	30	12575501	Switch, Limit
6	C3680310V	Switch, Light	19	12706112	Tank, Water	31	W10585699	Plate, Dispenser
7	12806501	Cover, Light	20	W10585703	Facade, Dispenser	32	12251001	Clip, Water Tube
8	W10443023	Housing, Light	21	12990512	Screw			Following Parts Not Illustrated
9	W10745744	Lamp, LED	22	12704801	Plate, Filter	W10224292		Harness, Controls (Refrigerator)
10	12570701V	Socket, Light	23	W10605367	Head, Water Filter			
11	12806801	Insert, Damper Cover	24	12568001	Cover, Filter			
12	12990604	Screw	25	W10735404	Filter, Water			
13	12806701	Cover, Damper						


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	13		Bracket, Door	22	13024803	Grille, Freezer Air
2	A3189392	Gasket, Foam		W10330994	Left Hand	23	13057901	Shroud, Evaporator Fan
3	12002497	Gear		W10330995	Right Hand	24	2169142	Blade, Fan
4		Rack, Side	14	W10277025	Module, Light	25	W10150583	Grommet, Fan Motor
	W10516605	Left Hand	15	13058002	Clip, Evaporator Motor	26	13062901	Motor, Evaporator
	W10516604	Right Hand	16	12466105	Switch, Light	27	W10662407	Assembly, Drain Funnel
5	12812903WD	Shaft, Rack	17	12791419SP	Thermistor	28	M0500703	Seal
6	12570701	Socket, Light	18		Cradle, Basket	29	B8381501	Gasket, Drain
7	W10157765	Diverter, Air		W10281115	Left Hand	30	12815301	Cover, Thermistor
8	12990521	Screw		W10281116	Right Hand	31	12990501	Screw
9	W10745744	Lamp, LED	19	13055901	Slide, Drawer	32	12932103	Guide, Fill Tube
10	W10277466	Foil, Housing	20	A3189396	Gasket			
11	W10308416	Cover, Evaporator	21		Adapter, Slide			
12	12990511	Screw		W10284692	Left Hand			
				W10284693	Right Hand			

REFRIGERATOR DOOR PARTS




REFRIGERATOR DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left
	13107888W	White
	13107888B	Black
2	12804701SP	Door, Dairy
3	12744905	Assembly, Dairy
4	12369502SP	Tray, Dairy
5	W10371194	Bucket, Medium
6	12990204	Screw
7	W10460893	Screw
8		Gasket, Door
	W10443221	White
	W10435968	Black

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9		Handle, Door
	W10775000	Stainless
10	W10450021	Gripper, Medium
	W10449760	Gripper, Gallon
11	W10289497	Bucket, Gallon
12		Mullion, Door
	12722803W	White
	12722803B	Black
13		Closure, Door
	12028505W	White
	12028505B	Black

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14		Stop, Door
	12968202W	White
	12968202B	Black
15	12990504	Screw
16		Door, Right
	13107887W	White
	13107887B	Black

FREEZER DOOR PARTS




FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer
	12977879W	White
	12977878B	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2		Handle, Door
	W10772582	Stainless
3		Nameplate
	W10765861	Grey

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Gasket, Door
	W10443319	White
	W10436252	Black
5	W10460893	Screw

UNIT PARTS




UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw
2	12825803	Blade, Fan
3	W10480111	Basepan
4	12990511	Screw
5	W10350564	Capacitor
6	W10233569	Tube, Discharge
7	W10292239	Harness, Evaporator Heater
8	W10655368	Pan, Drain
9	W10622701	Screw
10	12729123	Heater, Defrost
11	W10216075	Strap, Bale
12	W10330834	Device, Start
13	W10137529	Grommet, Condenser
14	2319835	Grommet, Condenser
15	12477102	Roller
16	12992101	Screw
17	10835903SP	Grommet, Compressor

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10346415	Condenser
19	W10281329	Clip, Drier
20	W10292803	Tray, Drip
21	12990701	Screw
22	W10317014	Evaporator
23		Dam
	12225602	Left Hand
	12225702	Right Hand
24	W10609117	Motor, Condenser Fan
25	10428101	Clip, Heater
26	W10679208	Harness, Unit (Includes Power Cord)
27	W10177049	Drier
28	W10445423	Compressor
29	10623002	Clip, Evaporator
30	12477202	Axle, Roller
31	W10189184	Shroud, Condenser Fan
32	W10236396	Strap, Compressor

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
33	W10622099	Extension, Drain Tube
		Following Parts Not Illustrated
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		5.00 oz. (R-134A)

SHELF PARTS




SHELF PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12204829	Glass, Pantry
2	12802602SP	Front, Crisper Pan
3	W10742811	Rack, Wine
4	W10528935	Trim, Pantry Glass
5	12227305WH	Brace, Pantry
6	12531901	Track, Deli Drawer
7	12727304	Tray, Lower Basket
8	W10241046	Divider, Basket (Upper)
9	12656901	Gasket, Pantry
10	12656202	Housing, Control
11	W10739612	Assembly, Shelf
12	12655402	Slide, Temperature Control
13	W10596756	Assembly, Produce Preserver
14	W10235370	Glide, Pantry
15	12990504	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16		Track, Pantry
	12656105	Left Hand
	12656018	Right Hand
17	12531105SP	Pan, Crisper
18	12227304WD	Brace, Crisper Cover
19	W10231485N	Trim, Crisper
20	12531202SP	Frame, Crisper
21	12204821	Glass, Crisper
22	W10273463	Ladder, Center
23	W10569182	Ladder, Side
24	12990513	Screw
25	W10215666	Screw
26	12990512	Screw
27	12530805SP	Slide, Humidity Control
28	12655303	Bar, Temperature Control
29	12655702	Drawer, Pantry
30	12655204	Knob, Temperature Control

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
31	12656813	Lid, Pantry
32	W10503185	Basket, Lower
33	W10150061	Divider, Basket (Lower)
34	W10348245	Basket, Freezer (Upper)
35	12709301	Divider, Pantry
36		Gear
	W10474716	Left Hand
	W10474715	Right Hand
37		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
38		Assembly, Shelf
39	W10149389N	Lift, Bail Arm
40	12812904WD	Shaft, Rack

ICE MAKER PARTS



ICE MAKER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10300025	Assembly, Mold and Heater	10	W10171529N	Pan, Ice	19	W10281342	Assembly, Module And Motor
2	W10512602	Arm, Shut Off	11	8533917	Screw	100	W10469286	Assembly, Icemaker (Complete)
3	W10410073	Cup, Water Fill	12	W10420083	Valve, Water Inlet			FOLLOWING PARTS NOT ILLUSTRATED
4	W10318914	Ejector	13	A3223101	Insert, Tube		8003RP	Kit, Water Inlet
5	W10699925	Stripper, Ice	14	B5705333	Tubing, Plastic			
6	628379	Clip, Thermal Fuse	15	W10458985	Harness, Ice Maker			
7	W10001240	Screw	16	2256086	Bracket, Ice Maker			
8	627985	Thermostat	17	12991604	Screw			
9	W10068250	Screw	18	W10377174	Cover, Front			

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key