


KitchenAid®

19 CUBIC FOOT BOTTOM MOUNT REFRIGERATOR

MODELS:

KRBL109ESS00 (Stainless Steel) (Left Hand)
KRBR109ESS00 (Stainless Steel) (Right Hand)

CABINET PARTS




CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10645692	Use and Care Guide
	W10740382	Energy Guide
	W10517966	Tech Sheet
2		Cabinet (Not a Serviceable Part)
3	12477501	Cover, Fill Tube
4	B5759655	Gasket
5		Assembly, Roller
	W10515763	Left Hand
	W10515762	Right Hand
6	W10141622	Brake, Roller
7	10351006	Pin, Center Hinge
8	12990511	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	12992602	Screw
10		Cover, Right Hinge
	12477601AP	Grey
11	W10673840	Screw (Stainless)
12	12990521	Screw
13	12249902	Label, Fill Tube
14	12992403	Screw
15		Hinge, Center
	12607103AP	Grey
16	12566606ED	Hinge, Top
17		Cover, Corner
	12587703AP	Grey
18	12820505	Insulation
19	W10217701	Cover, Water Valve

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
20	W10709365	Screw
21	W10210978	Cover, Unit
22		Assembly, Grille (Includes Clips)
	W10534165	Grey


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	14	W10277025	Module, Light	25	W10121318	Grommet
2	A3189397	Gasket, Foam	15	13058002	Clip, Evaporator Motor	26	W10128551	Motor, Evaporator
3	12002497	Gear	16	12466105	Switch, Light	27	W10662407	Assembly, Drain Funnel
4	12990501	Screw	17	12990504	Screw	28	M0500703	Seal
5	12812902WD	Shaft, Rack	18		Cradle, Basket	29	B8381501	Gasket, Drain
6	12570701	Socket, Light		W10280608	Left Hand	30		Rack, Side
7	12791409SP	Thermistor		W10280613	Right Hand		W10516603	Left Hand
8	12990521	Screw	19	W10120018	Slide, Door		W10516602	Right Hand
9	W10820003	Lamp, Led	20	A3189394	Gasket, Bottom	31	12815301	Cover, Thermistor
10	W10277466	Foil, Housing	21		Adapter, Slide	32	12932103	Guide, Fill Tube
11	W10308414	Cover, Evaporator		W10284684	Left Hand			
12	12990511	Screw		W10284685	Right Hand			
13		Bracket, Door	22	13024803	Grille, Freezer Air			
	W10330991	Left Hand	23	13057901	Shroud, Evaporator Fan			
	W10330993	Right Hand	24	2169142	Blade, Fan			

FREEZER DOOR PARTS




FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	13109223S	Door, Freezer Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10774991	Handle, Door Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10443312	Gasket, Door Grey
4	W10460893	Screw

REFRIGERATOR LINER PARTS




REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)
2	W10464757	Module, Light
3	W10593588	Overlay
4	W10464769	Module, Control
5	W10503278	Control, Electronic
6	C3680310V	Switch, Light

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	12806501	Cover, Light
8	W10443023	Housing, Light
9	W10820003	Lamp, Led
10	12570701V	Socket, Light
11	12806801	Insert, Damper Cover
12	12990604	Screw
13	12806701	Cover, Damper

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14	13012402	Insulation, Damper
15	W10594330	Damper, Control
		Following Parts Not Illustrated
	W10422363	Harness, Refrigerator Control (Includes Thermistor)

REFRIGERATOR DOOR PARTS




REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator
	13107541S	Stainless KRBL109ESS00
	13107539S	Stainless KRBR109ESS00
2	W10460893	Screw
3	12804701SP	Door, Dairy
4	12369502SP	Tray, Dairy
5	W10371194	Bucket, Medium

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	12990504	Screw
7		Stop, Door
	10447114	Grey
8		Gasket, Door
	W10443310	Grey
9		Handle, Door
	W10774991	Stainless
10	W10450021	Gripper, Medium

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11		Closure, Door
	12028505AP	Grey
12		Nameplate
	W10518672	Grey
13	12557904	Retainer, Door
14	W10351081	Bucket, Small
15	W10450001	Gripper, Small


UNIT PARTS



UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	12992301	Screw	16	12992101	Screw	30	12477202	Axle, Roller
2	12825803	Blade, Fan	17	10835903	Grommet	31	W10189184	Shroud, Condenser Fan
3	W10480107	Basepan	18	W10346423	Condenser	32	W10622098	Extension, Drain
4	12990511	Screw	19	W10281329	Clip, Drier	33	2319835	Grommet, Condenser
5	W10350564	Capacitor	20	W10292801	Tray, Drip			
6	W10294014	Tube, Discharge	21	12990701	Screw			Following Parts Not Illustrated
7	W10292244	Harness, Evaporator (Includes Heater)	22	W10317012	Evaporator		978025	Valve, Access
8	W10655367	Pan, Drain	23		Dam		978026	Valve, Access
9	W10622701	Screw		12225602	Left Hand		978027	Valve, Access
10	12729127	Heater, Evaporator		12225702	Right Hand		978028	Valve, Access
11	W10216075	Strap, Bale	24	W10609117	Motor, Condenser Fan		978029	Valve, Access
12	W10796752	Device, Start	25	10428101	Clip, Heater		978030	Valve, Access
13	W10137529	Grommet, Condenser	26	W10679216	Harness, Unit (Includes Power Cord)		876764	Valve, Access
14	W10236396	Strap, Compressor	27	W10177049	Drier			REFRIGERANT CHARGE
15	12477102	Roller	28	W10445422	Compressor			4.25 oz (R-134A)
			29	10623002	Clip, Evaporator			

SHELF PARTS



SHELF PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10671238	Rail, Center Crisper
2	W10231481	Trim, Crisper
3	12530805SP	Slide, Humidity Control
4	W10348236	Basket, Freezer (Upper)
5	W10503182	Basket, Freezer (Lower)
6	W10596756	Assembly, Produce Preserver
7	W10215666	Screw
8	W10146440	Divider, Basket (Lower)
9	12643602	Front, Crisper
10	W10241046	Divider, Basket (Upper)
11	12990513	Screw
12	12463608	Shelf, Stationary

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	12531305	Pan, Crisper
14	12227302WD	Brace, Crisper Cover
15	W10671240	Frame, Crisper
16	12204823N	Glass, Crisper Cover
17	W10273463	Ladder, Center
18	W10251970	Ladder, Side
19	W10328331	Drawer, Pantry
20	W10656984	Trim, Pantry Front
21		Support, Pantry
	12531001	Left Hand
	12531002	Right Hand
22	12531802	Hook, Ladder
23	12531901	Track, Deli Drawer

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
24	W10802329	Shaft, Rack
25		Mount, Gear
	W10348259	Left Hand
	W10348260	Right Hand
26		Gear
	W10474716	Left Hand
	W10474715	Right Hand
27	W10335942	Rack, Hanging Wire

OPTIONAL PARTS (NOT INCLUDED)

ICE MAKER FIELD INSTALLABLE

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10261234	IC13B

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392901	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350942	White Primer
	350930	White
	350939	Enamel, Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)
	799344	White (Uncut)
	4392900	Biscuit/Bisque

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	2217192	Cleaner, Stainless Steel