




30" BUILT-IN COMBO MICROWAVE WALL OVEN

MODELS:

KOCE500EBL04 (Black)
KOCE500EWH04 (White)
KOCE500ESS04 (Stainless)
KOCE500EBS04 (Black Stainless)


CONTROL PANEL PARTS



CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	W10655467	Chassis, Combo Side	16	W10681157	Cover, Combo Blower
	W10725683	Instructions, Installation	7	W10283031	Chassis, Cover Top			FOLLOWING PARTS
	W10643472	Guide, Use & Care (Oven)	8	7101P426-60	Screw			NOT ILLUSTRATED
	W10643473	Guide, Use & Care (Microwave Oven)	9	7101P434-60	Screw		W10789996	Harness, Main
	W10756611	Tech Sheet (English)	10	W10655463	Bracket, Blower (Left)		W10789995	Harness, Signal
	W10756612	Tech Sheet (French)		W10655462	Bracket, Blower (Right)		W10775068	Harness, Door Latch
2		Assembly, Control Panel (Includes Overlay)	11	4451758	Block, Foam		W10603949	Harness, Communication
	W10588754	Black	12		Skin, Control Panel		W10406103	Harness, Inverter
	W10588757	White		W10588744	Black		4450800	Screw, Grounding
	W10588755	Stainless		W10588746	White		313438	Clip, Harness
	W10697968	Black Stainless		W10588740	Stainless		W10392129	Strap, Ground
3	W10777215	Control (With Power Supply)		W10776407	Black Stainless		4448664	Clamp, Conduit
4	W10618105	Spacer, Lateral	13	W10519703	Cover, Back Duct		W10017410	Fuse, Time Delay
5	W10669823	Blower	14	W10618126	Chassis, Back Divider		4454949	Holder, Fuse
			15	W10318158	Chassis, Cover Top Front 30"			


CABINET AND STIRRER PARTS



CABINET AND STIRRER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10577815	Manager, Appliance	15	461967847321	Magnetron	32	46196782538	Screw
2	423107845441	Sensor, Convection	16	W10465869	Spring, Lamp	33	W10120235	Rod, Release
3	461967848711	Heater, Convection Element	17	W10490593	Holder, Lamp	34	241960100002	Sensor, Temperature
4	461967001792	Fan, Convection	18	W10795595	Lamp, Halogen	35	461967510191	Bushing
5	W10120233	Nut, Speed	19	W10371813	Harness, Convection	36	461967570351	Spring, Torsion
6	W10692851	Filter, Noise	20	W10330566	Switch	37	461967750494	Support
7	461967754821	Duct, Magnetron	21	8205683	Holder, Switch	38	461967750483	Arm, Sliding
8	461967017491	Trim, Side (Left)	22	423107022541	Reflector	39	423107570871	Spring, Release Rod
	W10367739	Trim, Side (Right)	23	423107720491	Lens, Lamp			Miscellaneous Parts
9	461967825321	Screw	24	461967010591	Clip, Spring		W10389372	Harness, Fan & Turntable
10	461967848621	Transformer, Light (20V)	25	461968973241	Vent, Top Microwave			
11	461967842541	Thermoactuator	26	W10460457	Sensor, Humidity			
12	241908600053	Fuse	27	461967008461	Support, Bottom			
13	4375231	Block, Fuse	28	461968979601	Hinge, Door			
14	461967846741	Thermostat, Magnetron	29	461969000371	Motor, Convection Fan			
			30	461968969271	Assembly, Cooling Fan			
			31	W10468206	Inverter			


MICROWAVE DOOR PARTS



MICROWAVE DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Door	2	W10359769	Foam, Handle	5	8304588BL	Cap, Screw
	W10615374	Black	3	W10687342	Assembly, Inner Door	6	7101P338-60	Screw
	W10615375	White	4		Assembly, Handle			
	W10615372	Stainless		W10541913	Stainless			
	W10697974	Black Stainless						

INTERNAL MICROWAVE PARTS




INTERNAL MICROWAVE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	461968977491	Plate, Crisp
2	461965699731	Steamer
3	W10748279	Rack, Convection
4	W10608467	Plate, Baking
5	461967848971	Motor, Turntable

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	461967721091	Turntable
7	W10367316	Ring, Turntable
8	W10545578	Drive, Turntable
9	461968929542	Handle, Pan
10	W10387651	Element, Grill

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	461967451001	Plate, Cover
12	461967753871	Support, Element
13	461967753742	Adapter, Turntable Motor
14	252262898008	Support, Spring Lock Grill

OVEN PARTS




OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10519707	Cover, Back Duct
2	W10282946	Tube, Vent
3	W10616802	Receiver, Hinge
4	W10618102	Spacer, Base
5	W10314880	Latch, Motorized
6	W10813743	Top, Chassis
7	W10519866	Assembly, Oven Light
8	W10283020	Support, Base (Left)
9	W10641572	Deflector, Blower
10	W10495154	Vent, Center 30"
11	W10282960	Gasket
12	W10616810	Cover, Vent Exhaust
13	W10318190	Side, Chassis
14	W10813703	Back, Chassis
15		Liner, Oven (Not Serviceable)
16	7430P043-60	Probe, Sensor
17	W10655466	Chassis, Combo Side (Left)
	W10283029	Chassis, Combo Side (Right)
18	4449751	Thermostat (TOD)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
19	W10834867	Base, Chassis
20		Assembly, Bottom Vent
	W10327373	Black
	W10506348	White
	W10351279	Stainless
	W10723091	Black Stainless
21	W10283008	Chassis, Bottom Duct
22	W10283021	Support, Base (Right)
23	W10213759	Support, Air Channel
24	W10351308	Spacer, Chassis Bottom Duct
25	W10351278	Bumper & Screw
26	W10472386	Lens, Light
27	7101P426-60	Screw
28	W10681156	Deflector, Chassis
29	W10254050	Screw
30	W10618106	Spacers, Front
31	9755542	Probe, Temperature
32	8285593	Cover, Connector
33	W10616809	Base, Vent Exhaust

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
34	W10472384	Bulb, Light
35		Trim, Side
	W10344483	Black (Left)
	W10344482	Black (Right)
36	W10283022	Support, Crossbar
37	W10283024	Side, Bracket
38	W10360517	Rail, Side (Left)
	W10710302	Rail, Side (Left)
		(For Black Stainless Models)
39	W10360519	Rail, Side (Right)
	W10710309	Rail, Side (Right)
		(For Black Stainless Models)
40	W10696226	Jack, Meat Probe
41	9755547	Washer, Lock
42	9755546	Nut, Hidden
		Following Parts Not Illustrated
	W10520715	Insulation, Wrap
	W10282944	Insulation, Cavity


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10347596	Assembly, Window Pack	7		Assembly, Door	11	W10656499	Screw
2	W10284285	Spring, Door Glass		W10615239	Black	12	7101P426-60	Screw
3	3196183	Screw		W10615240	White	13	7101P633-60	Screw (Black)
4		Badge		W10615236	Stainless	14	W10653954	Clip, Spring Metal
	W10518672	Grey	8	W10697969	Black Stainless	15	W10687815	Extension, Side Rail (Left)
5	W10709147	Assembly, Liner		W10541913	Stainless		W10687814	Extension, Side Rail (Right)
6	W10639069	Hinge, Door	9	W10678524	Glass, Inner	16	W10669415	Shield, Door Liner
			10	W10284297	Bracket, Glass			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10764078	Element, Broil	9	W10722667	Fan, Convection	15	W10588738	Shield, Broil Front
2	W10554526	Rack, Oven	10	W10631504	Nut, Acorn	16	W10720084	Screw
3	W10318198	Tray, Hidden Bake	11	W10631503	Blade, Fan			
4	7101P376-60	Screw	12	W10546519	Element, Convection			
5	7101P426-60	Screw	13	W10359277	Baffle, Bow Tie			
6	W10282957	Crossbar, Hidden Bake Tray		W10725944	Baffle, Bow Tie (For Black Stainless Models)			
7	W10546517	Element, Bake	14	W10554531	Rack, Sliding			
8	W10318164	Shield, Broil Element						

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black

PAINT, SPRAY

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	482338	Sealer, Silastic

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	W10355016	Cleaner, Stainless Steel
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting