

American Standard

Parts for the following:

Pièces pour la suivante :

Repuestos para lo siguiente:

• For Single Control
Faucets

Pour Robinets Monopieces
Para Grifos Monomando

• Ceramic Cartridge

Cartouche en Céramique
Cartucho de Cerámica

• Provides Both Volume
& Temperature Control

Fournit le Volume et le Contrôle de
Température Proveen Control de
Volumen y Temperatura

Colony®/Colony® Soft

Bathroom: 2175, 6210, 6211 Series
Kitchen: 4175 Series

Cadet®

Bathroom: 8114, 8115 Series

Fairbury™

Kitchen: 4005 Series

Arch™ Pull-Out

Kitchen: 4101 Series

Lakeland®

Kitchen: 4114 Series

Culinaire®

Kitchen: 4137 Series

Quince®

Kitchen: 4433 Series

Symphony™

Kitchen: 4505 Series

Paradiso™

Kitchen: 2913 Series

Jocelyn®

9316 Series

Olvera®

9092 Series

Portsmouth®

4285 series

Rochelle®

9175 Series

Made in/Fabrique a/Hecho en: MEXICO

A951470-0070AP

INSTRUCTIONS:

1. Shut off water supply and open handle.
2. Remove handle assembly and cap.
3. Remove cartridge assembly by removing securing screws.
4. Reassemble with new cartridge.

INSTRUCTIONS :

1. Coupez l'alimentation en eau et ouvrez la poignée.
2. Enlevez l'ensemble poignée et le capuchon.
3. Sortez la assemblage de cartouche en enlevez les vis de fixation.
4. Remontez avec la nouvelle cartouche.

INSTRUCCIONES:

1. Cierre el suministro de agua y gire el mando a la posición abierta.
2. Desaloje el conjunto del mando y casquete.
3. Quite el ensamble del cartucho quitando los tornillos de fijación.
4. Vuelva a armar el grifo con el cartucho nuevo.

