



AUBREY WALL MOUNT LIGHTING FIXTURES ASSEMBLY/INSTALLATION INSTRUCTIONS

NOTE: Fixtures are suitable for up or down mounting.

1. Before beginning the installation, carefully unpack and identify all parts referring to Figure 1. Be sure the supply power is OFF.
2. Using 2 JUNCTION BOX SCREWS, securely fasten the CROSSBAR to the JUNCTION BOX.
3. **MAKE ELECTRICAL CONNECTIONS:** (We recommend 2 people for the remainder of installation) Connect the SUPPLY GROUND WIRE to the FIXTURE GROUND WIRE with a wire connector and then secure it to the CROSSBAR with GREEN GROUND SCREW. Using wire connectors, connect the SUPPLY WHITE WIRE to the FIXTURE WHITE (or RIBBED) LEAD(S); Connect the SUPPLY BLACK (or RED) WIRE to the FIXTURE BLACK (or SMOOTH) LEAD. Wrap all connections with approved electrical tape.
4. Place the WALL PLATE over the CROSSBAR; making sure the FIXTURE SCREWS are through the holes on the WALL PLATE. Secure the FIXTURE SCREWS with (2) LOCKING NUTS.
5. Place the GLASS SHADE over the SOCKET. Thread SOCKET RING onto end of the SOCKET. Hand-tighten until snug.
6. Install LIGHT BULB (sold separately), referring to fixture labels for bulb type and maximum wattage. The bulb quantities depend on the style (See Figure 2).
7. Restore supply power (ON). Retain this sheet for future reference.

**IF IN DOUBT ABOUT ELECTRICAL INSTALLATION,
CONSULT A LICENSED ELECTRICIAN.**

Customer Service: 1-800-558-8700

FIGURE 1




FIGURE 2

