

## Elkay Outdoor Fountain Pedestal Non-Filtered Non-Refrigerated Sanitary Freeze Resistant **Model LK4410SFRK**

## PRODUCT SPECIFICATIONS

Elkay Outdoor Fountain Pedestal Non-Filtered, Non-Refrigerated Sanitary Freeze Resistant. Features shall include E-Coat, Heavy Duty Vandal-Resistant, Sanitary Freeze Resistant. Furnished with Vandal-Resistant bubbler. Front Bubbler Button activation. Product shall be Floor Mount/Freestanding, for Outdoor applications, serving 1 station(s). Unit shall be lead-free design which is certified to NSF/ANSI 61 & 372 (lead free) and meets Federal and State low-lead requirements.

Special Features:	E-Coat, Heavy Duty Vandal-
	Resistant, Sanitary Freeze Resistant
Finish:	Beige (BGE), Black (BLK),
	Blue (BLU), Brown (BRN),
	Evergreen (EVG), Gray (GRY),
	Orange (ORN), Purple (PUR),
	Red (RED), Terracotta (TER),
	White (WHT), Yellow (YLW)
Power:	No Electrical Required
Bubbler Style:	Vandal-Resistant
Activation by:	Front Bubbler Button
Mounting Type:	Floor Mount/Freestanding
Chilling Option:	Non-Refrigerated
Full Load Amps	0
Dimensions (L x W x H):	14" x 31" x 36-11/16"
Approx. Shipping Weight:	178 lbs.
Installation Location:	Outdoor
No. of Stations Served:	1

- Heavy Duty Vandal-Resistant:
  - Tamper resistant screws
  - Resists stains and corrosion
  - Heavy-gauge construction
- Vandal-resistant, bubblers are one-piece, chrome plated with integral hood guard design to prevent contamination from other users, airborne deposits and tampering.
- Unique E-Coat immersion process coats the inside and outside of the fountain for ultimate corrosion protection.
- Sanitary Freeze Resistant Valve System: Fully sealed freeze resistant system that minimizes chance of ground water contamination, and prevents drain water from mixing with fresh water. Designed for ground installation below the frost line.



#### AMERICAN PRIDE. A LIFETIME TRADITION.

Like your family, the Elkay family has values and traditions that endure. For almost a century, Elkay has been a family-owned and operated company, providing thousands of jobs that support our families and communities.



Included with Product: Outdoor Fountain,

Sanitary Freeze Resistant Valve

Assembly

#### PRODUCT COMPLIANCE

ADA

Buy American Act NSF/ANSI 61 & 372 (lead free)





#### Installation Instructions (PDF)

Warranty pertains to drinking water applications only. Nondrinking water applications are not covered under warranty.

Warranty (PDF)

## **OPTIONAL ACCESSORIES**

LK4471LHB - Locking Hose Bib
97890C - Accessory - Direct Bury Adaptor
LK4470NLHB - Hose Bib

PART:	QTY:
PROJECT:	
CONTACT:	
NOTES:	
APPROVAL:	

In keeping with our policy of continuing product improvement, Elkay reserves the right to change product specifications without notice. Please visit elkay.com for the most current version of Elkay product specification sheets. This specification describes an Elkay product with design, quality, and functional benefits to the user. When making a comparison of other producers' offerings, be certain these features are not overlooked.

# Elkay Outdoor Fountain Pedestal Non-Filtered Non-Refrigerated Sanitary Freeze Resistant

Model LK4410SFRK

MOUNTING INSTRUCTIONS and PLUMBING INSTRUCTIONS


Site and drainage excavation is required for fountain installation. Refer to owner's manual for site preparation details. Provide solid, well-drained surface to mount pedestal fountain (concrete pad recommended) with adequate support (300 lb. load minimum). (6) 3/8" minimum fasteners (not included) should be attached securely to mounting surface in order to secure fountain, (Refer to rough-in diagram), and be sure to allow an opening for the freeze-resistant valve in the ground as shown in the installation instructions that accompany the fountain. (Refer to the rough-in diagram below). Refer to local codes for any additional requirements.

Locate and install plumbing through ground as required. Assemble fountain to prepared site and mounting pad.


NOTE: Fountain is not furnished with service valve.
Position pedestal over plumbing and secure base to fasteners.
Remove access panels and connect supply and water lines.
Turn on water supply and check for leaks. Refer to owner's manual for detailed instructions. Reassemble access panels to pedestal. Trap and service stop not included.

OPERATING PRESSURES: Supply water 20 – 105 psi maximum


## **TOP VIEW**



#### DETAIL A AIR GAP / VACUUM BREAKER



#### SIDE VIEW



In keeping with our policy of continuing product improvement, Elkay reserves the right to change product specifications without notice. Please visit elkay.com for the most current version of Elkay product specification sheets. This specification describes an Elkay product with design, quality, and functional benefits to the user. When making a comparison of other producers' offerings, be certain these features are not overlooked.