




TempGuard™ COLD
Temperature sensor for disabling
fresh air damper in extreme cold.

Wiring Diagram



Installation:

Drill a 1/2" hole in duct on
the cold air side of damper.

Fasten sensor with 2 self
tapping screws provided.

Wire according to diagram.



ITEM NO. ACTG-H01



AirCycler
www.AirCycler.com