




BOTTOM MOUNT FRENCH DOOR REFRIGERATOR

MODELS:

KRFC604FSS00 (Stainless Steel)

CABINET PARTS




CABINET PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts Tech Sheet
	W10832390	English
	W10832391	French
	W10815169	Use and Care Guide
	W10895051	Energy Guide
2	12990204	Screw
3	W10840310	Block, Pivot
4	W10838044	Pad, Sound
5	W10789113	Control, Electronic
6	W10415341	Gasket, HV Box
7		Assembly, Roller
	W10828760	Left Hand
	W10828759	Right Hand
8	W10846099	Brake, Roller
9	12990521	Screw
10		Hinge, Top
	W10845851	Left Hand
	W10845849	Right Hand
11	W10673840	Screw (Stainless)
12		Cover, Right Hinge
	W10819300	Grey
13		Cover, Left Hinge
	W10819302	Grey
14	W10731474	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15		Hinge, Center (Right)
	W10816323	Grey
16	12990702	Screw
17		Cover, Corner
	W10868482	Grey
18	W10726788	Valve, Water
19	W10485964	Switch, Reed
20	W10709365	Screw
21		Divider, Air
	W10878918	Rear
	W10878920	Bottom
22		Grille, Toe
	W10821309	Grey
23	12992601	Screw
24		Hinge, Center (Left)
	W10816322	Grey
25	W10141645	Screw
26	12990511	Screw
27	W10831131	Assembly, Jumper Wire
28	W10754144	Cover, Control Box
29	W10141645	Screw
30	W10669259	Cover, Unit
31	M0108107	Clamp, Tube
32	W10853597	Tube, Icemaker Water (Includes Seal)
	W10853599	Tube, Dispenser Water (Includes Seal)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
33	W10768379	Lid, HV
34	W10705239	Retainer, Door
35		Cabinet (Not a Servicable Part)
36	549193	Clamp, Power Cord
37		Assembly, Outer Air Tunnel (Includes Gasket)
	W10838744	Grey
38		Assembly, Inner Air Tunnel (Includes Gasket)
	W10838745	Grey
39	W10208592	Cover, Valve
40	W10831587	Bushing


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	11	W10680605	Filter, Water	22	W10635994	Assembly, Evaporator
2	W10708473	Housing, Water Tank	12	W10315189	Filter, Air	23	W10633172	Strip, LED
3	W10786645	Strip, LED	13	W10708474	Bracket, Filter	24	W10831305	Filter, Air
4	W10878020	Reservoir, Water (Also Order Wire Tie Part W10838005 Qty 2)	14	W10119266	Screw	25	W10716179	Base, Tower Cover
5	W10853040	Valve, Dual Water	15	12990518	Screw	26	W10848895	Harness, Air Tower Jumper
6	W10238156	Housing, Water Filter	16	W10839501	Insulation, Under Filter	27	12990501	Screw
7	W10900010	Cover, Water Valve	17	W10842807	Assembly, Air Filter	28	W10877761	Heater, Filter
8	W10789102	Tube, Water Filter	18	W10856502	Cover, Air Filter	29	W10818463	Gasket, Evaporator Air Dam
9	W10718061	Cover, Cooling Duct	19	W10673133	Bracket, Evaporator Drain	30	W10901792	Gasket, Sealing
10	W10836076	Cover, Tower	20	W10719253	Cap, Filter	FOLLOWING PARTS NOT ILLUSTRATED		
			21	W10865106	Assembly, Evaporator Cover (Includes Fan Motor, Wire Assembly and Thermistor)			
						W10871610	Assembly, Valve Wire	


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	7	C3680310V	Switch, Light	14	W10503218	Assembly, Drain Funnel
2	W10683669	Assembly, Evaporator	8	10623002	Clip, Evaporator	15	M0500703	Seal
3	W10660728	Assembly, LED Light Module	9	W10683507	Clip, Defrost Heater	16	B8381501	Gasket, Drain
4	W10772353	Assembly, Evaporator Cover (Includes Fan Motor and Wire Assembly)	10	W10668191	Shield, Heat	17	W10280385	Thermistor
5	12990511	Screw	11	W10886209	Assembly, Heat Shield	18	W10770923	Seal, Crisp Front
6	W10882092	Heater, Defrost	12		Dam, Air	19	W10685479	Assembly, Icebox Fan
				W10668201	Left Hand	20	W10683540	Gasket, Drip Tray Rear
				W10668198	Right Hand			
			13	W10655745	Assembly, Evaporator Heater Wire			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Left	11		Nameplate	22		Gasket, Door
	W10798169	Stainless		W10518672	Grey		W10798100	Grey
2		Door, Right	12	W10460893	Screw	23	W10823512	Trim, Gallon
	W10798250	Stainless	13	W10795606	Trivet, Ice Compartment	24	W10795526	Assembly, Utility Bin
3	W10464016	Screw			Door	25	W10795523	Base, Utility Bin
4	W10830493	Assembly, Ice Door	14		Bin, Door	26	W10803630	Door, Utility Bin (Includes Gasket)
5	W10763415	Bracket, Door Stop		W10806697	Medium	27	W10795525	Gasket, Utility Bin
6		Mullion, Door	15	W10720065	Retainer, Door Duct	28	W10795524	Lid, Utility Bin
	W10798202	Grey	16	W10853439	Gasket, Ice Door	29	W10793652	Assembly, Fill Tube (Icemaker)
7	12990204	Screw	17	W10245516	Clip, Tube	30	W10720069	Gasket, Snap-In Cooling
8		Handle, Door	18	W10842809	Assembly, User Interface	31		Closer, Door
	W10704121	Stainless	19	W10720073	Gasket, Cooling Duct		W10872968	Left Hand
9	W10656772	Switch, Rocker Arm	20		Bin, Door		W10872969	Right Hand
				W10776705	Gallon			
10		Bumper, Door	21	W10883965	Tube, Water			
	W10798308	Grey						


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Door Gasket)	7	12990518	Screw	15		Gasket, Door
	W10798127	Stainless	8	W10795831	Assembly, Top Pan		W10897938	Grey
2		Handle, Door	9	W10277361	Collar, Gear	16	W10697812	Bar, Support
	W10798381	Stainless	10	12991401	Screw	17	W10874021	Roller, Pan
3	W10460893	Screw	11	W10469177	Support, Pan	18	W10643690	Axle, Roller
4	W10851956	Shaft, Rack	12	489443	Screw (Stainless)	19	W10830658	Rail, Guard
5		Assembly, Bracket	13	W10795834	Assembly, Upper Half Pan	20	W10742424	Roller
	W10795842	Left Hand	14		Stop, Pan			
	W10795846	Right Hand		W10485096	Left Hand			
6	W10795850	Assembly, Bottom Pan		W10485089	Right Hand			





UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw	15	W10836504	Grommet, Compressor	29	W10709318	Coil, 3 Way Valve
2	W10820084	Screw	16	W10658301	Condenser	30	W10683708	Gasket, Condenser Fan
3	W10658357	Baseplate	17	W10391376	Bracket, Valve			Following Parts Not Illustrated
4	12990511	Screw	18	W10767831	Cover, Housing	978025		Valve, Access
5	W10860180	Assembly, Drain Extension	19	W10141645	Screw	978026		Valve, Access
6	W10674646	Assembly, 3 Way Valve	20	W10792503	Filter, EMI	978027		Valve, Access
7	W10838081	Pad, Sound	21	W10701009	Cover, Terminal	978028		Valve, Access
8	W10877573	Tray, Evaporator	22	2169104	Sealer, Insulation	978029		Valve, Access
9	W10884826	Grommet, Condenser	23	W10666068	Assembly, Suction Tube	978030		Valve, Access
10	W10697007	Bolt	24	W10655759	Harness, Unit (Condenser Fan)	876764		Valve, Access
11	W10697017	Clip, Retaining	25	4387019	Drier (Service Drier Without Dye)			REFRIGERANT CHARGE
12	W10789117	Assembly, Orion Box (Includes Wiring Harness for Compressor and Power Cord)	26	W11025999	Compressor (Includes Orion Box Assembly)			4.65 oz. (R134A)
13	W10774846	Roller	27	W10883082	Assembly, Condenser Fan			
14	12992101	Screw	28	12477202	Axle, Roller			


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10836749	Assembly, Pantry/Crisper Frame	10	W10794349	Pan, Pantry	18	W10758550	Assembly, Light
2	W10696184	Ring, Handle	11	W10868912	Assembly, Platter Shelf	19	W10666373	Screw
3	W10834718	Housing, Filter	12		Glide, Platter	20	W10826105	Assembly, Produce Preserver
4	W10794356	Door, Filter		W10843718	Left Hand	21	W10804977	Screw
5	2223877	Latch, Push		W10843719	Right Hand	22	W10897364	Glass, Platter
6	W10794689	Assembly, 15" Full Shelf	13	W10663641	Spacer, Handle	23	W10840918	Flange, Side Support
7	W10794698	Assembly, 12" Full Shelf	14	W10804533	Glass, Crisper Cover	24	W10840922	Knob, Side Support
8	W10837198	Assembly, Tuck Shelf	15		Glide, Crisper	25	W10795580	Assembly, Herb Storage (Includes Lid and Gasket)
9		Assembly, Block		W10866165	Left Hand			
	W10817918	Front Left/Back Right		W10866168	Right Hand			
	W10817925	Front Right/Back Left	16	W10794346	Handle			
			17	W10794330	Assembly, Crisper Pan			




DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	6	W10837350	Grate, Drip	13	W10704135	Assembly, Paddle Jumper Wire
2	W10786655	Assembly, User Interface	7		Tray, Drip	14	W10757499	Bracket, User Interface Adapter
3		Wall, Dispenser False		W10792138	Black	15	W10696713	Gasket, User Interface Adapter
	W10792135	Black	8		Ring, Trim	16	W10696704	Assembly, Ice Door Motor Bracket
4		Paddle, Water Dispenser		W10792136	Chrome	17	W10663699	Pad, Sound
	W10889223	Chrome	9		Paddle, Ice Dispenser	18	W10752689	Heater, Dispenser
5		Seperator		W10815345	Black	19	W10888235	Gasket
	W10889235	Black	10	W10403752	Switch, Limit	20	W10809296	Guide, Light
			11	W10672578	Spring, Torsion			
			12	W10663682	Spring, Torsion			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10682175	Plate, Ice Chute
3	W10291905	Gasket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10903433	Assembly, Ice Container
5	W10678163	Shaft, Motor
6	W10215646	Motor, Dispenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	W10888881	Assembly, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key