


KitchenAid®

BOTTOM MOUNT FRENCH DOOR REFRIGERATOR

MODELS:

KRFC704FBS00 (Black Stainless)
KRFC704FSS00 (Stainless Steel)

CABINET PARTS




CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts Tech Sheet
	W10832390	English
	W10832391	French
	W10815169	Use and Care Guide
	W10815173	Energy Guide
2	12990204	Screw
3	W10840312	Block, Pivot
4	W10838044	Pad, Sound
5	W10789113	Control, Electronic
6	W10415341	Gasket, HV Box
7		Assembly, Roller
	W10828760	Left Hand
	W10828759	Right Hand
8	W10846099	Brake, Roller
9	12990521	Screw
10		Hinge, Top
	W10845851	Left Hand
	W10845849	Right Hand
11	W10673840	Screw (Stainless)
12		Cover, Top Hinge
		Left Hand
	W10819303	Black
	W10819302	Grey
		Right Hand
	W10819301	Black
	W10819300	Grey
13	W10208592	Cover, Valve

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10731474	Screw
15		Hinge, Center Left Hand
	W10691674	Black
	W10816322	Grey
		Right Hand
	W10691700	Black
	W10816323	Grey
16	12990702	Screw
17		Cover, Corner
	12587703B	Black
	W10868482	Grey
18	W10726788	Valve, Water
19	W10485964	Switch, Reed
20	W10709365	Screw
21		Divider, Air
	W10878918	Rear
	W10878920	Bottom
22		Grille, Toe
	W10821308	Black
	W10821309	Grey
23	12992601	Screw
24		Assembly, Outer Air Tunnel (Includes Gasket)
	W10835554	Black
	W10838744	Grey
25	W10141645	Screw
26	12990511	Screw
27	W10831131	Assembly, Jumper Wire

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
28	W10754144	Cover, Control Box
29	W10141645	Screw
30	W10669259	Cover, Unit
31	M0108107	Clamp, Tube
32	W10853597	Tube, Icemaker Water (Includes Seal)
	W10853599	Tube, Dispenser Water (Includes Seal)
33	W10768379	Lid, HV
34	W10705239	Retainer, Door
35		Cabinet (Not a Servicable Part)
36	549193	Clamp, Power Cord
37		Assembly, Inner Air Tunnel (Includes Gasket)
	W10835557	Black
	W10838745	Grey
38	W10831587	Bushing


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	11	W10680605	Filter, Water	22	W10635994	Assembly, Evaporator
2	W10708473	Housing, Water Tank	12	W10315189	Filter, Air	23	W10887931	Strip, LED
3	W10786645	Strip, LED	13	W10708474	Bracket, Filter	24	W10831305	Filter, Air
4	W10878020	Reservoir, Water (Also Order Wire Tie Part W10838005 Qty 2)	14	W10119266	Screw	25	W10815960	Base, Tower Cover
5	W10853040	Valve, Dual Water	15	12990518	Screw	26	W10848895	Harness, Air Tower Jumper
6	W10906054	Housing, Water Filter	16	W10839501	Insulation, Under Filter	27	12990501	Screw
7	W10900011	Cover, Water Valve	17	W10817432	Assembly, Air Filter	28	W10877761	Heater, Filter
8	W10789102	Tube, Water Filter	18	W10856502	Cover, Air Filter	29	W10901792	Gasket, Sealing
9	W10815965	Cover, Cooling Duct	19	W10673133	Bracket, Evaporator Drain	30	W10818463	Gasket, Evaporator Air Dam
10	W10815966	Cover, Tower	20	W10813883	Cap, Filter			FOLLOWING PARTS NOT ILLUSTRATED
			21	W10815735	Assembly, Evaporator Cover (Includes Fan Motor, Wire Assembly and Thermistor)	W10871610		Assembly, Valve Wire


FREEZER LINER PARTS



FREEZER LINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Liner (Not A Serviceable Part)	8	10623002	Clip, Evaporator	15	M0500703	Seal
2	W10683669	Assembly, Evaporator	9	W10683507	Clip, Defrost Heater	16	B8381501	Gasket, Drain
3	W10660728	Assembly, LED Light Module	10	W10886209	Assembly, Heat Shield	17	W10280385	Thermistor
4	W10815704	Assembly, Evaporator Cover (Includes Fan Motor and Wire Assembly)	11	W10683540	Gasket, Drip Tray Rear	18	W10770923	Seal, Crisp Front
5	12990511	Screw	12		Dam, Air	19	W10685479	Assembly, Icebox Fan
6	W10882092	Heater, Defrost		W10668201	Left Hand			
7	W10565415	Switch, Light		W10668198	Right Hand			
			13	W10655745	Assembly, Evaporator Heater Wire			
			14	W10503218	Assembly, Drain Funnel			


REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Refrigerator	9	W10810008	Switch, Rocker Arm	21	W10883965	Tube, Water
		Left Hand	10		Bumper, Door	22		Gasket, Door
	W10798171	Black		W10407187	Black		W10798099	Black
	W10798170	Stainless		W10798308	Grey		W10798100	Grey
		Right Hand	11		Nameplate	23	W10823512	Trim, Gallon
	W10798252	Black		W10518672	Grey	24	W10795526	Assembly, Utility Bin
	W10831951	Stainless	12	W10460893	Screw	25	W10795523	Base, Utility Bin
2	W10793652	Assembly, Fill Tube (Icemaker)	13	W10795606	Trivet, Ice Compartment Door	26	W10803630	Door, Utility Bin (Includes Gasket)
3	W10464016	Screw	14		Bin, Door	27	W10795525	Gasket, Utility Bin
4	W10798124	Assembly, Ice Door		W10806697	Medium	28	W10795524	Lid, Utility Bin
5	W10763415	Bracket, Door Stop	15	W10834282	Retainer, Door Duct	29	W10799328	Duct, Cooling
6		Mullion, Door	16	W10853441	Gasket, Ice Door	30		Closer, Door
	W10798203	Black	17	W10839046	Clip, Tube		W10872968	Left Hand
	W10798202	Grey	18	W10842809	Assembly, User Interface		W10872969	Right Hand
7	12990204	Screw	19	W10828418	Gasket, Cooling Duct			
8		Handle, Door	20		Bin, Door			
	W10704121	Stainless		W10776705	Gallon			


FREEZER DOOR PARTS



FREEZER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Door, Freezer (Includes Door Gasket)	7	12990518	Screw	15		Gasket, Door
	W10798129	Black	8	W10795832	Assembly, Top Pan		W10884296	Black
	W10832272	Stainless	9	W10277361	Collar, Gear		W10897938	Grey
2		Handle, Door	10	12991401	Screw	16	W10697812	Bar, Support
	W10798381	Stainless	11	W10469177	Support, Pan	17	W10874022	Roller
3	W10460893	Screw	12	489443	Screw (Stainless)	18	W10839803	Axle, Roller
4	W10851956	Shaft, Rack	13	W10795835	Assembly, Upper Half Pan	19	W10830659	Rail, Guard
5		Assembly, Bracket	14		Stop, Pan	20	W10837296	Roller
	W10795843	Left Hand		W10795820	Left Hand			
	W10795847	Right Hand		W10795822	Right Hand			
6	W10795851	Assembly, Bottom Pan						

UNIT PARTS





UNIT PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10141625	Screw
2	W10820084	Screw
3	W10658357	Baseplate
4	12990511	Screw
5	W10860180	Assembly, Drain Extension
6	W10674646	Assembly, 3 Way Valve
7	W10838081	Pad, Sound
8	W10877573	Tray, Evaporator
9	W10683708	Gasket, Condenser Fan
10	W10697007	Bolt
11	W10697017	Clip, Retaining
12	W10789117	Assembly, Orion Box (Includes Wiring Harness for Compressor and Power Cord)
13	W10774846	Roller
14	12992101	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
15	W10836504	Grommet, Compressor
16	W10658301	Condenser
17	W10391376	Bracket, Valve
18	W10767831	Cover, Housing
19	W10141645	Screw
20	W10792503	Filter, EMI
21	W10701009	Cover, Terminal
22	2169104	Sealer, Insulation
23	W10666068	Assembly, Suction Tube
24	W10655759	Harness, Unit (Condenser Fan)
25	4387019	Drier (Service Drier Without Dye)
26	W11025999	Compressor (Includes Orion Box Assembly)
27	W10883082	Assembly, Condenser Fan
28	12477202	Axle, Roller

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
29	W10709318	Coil, 3 Way Valve
30	W10884826	Grommet, Condenser
Following Parts Not Illustrated		
	978025	Valve, Access
	978026	Valve, Access
	978027	Valve, Access
	978028	Valve, Access
	978029	Valve, Access
	978030	Valve, Access
	876764	Valve, Access
		REFRIGERANT CHARGE
		4.65 oz. (R134A)


SHELF PARTS



SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10794291	Assembly, Pantry/Crisper Frame	10	W10794349	Pan, Pantry	18	W10758550	Assembly, Light
2	W10696184	Ring, Handle	11	W10794568	Assembly, Platter Shelf	19	W10666373	Screw
3	W10794370	Housing, Filter	12		Glide, Platter	20	W10826105	Assembly, Produce Preserver
4	W10794356	Door, Filter		W10843722	Left Hand	21	W10818078	Pan, Under Shelf
5	2223877	Latch, Push		W10814862	Right Hand	22	W10794571	Glass, Platter
6	W10793467	Assembly, 15" Full Shelf	13	W10663641	Spacer, Handle	23	W10840918	Flange, Side Support
7	W10793520	Assembly, 12" Full Shelf	14	W10804533	Glass, Crisper Cover	24	W10840920	Knob, Side Support
8	W10794646	Assembly, Tuck Shelf	15		Glide, Crisper	25	W10795580	Assembly, Herb Storage (Includes Lid and Gasket)
9		Assembly, Block		W10816001	Left Hand			
	W10817922	Front Left/Back Right		W10814857	Right Hand			
	W10817921	Front Right/Back Left	16	W10794346	Handle			
			17	W10794330	Assembly, Crisper Pan			





DISPENSER FRONT PARTS



DISPENSER FRONT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Housing, Dispenser (Not Serviced)	6	W10837350	Grate, Drip	13	W10704135	Assembly, Paddle Jumper Wire
2	W10786655	Assembly, User Interface	7		Tray, Drip	14	W10888235	Gasket
3		Wall, Dispenser False		W10792138	Black	15	W10696713	Gasket, User Interface Adapter
	W10792135	Black	8		Ring, Trim	16	W10696704	Assembly, Ice Door Motor Bracket
4		Paddle, Water Dispenser		W10792136	Chrome	17	W10663699	Pad, Sound
	W10889223	Chrome	9		Paddle, Ice Dispenser	18	W10752689	Heater, Dispenser
5		Seperator		W10815345	Black	19	W10757499	Bracket, User Interface Adapter
	W10889235	Black	10	W10403752	Switch, Limit	20	W10809296	Guide, Light
			11	W10672578	Spring, Torsion			
			12	W10663682	Spring, Torsion			

ICEMAKER AND ICE CONTAINER PARTS



ICEMAKER AND ICE CONTAINER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10272364	Screw
2	W10793257	Plate, Ice Chute
3	W10291905	Gasket

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10903434	Assembly, Ice Container
5	W10678163	Shaft, Motor
6	W10215646	Motor, Dispenser

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8281163	Screw (Stainless)
8	W10888882	Assembly, Icemaker

OPTIONAL PARTS

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Insulation (2 Pieces, 3" x 24" x 48")
	876305	Insulation Kit (14 Pieces, 3" x 24" x 48")
	978941	Insulation, Fiberglass (63 1/2" x 35 1/2" x 2 5/8")
	876029	Kit, Foam Slab (30" x 32 1/2" x 1 1/2")
	505587	Sealer, Mastic (1 Qt)
	503695	Cork, Sealer
	20000008	Cleaner, Stainless Steel
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1 1/4 Oz.)
	833938	Kit, Terminal Connector
	8003RP	Kit, Water Inlet

TORX SCREW WRENCH

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	1117510	Torx Key