

RH1T

Parts List
12-November-2018



*This parts list is current as of the above revision date.
See <http://www.rheempartslists.net/92-42801-RH1T.pdf> for the current revision.*

Air Handlers

Table of Contents

Model Explanation	Page 3
-------------------------	--------

Parts Numbers

Panels - MSC (1)	Page 4
Panels - MSC (2)	Page 5
Panels - MSC (3)	Page 6
ELG (1)	Page 7
ELG (2)	Page 8
ELG (3)	Page 9
BG (1)	Page 10
BG (2)	Page 11
BG (3)	Page 12
CPG (1)	Page 13
CPG (2)	Page 14
HKG (1)	Page 15
HKG (2)	Page 16

Drawings/Photographs

Exploded View	Page 17
Blower Assembly	Page 18

Notes	Page 19
-------------	---------

MODEL NUMBER EXPLANATION

R	H	1	T	2	4	1	7	S	T	A	N	A	A	***
1	2	3	4	5		6		7	8	9	10	11	12	13

- | | |
|--|--|
| <p>(1) BRAND</p> <p>(2) AIR HANDLER</p> <p>(3) STAGE OF AIRFLOW
1 = Single</p> <p>(4) MOTOR TYPE
T = Constant Torque</p> <p>(5) CAPACITY (BTU/HR)
18 = 18,000 BTU/HR
24 = 24,000 BTU/HR
30 = 30,000 BTU/HR
36 = 36,000 BTU/HR
42 = 42,000 BTU/HR
48 = 48,000 BTU/HR
60 = 60,000 BTU/HR</p> <p>(6) WIDTH
17 = 17.5 in. (600 - 1200 CFM)
21 = 21 in. (800 - 1600 CFM)
24 = 24.5 in. (1400 - 1800 CFM)</p> <p>(7) COIL SIZE
S = Standard
M = Medium
H = High</p> | <p>(8) METERING DEVICE
T = TEV (TXV)
E = EEV (EXV)
P = Piston</p> <p>(9) MAJOR SERIES
A = First
B = Piston Change</p> <p>(10) CONTROLS
C = Communicating
N = Non-Communicating</p> <p>(11) VOLTAGE
A = 115/1/60
D = 460/3/60
J = 208-230/1/60
T = 220-240/1/50</p> <p>(12) MINOR SERIES
A = First</p> <p>(13) OPTION CODE
Blank = None</p> |
|--|--|

SERIAL NUMBER EXPLANATION

W	0	7	0	9	9	9	9	9	9
1	2	3	4						

- | | |
|---|---|
| 1 | PRODUCTION LOCATION
W = Nuevo Laredo (West) |
| 2 | WEEK OF PRODUCTION |
| 3 | YEAR OF PRODUCTION |
| 4 | PRODUCTION NUMBER |

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 24 17 SP AN/BN AA	RH1T 24 17 SP AN/BN JA	RH1T 24 17 ST AN AA	RH1T 24 17 ST AN JA	RH1T 36 17 SE AN JA	RH1T 36 17 SP AN/BN AA
PANELS, SHEET METAL, MISCELLANEOUS								
1		Cabinet	N/A	N/A	N/A	N/A	N/A	N/A
		Insulation - Cabinet	68-101121-01	68-101121-01	68-101121-01	68-101121-01	68-101121-01	68-101121-01
		Insulation Retainer Rod (2)	45-102868-02	45-102868-02	45-102868-02	45-102868-02	45-102868-02	45-102868-02
2		Coil Door	AE-100685-32	AE-100685-32	AE-100685-32	AE-100685-32	AE-100685-32	AE-100685-32
		Insulation - Coil Door	68-101577-06	68-101577-06	68-101577-06	68-101577-06	68-101577-06	68-101577-06
3		Top Cover Plate	AE-100686-31	AE-100686-31	AE-100686-31	AE-100686-31	AE-100686-31	AE-100686-31
		Insulation - Top Cover Plate	68-101122-01	68-101122-01	68-101122-01	68-101122-01	68-101122-01	68-101122-01
4		Blower Door	AE-100684-31	AE-100684-31	AE-100684-31	AE-100684-31	AE-100684-31	AE-100684-31
		Insulation - Blower Door	68-101576-01	68-101576-01	68-101576-01	68-101576-01	68-101576-01	68-101576-01
5		Access Panel	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31
		Insulation - Access Panel	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01
		Poron Gasket (Blower & Coil Doors)	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03
6		Drain Pan - Vertical	See RCH Coil Parts List					
7		Drain Pan - Horizontal	See RCH Coil Parts List					
8		Plate - Block Off	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01
9		Cabinet Brace	AE-101134-02	AE-101134-02	AE-101134-02	AE-101134-02	AE-101134-02	AE-101134-02
10		Middle Brace	AE-101054-01	AE-101054-01	AE-101054-01	AE-101054-01	AE-101054-01	AE-101054-01
13a		Heat Barrier	AE-100683-02	AE-100683-02	AE-100683-03	AE-100683-03	AE-100683-03	AE-100683-03
13b		Heat Barrier Side (2)	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01
		Insulation Retainer Rod (2)	45-102868-02	45-102868-02	45-102868-02	45-102868-02	45-102868-02	45-102868-02
		Duct Flanges (2)	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07
		Touch-up Paint - Granite/Steel Gray (Aerosol)	PD523018	PD523018	PD523018	PD523018	PD523018	PD523018
		Touch-up Paint - Granite/Steel Gray (Paint Pens)	PD523019	PD523019	PD523019	PD523019	PD523019	PD523019

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 36 17 SP AN/BN JA	RH1T 36 17 ST AN AA	RH1T 36 17 ST AN JA	RH1T 36 17 ST AN DA		
PANELS, SHEET METAL, MISCELLANEOUS								
1		Cabinet	N/A	N/A	N/A	N/A		
		Insulation - Cabinet	68-101121-01	68-101121-01	68-101121-01	68-101121-01		
		Insulation Retainer Rod (2)	45-102868-02	45-102868-02	45-102868-02	45-102868-02		
2		Coil Door	AE-100685-32	AE-100685-32	AE-100685-32	AE-100685-32		
		Insulation - Coil Door	68-101577-06	68-101577-06	68-101577-06	68-101577-06		
3		Top Cover Plate	AE-100686-31	AE-100686-31	AE-100686-31	AE-100686-31		
		Insulation - Top Cover Plate	68-101122-01	68-101122-01	68-101122-01	68-101122-01		
4		Blower Door	AE-100684-31	AE-100684-31	AE-100684-31	AE-100684-31		
		Insulation - Blower Door	68-101576-01	68-101576-01	68-101576-01	68-101576-01		
5		Access Panel	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31		
		Insulation - Access Panel	68-101644-01	68-101644-01	68-101644-01	68-101644-01		
		Poron Gasket (Blower & Coil Doors)	68-42246-03	68-42246-03	68-42246-03	68-42246-03		
6		Drain Pan - Vertical	See RCH Coil Parts List					
7		Drain Pan - Horizontal	See RCH Coil Parts List					
8		Plate - Block Off	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01		
9		Cabinet Brace	AE-101134-02	AE-101134-02	AE-101134-02	AE-101134-02		
10		Middle Brace	AE-101054-01	AE-101054-01	AE-101054-01	AE-101054-01		
13a		Heat Barrier	AE-100683-03	AE-100683-03	AE-100683-03	AE-100683-03		
13b		Heat Barrier Side (2)	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01		
		Insulation Retainer Rod (2)	45-102868-02	45-102868-02	45-102868-02	45-102868-02		
		Duct Flanges (2)	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07		
		Touch-up Paint - Granite/Steel Gray (Aerosol)	PD523018	PD523018	PD523018	PD523018	PD523018	PD523018
		Touch-up Paint - Granite/Steel Gray (Paint Pens)	PD523019	PD523019	PD523019	PD523019	PD523019	PD523019

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T	RH1T	RH1T
		CAPACITY	36	36	36	36	36	48
		CABINET SIZE	21	21	21	21	21	21
		COIL SIZE/METERING	MT	MT	HT	HT	MT	ST
		MAJOR SERIES/CONTROLS	AN	AN	AN	AN	AN	AN
		VOLTAGE/MINOR SERIES	AA	JA	AA	JA	DA	DA
PANELS, SHEET METAL, MISCELLANEOUS								
1		Cabinet	N/A	N/A	N/A	N/A	N/A	N/A
		Insulation - Cabinet	68-101121-03	68-101121-03	68-101121-15	68-101121-15	68-101121-03	68-101121-03
		Insulation Retainer Rod (2)	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03
2		Coil Door	AE-100685-34	AE-100685-34	AE-100685-37	AE-100685-37	AE-100685-34	AE-100685-34
		Insulation - Coil Door	68-101577-08	68-101577-08	68-101577-10	68-101577-10	68-101577-08	68-101577-08
3		Top Cover Plate	AE-100686-32	AE-100686-32	AE-100686-32	AE-100686-32	AE-100686-32	AE-100686-32
		Insulation - Top Cover Plate	68-101122-02	68-101122-02	68-101122-02	68-101122-02	68-101122-02	68-101122-02
4		Blower Door	AE-100684-32	AE-100684-32	AE-100684-32	AE-100684-32	AE-100684-32	AE-100684-32
		Insulation - Blower Door	68-101576-02	68-101576-02	68-101576-02	68-101576-02	68-101576-02	68-101576-02
5		Access Panel	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31
		Insulation - Access Panel	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01
		Poron Gasket (Blower & Coil Doors)	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03
6		Drain Pan - Vertical	See RCH Coil Parts List					
7		Drain Pan - Horizontal	See RCH Coil Parts List					
8		Plate - Block Off	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01
9		Cabinet Brace	AE-101134-03	AE-101134-03	AE-101134-03	AE-101134-03	AE-101134-03	AE-101134-03
10		Middle Brace	AE-101054-02	AE-101054-02	AE-101054-02	AE-101054-02	AE-101054-02	AE-101054-02
13a		Heat Barrier	AE-100683-06	AE-100683-06	AE-100683-06	AE-100683-06	AE-100683-06	AE-100683-06
13b		Heat Barrier Side (2)	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01
		Insulation Retainer Rod (2)	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03
		Duct Flanges (2)	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07
		Touch-up Paint - Granite/Steel Gray (Aerosol)	PD523018	PD523018	PD523018	PD523018	PD523018	PD523018
		Touch-up Paint - Granite/Steel Gray (Paint Pens)	PD523019	PD523019	PD523019	PD523019	PD523019	PD523019

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T	RH1T	RH1T
		CAPACITY	48	48	48	48	48	48
		CABINET SIZE	21	21	21	21	21	21
		COIL SIZE/METERING	SP	SP	ST	ST	MT	MT
		MAJOR SERIES/CONTROLS	AN/BN	AN/BN	AN	AN	AN	AN
		VOLTAGE/MINOR SERIES	AA	JA	AA	JA	AA	JA
PANELS, SHEET METAL, MISCELLANEOUS								
1		Cabinet	N/A	N/A	N/A	N/A	N/A	N/A
		Insulation - Cabinet	68-101121-03	68-101121-03	68-101121-03	68-101121-03	68-101121-15	68-101121-15
		Insulation Retainer Rod (2)	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03
2		Coil Door	AE-100685-34	AE-100685-34	AE-100685-34	AE-100685-34	AE-100685-37	AE-100685-37
		Insulation - Coil Door	68-101577-08	68-101577-08	68-101577-08	68-101577-08	68-101577-10	68-101577-10
3		Top Cover Plate	AE-100686-32	AE-100686-32	AE-100686-32	AE-100686-32	AE-100686-32	AE-100686-32
		Insulation - Top Cover Plate	68-101122-02	68-101122-02	68-101122-02	68-101122-02	68-101122-02	68-101122-02
4		Blower Door	AE-100684-32	AE-100684-32	AE-100684-32	AE-100684-32	AE-100684-32	AE-100684-32
		Insulation - Blower Door	68-101576-02	68-101576-02	68-101576-02	68-101576-02	68-101576-02	68-101576-02
5		Access Panel	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31
		Insulation - Access Panel	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01
		Poron Gasket (Blower & Coil Doors)	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03
6		Drain Pan - Vertical	See RCH Coil Parts List					
7		Drain Pan - Horizontal	See RCH Coil Parts List					
8		Plate - Block Off	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01
9		Cabinet Brace	AE-101134-03	AE-101134-03	AE-101134-03	AE-101134-03	AE-101134-03	AE-101134-03
10		Middle Brace	AE-101054-02	AE-101054-02	AE-101054-02	AE-101054-02	AE-101054-02	AE-101054-02
13a		Heat Barrier	AE-100683-06	AE-100683-06	AE-100683-06	AE-100683-06	AE-100683-06	AE-100683-06
13b		Heat Barrier Side (2)	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01
		Insulation Retainer Rod (2)	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03	45-102868-03
		Duct Flanges (2)	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07
		Touch-up Paint - Granite/Steel Gray (Aerosol)	PD523018	PD523018	PD523018	PD523018	PD523018	PD523018
		Touch-up Paint - Granite/Steel Gray (Paint Pens)	PD523019	PD523019	PD523019	PD523019	PD523019	PD523019

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T	RH1T	RH1T
		CAPACITY	48	48	48	60	60	60
		CABINET SIZE	24	24	24	21	21	21
		COIL SIZE/METERING	ST	ST	ST	ST	ST	ST
		MAJOR SERIES/CONTROLS	AN	AN	AN	AN	AN	AN
		VOLTAGE/MINOR SERIES	AA	JA	DA	AA	JA	DA
PANELS, SHEET METAL, MISCELLANEOUS								
1		Cabinet	N/A	N/A	N/A	N/A	N/A	N/A
		Insulation - Cabinet	68-101121-04	68-101121-04	68-101121-04	68-101121-15	68-101121-15	68-101121-15
		Insulation Retainer Rod (2)	45-102868-04	45-102868-04	45-102868-04	45-102868-03	45-102868-03	45-102868-03
2		Coil Door	AE-100685-36	AE-100685-36	AE-100685-36	AE-100685-37	AE-100685-37	AE-100685-37
		Insulation - Coil Door	68-101577-09	68-101577-09	68-101577-09	68-101577-10	68-101577-10	68-101577-10
3		Top Cover Plate	AE-100686-33	AE-100686-33	AE-100686-33	AE-100686-32	AE-100686-32	AE-100686-32
		Insulation - Top Cover Plate	68-101122-03	68-101122-03	68-101122-03	68-101122-02	68-101122-02	68-101122-02
4		Blower Door	AE-100684-33	AE-100684-33	AE-100684-33	AE-100684-32	AE-100684-32	AE-100684-32
		Insulation - Blower Door	68-101576-03	68-101576-03	68-101576-03	68-101576-02	68-101576-02	68-101576-02
5		Access Panel	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31	AE-101133-31
		Insulation - Access Panel	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01	68-101644-01
		Poron Gasket (Blower & Coil Doors)	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03	68-42246-03
6		Drain Pan - Vertical	See RCH Coil Parts List					
7		Drain Pan - Horizontal	See RCH Coil Parts List					
8		Plate - Block Off	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01	AE-100455-01
9		Cabinet Brace	AE-101134-04	AE-101134-04	AE-101134-04	AE-101134-03	AE-101134-03	AE-101134-03
10		Middle Brace	AE-101054-03	AE-101054-03	AE-101054-03	AE-101054-02	AE-101054-02	AE-101054-02
13a		Heat Barrier	AE-100683-08	AE-100683-08	AE-100683-08	AE-100683-06	AE-100683-06	AE-100683-06
13b		Heat Barrier Side (2)	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01	AE-104241-01
		Insulation Retainer Rod (2)	45-102868-04	45-102868-04	45-102868-04	45-102868-03	45-102868-03	45-102868-03
		Duct Flanges (2)	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07	AE-101048-07
		Touch-up Paint - Granite/Steel Gray (Aerosol)	PD523018	PD523018	PD523018	PD523018	PD523018	PD523018
		Touch-up Paint - Granite/Steel Gray (Paint Pens)	PD523019	PD523019	PD523019	PD523019	PD523019	PD523019

No.	Notes	MODEL				RH1T	RH1T	RH1T
		CAPACITY				60	60	60
		CABINET SIZE				24	24	24
		COIL SIZE/METERING				ST	ST	ST
		MAJOR SERIES/CONTROLS				AN	AN	AN
		VOLTAGE/MINOR SERIES				AA	DA	JA
PANELS, SHEET METAL, MISCELLANEOUS								
1		Cabinet				N/A	N/A	N/A
		Insulation - Cabinet				68-101121-04	68-101121-04	68-101121-04
		Insulation Retainer Rod (2)				45-102868-04	45-102868-04	45-102868-04
2		Coil Door				AE-100685-36	AE-100685-36	AE-100685-36
		Insulation - Coil Door				68-101577-09	68-101577-09	68-101577-09
3		Top Cover Plate				AE-100686-33	AE-100686-33	AE-100686-33
		Insulation - Top Cover Plate				68-101122-03	68-101122-03	68-101122-03
4		Blower Door				AE-100684-33	AE-100684-33	AE-100684-33
		Insulation - Blower Door				68-101576-03	68-101576-03	68-101576-03
5		Access Panel				AE-101133-31	AE-101133-31	AE-101133-31
		Insulation - Access Panel				68-101644-01	68-101644-01	68-101644-01
		Poron Gasket (Blower & Coil Doors)				68-42246-03	68-42246-03	68-42246-03
6		Drain Pan - Vertical	See RCH Coil Parts List					
7		Drain Pan - Horizontal	See RCH Coil Parts List					
8		Plate - Block Off				AE-100455-01	AE-100455-01	AE-100455-01
9		Cabinet Brace				AE-101134-04	AE-101134-04	AE-101134-04
10		Middle Brace				AE-101054-03	AE-101054-03	AE-101054-03
13a		Heat Barrier				AE-100683-08	AE-100683-08	AE-100683-08
13b		Heat Barrier Side (2)				AE-104241-01	AE-104241-01	AE-104241-01
		Insulation Retainer Rod (2)				45-102868-04	45-102868-04	45-102868-04
		Duct Flanges (2)				AE-101048-07	AE-101048-07	AE-101048-07
		Touch-up Paint - Granite/Steel Gray (Aerosol)				PD523018	PD523018	PD523018
		Touch-up Paint - Granite/Steel Gray (Paint Pens)				PD523019	PD523019	PD523019

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 24 17 SP AN/BN AA	RH1T 24 17 SP AN/BN JA	RH1T 24 17 ST AN AA	RH1T 24 17 ST AN JA	RH1T 36 17 SP AN/BN AA	RH1T 36 17 SP AN/BN JA
ELECTRICAL GROUP								
17	Stk	Transformer	46-101944-01	46-101905-01	46-101944-01	46-101905-01	46-101944-01	46-101905-01
18	Stk	Control Board	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat)	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)	45-24258-24	45-24258-22	45-24258-24	45-24258-22	45-24258-24	45-24258-22
11		Terminal Block	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 36 17 ST AN AA	RH1T 36 17 ST AN JA	RH1T 36 17 ST AN DA	RH1T 36 21 MT AN AA	RH1T 36 21 MT AN JA	RH1T 36 21 HT AN AA
ELECTRICAL GROUP								
17	Stk	Transformer	46-101944-01	46-101905-01	46-101946-01	46-101944-01	46-101905-01	46-101944-01
18	Stk	Control Board	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat)	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)	45-24258-24	45-24258-22	45-24258-22	45-24258-24	45-24258-22	45-24258-24
11		Terminal Block	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 36 21 HT AN JA	RH1T 36 21 MT AN DA				
ELECTRICAL GROUP								
17	Stk	Transformer	46-101905-01	46-101946-01				
18	Stk	Control Board	47-102077-05	47-102077-05				
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat)	45-101891-01	45-101891-01				
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)	45-24258-18	45-24258-18				
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)	45-24258-22	45-24258-22				
11		Terminal Block	45-23222-02	45-23222-02				

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T	RH1T	RH1T
		CAPACITY	48	48	48	48	48	48
		CABINET SIZE	21	21	21	21	21	21
		COIL SIZE/METERING	ST	SP	SP	ST	ST	MT
		MAJOR SERIES/CONTROLS	AN	AN/BN	AN/BN	AN	AN	AN
		VOLTAGE/MINOR SERIES	DA	AA	JA	AA	JA	AA
ELECTRICAL GROUP								
17	Stk	Transformer	46-101946-01	46-101944-01	46-101905-01	46-101944-01	46-101905-01	46-101944-01
18	Stk	Control Board	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat)	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)	45-24258-22	45-24258-24	45-24258-22	45-24258-24	45-24258-22	45-24258-24
11		Terminal Block	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T		
		CAPACITY	48	48	48	48		
		CABINET SIZE	21	24	24	24		
		COIL SIZE/METERING	MT	ST	ST	ST		
		MAJOR SERIES/CONTROLS	AN	AN	AN	AN		
		VOLTAGE/MINOR SERIES	JA	AA	JA	DA		
ELECTRICAL GROUP								
17	Stk	Transformer	46-101905-01	46-101944-01	46-101905-01	46-101946-01		
18	Stk	Control Board	47-102077-05	47-102077-05	47-102077-05	47-102077-05		
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat)	45-101891-01	45-101891-01	45-101891-01	45-101891-01		
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)	45-24258-18	45-24258-18	45-24258-18	45-24258-18		
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)	45-24258-22	45-24258-24	45-24258-22	45-24258-22		
11		Terminal Block	45-23222-02	45-23222-02	45-23222-02	45-23222-02		

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T	RH1T	RH1T
		CAPACITY	60	60	60	60	60	60
		CABINET SIZE	21	21	21	24	24	24
		COIL SIZE/METERING	ST	ST	ST	ST	ST	ST
		MAJOR SERIES/CONTROLS	AN	AN	AN	AN	AN	AN
		VOLTAGE/MINOR SERIES	AA	JA	DA	AA	DA	JA
ELECTRICAL GROUP								
17	Stk	Transformer	46-101944-01	46-101905-01	46-101946-01	46-101944-01	46-101946-01	46-101905-01
18	Stk	Control Board	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05	47-102077-05
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat)	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01	45-101891-01
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18	45-24258-18
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)	45-24258-24	45-24258-22	45-24258-22	45-24258-24	45-24258-22	45-24258-22
11		Terminal Block	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02	45-23222-02

No.	Notes	MODEL		RH1T				
		CAPACITY		36				
		CABINET SIZE		17				
		COIL SIZE/METERING		SE				
		MAJOR SERIES/CONTROLS		AN				
		VOLTAGE/MINOR SERIES		JA				
ELECTRICAL GROUP								
17	Stk	Transformer		46-101905-01				
18	Stk	Control Board		47-102077-05				
		Control Board - EXV		47-105369-01				
		Wiring Harness - 6 Pin Molex to 6 stripped wires (For T-Stat) and 4 Pin Plug (To EXV Board)		45-101891-10				
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor to Terminal Block - Black Wires)		45-24258-18				
		Wiring Harness - 1 strip lead and 1 connector to single connector (Control Transformer to Blower Motor and Terminal Block)		45-24258-22				
11		Terminal Block		45-23222-02				
		Wiring Harness - Pressure Transducer		45-104130-03				
		Sensor/Clip Assembly (Thermistor)		47-102710-16				
		Push Mount Tie (for Memory Card Wire Tie)		64-25340-01				

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 24 17 SP AN/BN AA	RH1T 24 17 SP AN/BN JA	RH1T 24 17 ST AN AA	RH1T 24 17 ST AN JA	RH1T 36 17 SP AN/BN AA	RH1T 36 17 SP AN/BN JA
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)	AS-101930-01	AS-101886-01	AS-101930-06	AS-101886-13	AS-101930-02	AS-101886-02
16		Mounting Bracket - Control Board	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel	70-101729-01	70-101729-01	70-101729-02	70-101729-02	70-101729-02	70-101729-02
	Stk	Blower Wheel	703012	703012	703014	703014	703014	703014
20		Motor Mount - Band	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04
21		Motor Mount - Arm (4)	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10
22	Stk	Blower Motor	51-104354-01	51-104358-01	51-102171-03	51-104358-09	51-104355-01	51-104359-01
23		Mounting Bracket Cover	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 36 17 ST AN AA	RH1T 36 17 ST AN JA	RH1T 36 17 ST AN DA	RH1T 36 21 MT AN AA	RH1T 36 21 MT AN JA	RH1T 36 21 HT AN AA
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)	AS-101930-02	AS-101886-02	AS-101886-26	AS-101930-05	AS-101886-06	AS-101930-07
16		Mounting Bracket - Control Board	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel	70-101729-02	70-101729-02	70-101729-02	70-101729-08	70-101729-08	70-101729-08
	Stk	Blower Wheel	703014	703014	703014	703023	703023	703023
20		Motor Mount - Band	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04
21		Motor Mount - Arm (4)	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10
22	Stk	Blower Motor	51-104355-01	51-104359-01	51-103623-05	51-104355-05	51-104359-30	51-104355-07
		Power Factor Choke	N/A	N/A	N/A	46-24256-04	N/A	46-24256-04
23		Mounting Bracket Cover	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 36 21 HT AN JA	RH1T 36 21 MT AN DA				
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)	AS-101886-14	AS-101886-28				
16		Mounting Bracket - Control Board	AE-101049-01	AE-101049-01				
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel	70-101729-08	70-101729-08				
	Stk	Blower Wheel	703023	703023				
20		Motor Mount - Band	70-19927-04	70-19927-04				
21		Motor Mount - Arm (4)	70-19929-10	70-19929-10				
22	Stk	Blower Motor	51-104359-31	51-103623-06				
		Power Factor Choke	N/A	N/A				
23		Mounting Bracket Cover	AE-101797-01	AE-101797-01				

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 48 21 ST AN DA	RH1T 48 21 SP AN/BN AA	RH1T 48 21 SP AN/BN JA	RH1T 48 21 ST AN AA	RH1T 48 21 ST AN JA	RH1T 48 21 MT AN AA
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)	AS-101886-25	AS-101930-03	AS-101886-03	AS-101930-03	AS-101886-03	AS-101930-08
16		Mounting Bracket - Control Board	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel	70-101729-08	70-101729-08	70-101729-08	70-101729-08	70-101729-08	70-101729-08
	Stk	Blower Wheel	703023	703023	703023	703023	703023	703023
20		Motor Mount - Band	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04
21		Motor Mount - Arm (4)	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10
22	Stk	Blower Motor	51-103253-09	51-104356-01	51-104360-01	51-104356-01	51-104360-01	51-104356-10
		Power Factor Choke	N/A	46-24256-04	N/A	46-24256-04	N/A	46-24256-04
23		Mounting Bracket Cover	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 48 21 MT AN JA	RH1T 48 24 ST AN AA	RH1T 48 24 ST AN JA	RH1T 48 24 ST AN DA		
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)	AS-101886-15	AS-101930-04	AS-101886-04	AS-101886-27		
16		Mounting Bracket - Control Board	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01		
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel	70-101729-08	70-101729-04	70-101729-04	70-101729-04		
	Stk	Blower Wheel	703023	703015	703015	703015		
20		Motor Mount - Band	70-19927-04	70-19927-04	70-19927-04	70-19927-04		
21		Motor Mount - Arm (4)	70-19929-10	70-19929-10	70-19929-10	70-19929-10		
22	Stk	Blower Motor	51-104360-31	51-104356-02	51-104360-02	51-103253-10		
		Power Factor Choke	N/A	46-24256-04	N/A			
23		Mounting Bracket Cover	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01		

No.	Note s	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING MAJOR SERIES/CONTROLS VOLTAGE/MINOR SERIES	RH1T 60 21 ST AN AA	RH1T 60 21 ST AN JA	RH1T 60 21 ST AN DA	RH1T 60 24 ST AN AA	RH1T 60 24 ST AN DA	RH1T 60 24 ST AN JA
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)	AS-101930-09	AS-101886-16	AS-101886-29	AS-101930-04	AS-101886-05	AS-101886-04
16		Mounting Bracket - Control Board	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01	AE-101049-01
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel	70-101729-08	70-101729-08	70-101729-08	70-101729-04	70-101729-04	70-101729-04
	Stk	Blower Wheel	703023	703023	703023	703015	703015	703015
20		Motor Mount - Band	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04	70-19927-04
21		Motor Mount - Arm (4)	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10	70-19929-10
22	Stk	Blower Motor	51-104356-11	51-104360-32	51-103253-11	51-104356-02	51-103253-01	51-104360-02
		Power Factor Choke	46-24256-04	N/A	N/A	46-24256-04	N/A	N/A
23		Mounting Bracket Cover	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01	AE-101797-01

No.	Notes	MODEL		RH1T				
		CAPACITY		36				
		CABINET SIZE		17				
		COIL SIZE/METERING		SE				
		MAJOR SERIES/CONTROLS		AN				
		VOLTAGE/MINOR SERIES		JA				
BLOWER GROUP								
15	Stk	Blower Assembly (Includes items 16-22)		AS-101886-02				
16		Mounting Bracket - Control Board		AE-101049-01				
17		Transformer	See Electrical Group					
18		Control Board	See Electrical Group					
19		Blower Housing w/Wheel		70-101729-02				
	Stk	Blower Wheel		703014				
20		Motor Mount - Band		70-19927-04				
21		Motor Mount - Arm (4)		70-19929-10				
22	Stk	Blower Motor		51-104359-01				
		Power Factor Choke		N/A				
23		Mounting Bracket Cover		AE-101797-01				

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T	RH1T	RH1T
		CAPACITY	24	36	36	48	48	60
		CABINET SIZE	17	17	21	21	24	24
		COIL SIZE/METERING	ST	ST	MT	ST	ST	ST
COIL GROUP (TXV Coil)								
12		Replacement Coil w/TXV	RCH-2417STAVUA	RCH-3617STAVUA	RCH-3621MTAVUA	RCH-4821STAVUA	RCH-4824STAVUA	RCH-6024STAVUA
		Horizontal Adapter Kit	See specified RCH Coil Parts List					
		Drain Pan - Vertical	See specified RCH Coil Parts List					
		TXV	See specified RCH Coil Parts List					

No.	Notes	MODEL	RH1T	RH1T	RH1T	RH1T		
		CAPACITY	36	48	60	36		
		CABINET SIZE	21	21	21	21		
		COIL SIZE/METERING	HT	MT	ST	MT		
COIL GROUP (TXV Coil)								
12		Replacement Coil w/TXV	RCH-3621HTAVUA	RCH-4821MTAVUA	RCH-6021STAVUA	RCH-3621MTAVUA		
		Horizontal Adapter Kit	See specified RCH Coil Parts List					
		Drain Pan - Vertical	See specified RCH Coil Parts List					
		TXV	See specified RCH Coil Parts List					

No.	Notes	MODEL	RH1T	RH1T	RH1T			
		CAPACITY	24	36	48			
		CABINET SIZE	17	17	21			
		COIL SIZE/METERING	SPA	SPA	SPA			
COIL GROUP (Piston Coil)								
12		Replacement Coil w/Distributor-Piston Assembly	RCH-2417SPAVUA	RCH-3617SPAVUA	RCH-4821SPAVUA			
		Horizontal Adapter Kit	See specified RCH Coil Parts List					
		Drain Pan - Vertical	See specified RCH Coil Parts List					
		Flow Check/Distributor Assy	See specified RCH Coil Parts List					


No.	Notes	MODEL	RH1T	RH1T	RH1T			
		CAPACITY	24	36	48			
		CABINET SIZE	17	17	21			
		COIL SIZE/METERING	SPB	SPB	SPB			
COIL GROUP (Piston Coil)								
12		Replacement Coil w/Distributor-Piston Assembly	RCH-2417SPBVUA	RCH-3617SPBVUA	RCH-4821SPBVUA			
		Horizontal Adapter Kit	See specified RCH Coil Parts List					
		Drain Pan - Vertical	See specified RCH Coil Parts List					
		Flow Check/Distributor Assy	See specified RCH Coil Parts List					

No.	Notes	MODEL		RH1T				
		CAPACITY		36				
		CABINET SIZE		17				
		COIL SIZE/METERING		SE				
COIL GROUP (EEV Coil)								
12		Replacement Coil w/EEV		RCH-3617SEAVUA				
		Horizontal Adapter Kit	See specified RCH Coil Parts List					
		Drain Pan - Vertical	See specified RCH Coil Parts List					
		EEV	See specified RCH Coil Parts List					


No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING	RH1T 24 17 SP/ST	RH1T 36 17 SP/ST	RH1T 36 21 MT	RH1T 48 21 SP/ST	RH1T 48 24 ST	RH1T 60 24 ST
HEATER KITS								
		Heater Kit - 3kW/208-240/1	RXBH-1724A03J RXBH-1724B03J RXBH-1724C03J	RXBH-1724A03J RXBH-1724B03J RXBH-1724C03J	N/A	N/A	N/A	N/A
		Heater Kit - 5kW/208-240/1	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724B05J RXBH-1724C05J
		Heater Kit - 7kW/208-240/1	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J
		Heater Kit - 10kW/208-240/1	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J
		Heater Kit - 13kW/208-240/1	RXBH-1724A13J	RXBH-1724A13J	N/A	N/A	N/A	N/A
		Heater Kit - 15kW/208-240/1	N/A	RXBH-1724A15J	RXBH-1724A15J	RXBH-1724A15J	RXBH-1724A15J	RXBH-1724A15J
		Heater Kit - 18kW/208-240/1	N/A	RXBH-1724A18J	RXBH-1724A18J	RXBH-1724A18J	RXBH-1724A18J	RXBH-1724A18J
		Heater Kit - 20kW/208-240/1	N/A	N/A	RXBH-24A20J	RXBH-24A20J	RXBH-24A20J	RXBH-24A20J
		Heater Kit - 25kW/208-240/1	N/A	N/A	RXBH-24A25J	RXBH-24A25J	RXBH-24A25J	RXBH-24A25J
		Heater Kit - 30kW/208-240/1	N/A	N/A	N/A	N/A	N/A	RXBH-24A30J
		Heater Kit - 7kW/208-240/3	RXBH-1724A07C	RXBH-1724A07C	RXBH-1724A07C	RXBH-1724A07C	RXBH-1724A07C	RXBH-1724A07C
		Heater Kit - 10kW/208-240/3	RXBH-1724A10C	RXBH-1724A10C	RXBH-1724A10C	RXBH-1724A10C	RXBH-1724A10C	RXBH-1724A10C
		Heater Kit - 13kW/208-240/3	RXBH-1724A13C	RXBH-1724A13C	N/A	N/A	N/A	N/A
		Heater Kit - 15kW/208-240/3	N/A	RXBH-1724A15C	RXBH-1724A15C	RXBH-1724A15C	RXBH-1724A15C	RXBH-1724A15C
		Heater Kit - 18kW/208-240/3	N/A	RXBH-1724A18C	RXBH-1724A18C	RXBH-1724A18C	RXBH-1724A18C	RXBH-1724A18C
		Heater Kit - 20kW/208-240/3	N/A	N/A	RXBH-24A20C	RXBH-24A20C	RXBH-24A20C	RXBH-24A20C
		Heater Kit - 25kW/208-240/3	N/A	N/A	RXBH-24A25C	RXBH-24A25C	RXBH-24A25C	RXBH-24A25C
		Heater Kit - 30kW/208-240/3	N/A	N/A	N/A	N/A	N/A	RXBH-24A30C
		Heater Kit - 20kW/480/3	N/A	N/A	N/A	RXBH-24A20D	RXBH-24A20D	RXBH-24A20D
		Heater Kit - 25kW/480/3	N/A	N/A	N/A	RXBH-24A25D	RXBH-24A25D	RXBH-24A25D
		Heater Kit - 30kW/480/3	N/A	N/A	N/A	N/A	N/A	RXBH-24A30D

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING	RH1T 36 21 HT	RH1T 48 21 MT	RH1T 60 21 ST		
HEATER KITS							
		Heater Kit - 3kW/208-240/1	N/A	N/A	N/A		
		Heater Kit - 5kW/208-240/1	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J	RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J		
		Heater Kit - 7kW/208-240/1	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J	RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J		
		Heater Kit - 10kW/208-240/1	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J	RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J		
		Heater Kit - 13kW/208-240/1	N/A	N/A	N/A		
		Heater Kit - 15kW/208-240/1	RXBH-1724A15J	RXBH-1724A15J	RXBH-1724A15J		
		Heater Kit - 18kW/208-240/1	RXBH-1724A18J	RXBH-1724A18J	RXBH-1724A18J		
		Heater Kit - 20kW/208-240/1	RXBH-24A20J	RXBH-24A20J	RXBH-24A20J		
		Heater Kit - 25kW/208-240/1	RXBH-24A25J	RXBH-24A25J	RXBH-24A25J		
		Heater Kit - 30kW/208-240/1	N/A	N/A	N/A		
		Heater Kit - 7kW/208-240/3	RXBH-1724A07C	RXBH-1724A07C	RXBH-1724A07C		
		Heater Kit - 10kW/208-240/3	RXBH-1724A10C	RXBH-1724A10C	RXBH-1724A10C		
		Heater Kit - 13kW/208-240/3	N/A	N/A	N/A		
		Heater Kit - 15kW/208-240/3	RXBH-1724A15C	RXBH-1724A15C	RXBH-1724A15C		
		Heater Kit - 18kW/208-240/3	RXBH-1724A18C	RXBH-1724A18C	RXBH-1724A18C		
		Heater Kit - 20kW/208-240/3	RXBH-24A20C	RXBH-24A20C	RXBH-24A20C		
		Heater Kit - 25kW/208-240/3	RXBH-24A25C	RXBH-24A25C	RXBH-24A25C		
		Heater Kit - 30kW/208-240/3	N/A	N/A	N/A		
		Heater Kit - 7kW/480/3	N/A	N/A	RXBH-24A07D		
		Heater Kit - 20kW/480/3	RXBH-24A20D	RXBH-24A20D	RXBH-24A20D		
		Heater Kit - 25kW/480/3	RXBH-24A25D	RXBH-24A25D	RXBH-24A25D		
		Heater Kit - 30kW/480/3	N/A	N/A	N/A		

No.	Notes	MODEL CAPACITY CABINET SIZE COIL SIZE/METERING		RH1T 36 17 SE				
HEATER KITS								
		Heater Kit - 3kW/208-240/1		RXBH-1724A03J RXBH-1724B03J RXBH-1724C03J				
		Heater Kit - 5kW/208-240/1		RXBH-1724A05J RXBH-1724B05J RXBH-1724C05J				
		Heater Kit - 7kW/208-240/1		RXBH-1724A07J RXBH-1724B07J RXBH-1724C07J				
		Heater Kit - 10kW/208-240/1		RXBH-1724A10J RXBH-1724B10J RXBH-1724C10J				
		Heater Kit - 13kW/208-240/1		RXBH-1724A13J				
		Heater Kit - 15kW/208-240/1		RXBH-1724A15J				
		Heater Kit - 18kW/208-240/1		RXBH-1724A18J				
		Heater Kit - 7kW/208-240/3		RXBH-1724A07C				
		Heater Kit - 10kW/208-240/3		RXBH-1724A10C				
		Heater Kit - 13kW/208-240/3		RXBH-1724A13C				
		Heater Kit - 15kW/208-240/3		RXBH-1724A15C				
		Heater Kit - 18kW/208-240/3		RXBH-1724A18C				



Exploded View



Blower Assembly

NOTES

Stk It is recommended that stock be maintained for this part.
N/A Not Applicable